

Part No. 030450-10, Rev. C
May 2000

Advanced Routing

User Manual Release 4.2



www.alcatel.com

SwitchExpertSM Service Programs: An Alcatel service agreement brings your company the assurance of 7x24 no-excuses technical support. You'll also receive regular software updates to maintain and maximize your Alcatel product's features and functionality and on-site hardware replacement through our global network of highly qualified service delivery partners. Additionally, with 24-hour-a-day access to Alcatel's Service and Support web page, you'll be able to view and update any case (open or closed) that you have reported to Alcatel's technical support, open a new case or access helpful release notes, technical bulletins, and manuals. For more information on Alcatel's Service Programs, see our web page at www.ind.alcatel.com, call us at 1-800-995-2696, or email us at switchexpert@ind.alcatel.com.

**This Manual documents Release 4.2 Advanced Routing software.
This Manual is an addition to the 4.1 OmniSwitch and Omni Switch/Router User Manual.
The functionality described in this Manual is subject to change without notice.**

Copyright© 2000 by Alcatel Internetworking, Inc. All rights reserved. This document may not be reproduced in whole or in part without the express written permission of Alcatel Internetworking, Inc.

Alcatel[®] and the Alcatel logo are registered trademarks of Alcatel. Xylan[®], OmniSwitch[®], PizzaSwitch[®] and OmniStack[®] are registered trademarks of Alcatel Internetworking, Inc. X-Cell[™], Omni Switch/Router[™], OmniAccess[™], PizzaPort[™], X-Vision[™], AutoTracker[™], SwitchManager[™], SwitchStart[™], SwitchExpertSM, WebView[™], PolicyView[™] and the Xylan logo are trademarks of Alcatel Internetworking, Inc. All other brand and product names are trademarks of their respective companies.



26801 West Agoura Road
Calabasas, CA 91301
(818) 880-3500 FAX (818) 880-3505
info@ind.alcatel.com

US Customer Support—(800) 995-2696
International Customer Support—(818) 878-4507
Internet—<http://www.ind.alcatel.com>

Warning

This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in this guide, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user will be required to correct the interference at his own expense.

The user is cautioned that changes and modifications made to the equipment without approval of the manufacturer could void the user's authority to operate this equipment. It is suggested that the user use only shielded and grounded cables to ensure compliance with FCC Rules.

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus out in the radio interference regulations of the Canadian department of communications.

Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la Class A prescrites dans le reglement sur le brouillage radioelectrique edicte par le ministere des communications du Canada.

Table of Contents

1	IP Multicast Switching	1-1
	Introduction	1-1
	Hardware/Software Support	1-4
	IPMS and Multicast VLANs	1-5
	IPMS and MAC Addresses	1-5
	IPMS and Flood Limits	1-5
	Installing IPMS	1-6
	IPMS User Interface Commands	1-7
	IP Multicast Switching Menu	1-7
	Enabling or Disabling IPMS	1-7
	Viewing the IPMS Forwarding Table	1-9
	Viewing Multicast Groups	1-11
	Viewing the IPMS Neighbor Table	1-12
	Displaying IPMS Summary Status	1-13
	Viewing IPMS Statistics	1-14
	Resetting Statistics to Zero	1-15
2	IP Multicast Routing	2-1
	Introduction	2-1
	Hardware/Software Support	2-3
	Installing MrouteD	2-4
	Disabling MrouteD	2-4
	User Interface Commands	2-5
	IP Multicast Routing Menu	2-5
	Enabling or Disabling Multicast Routing	2-6
	Updating the MrouteD Configuration	2-6
	Viewing Current Cache Life	2-7
	Viewing the Multicast Forwarding Table	2-8
	Displaying the Interface Configuration Table	2-9
	Adding an Entry to the Interface Configuration Table	2-10
	Modifying an Entry in the Interface Configuration Table	2-13
	Modifying the Boundary List	2-14
	Modifying the Alternate Network List	2-15
	Disabling or Enabling Pruning	2-17
	Viewing Prune Requests	2-17
	Viewing the Multicast Routing Table	2-19
	Viewing the Group Table	2-20

3	GateD Basics	3-1
	GateD Requirements	3-1
	Protocols Supported	3-1
	Routing Functions	3-2
	Configuration File	3-3
	UI commands	3-3
	Routing Terminology	3-4
	Configuration Overview for GateD	3-7
	The GateD Configuration File	3-9
	Statement Syntax	3-11
	Syntax Description Conventions	3-12
	Statement Order	3-13
	GateD Quick Start	3-15
	Enable RIP, Version 1	3-15
	Enable RIP, Version 2	3-16
	Enable OSPF	3-16
	Enable BGP	3-18
4	GateD Global Configuration	4-1
	GateD Global UI Commands	4-2
	GateD Subcommands	4-2
	Displaying GateD Status	4-3
	Displaying GateD Routing Information	4-3
	Reloading the GateD Configuration File	4-4
	Restarting GateD	4-4
	Reconfig or Restart?	4-4
	Route Preference	4-5
	Selecting a Route	4-6
	Assigning Preferences	4-6
	Setting Route Preference	4-7
	The Options Statement	4-8
	Options Statement Example	4-10
	Definition Statements	4-11
	Definition Statement Example	4-13
5	GateD Router Interfaces	5-1
	Interfaces and Switch Router Ports	5-1
	Protocol Specific Interfaces	5-2
	Global Interfaces Commands	5-2
	The Interface Statement	5-3
	Options Statements	5-4
	Interface Statements	5-5

Define Statements	5-7
Interface Statement Example	5-8
6 The Routing Information Protocol (RIP)	6-1
The RIP Routing Table	6-2
RIP Version 2	6-3
RIP I and Network Masks	6-4
Specifying Gateways When Exporting RIP Routes	6-4
Restricting RIP Traffic to Gateways	6-6
RIP UI Commands	6-8
Viewing RIP Interface Statistics	6-8
Viewing RIP Interface Configuration	6-9
Listing RIP Peers	6-10
The RIP Statement	6-11
RIP Statement Example	6-15
Application Example	6-16
Router 1	6-16
Router 2	6-16
Router 3	6-17
7 The Open Shortest Path First (OSPF) Protocol	7-1
OSPF Areas	7-2
Classification of Routers	7-3
Virtual Links	7-4
Stub Areas	7-5
OSPF UI Commands	7-6
Displaying OSPF Status	7-6
Displaying OSPF Neighbors	7-7
Displaying the OSPF Interface List	7-9
Displaying Details of a Specific OSPF Interface	7-11
Displaying the OSPF Area List	7-12
Displaying the OSPF Link State Database	7-13
The OSPF Statement	7-14
OSPF General Statements	7-16
OSPF Backbone and Areas	7-18
Common Interface Parameters	7-22
Interface Parameters for Point-to-Point Links	7-22
Interface Parameters for Non-Broadcast Multi-Access Links	7-23
Using Authentication in OSPF	7-23
No Authentication	7-24
Simple Authentication Key	7-24
MD5 Authentication	7-25
OSPF Statement Example	7-26

Application Example	7-27
Switch 1	7-27
Switch 2	7-28
Switch 4	7-29
8 The Border Gateway Protocol (BGP)	8-1
BGP Speakers	8-1
Routing Decisions	8-2
BGP Features	8-2
Classless Interdomain Routing (CIDR)	8-2
BGP Path Selection	8-3
Local Preference	8-3
How local_pref is Derived	8-4
How Route Preferences are Translated by local_pref	8-4
Multi-Exit Discriminator (MED)	8-6
Communities	8-6
Route Dampening	8-6
Route Reflection	8-7
Configuring Route Reflection	8-9
Redundant Route Reflectors	8-9
BGP UI Commands	8-10
Viewing BGP Statistics	8-10
Viewing a List of BGP Peers	8-11
Viewing Detailed Peer Information	8-12
Viewing BGP Paths	8-14
Viewing Detailed BGP Path Information	8-15
The BGP Statement	8-16
The autonomoussystem Statement	8-17
Global BGP Statements	8-18
Group Statements	8-19
Classic External BGP Groups	8-20
Internal BGP Groups Using Internal Protocol Routing	8-21
Internal Group with No IP-Level Routing	8-23
External Group with Test Peers	8-24
Peer Statements	8-25
The Allow Clause	8-25
The Peer Clause	8-26
Route Dampening Statements	8-30
Community Statements	8-31

9	Other GateD Protocols	9-1
	The Kernel Interface	9-2
	The Kernel Statement	9-2
	Kernel Statement Example	9-5
	Static Routes	9-6
	Static Routes Creation (GateD vs. <code>aisr</code> command)	9-6
	The Static Statement	9-6
	Static Statement Example	9-8
	The Router Discovery Protocol	9-9
	The Router Discovery Server	9-9
	The Router Discovery Server Statement	9-10
	Router Discovery Server Statement Example	9-11
	The Router Discovery Client	9-12
	The Router Discovery Client Statement	9-12
	Router Discovery Client Statement Example	9-13
	The Internet Control Message Protocol (ICMP)	9-14
	The ICMP Statement	9-14
10	Route Importing, Exporting, and Filtering	10-1
	Route Filters	10-2
	Route Filter Example	10-3
	Route Importation	10-4
	Specifying Preferences	10-4
	Importing Routes from BGP	10-4
	Importing Routes from BGP Using AS Path Regular Expressions	10-5
	Examples of AS Path Regular Expressions	10-6
	Importing Routes from RIP	10-7
	Example	10-7
	Importing Routes from OSPF	10-8
	Example of Import Statement for OSPF	10-8
	Route Exportation	10-9
	Specifying Metrics	10-9
	Exporting to BGP	10-10
	Example	10-10
	Exporting to RIP	10-11
	Example	10-12
	Exporting to OSPF	10-12
	Example	10-13
	Exporting Routes from Non-Routing Protocols	10-13
	Non-routing with Interface	10-13
	Non-routing by Protocol	10-14
	Example	10-14
	Exporting by AS Path	10-14
	Example	10-15

Exporting by Route Tag	10-15
Example	10-15
11 Route Aggregation	11-1
Specifying Preferences	11-2
The Aggregate and Generate Statements	11-3
Aggregate and Generate Statement Example	11-5
12 Tracing	12-1
Modifying the mpm.cmd File	12-1
The Trace Statement	12-2
Trace Statement Example	12-3
13 Virtual Router Redundancy Protocol (VRRP)	13-1
Introduction	13-1
Virtual Routers	13-1
VRRP Authentication	13-2
VRRP MAC Addresses	13-3
VRRP and ARP Requests	13-3
VRRP and ICMP Redirects	13-3
VRRP and Token Ring	13-3
VRRP Configuration Example 1	13-4
VRRP Configuration Example 2	13-5
Installation	13-6
Disabling VRRP	13-6
User Interface Commands	13-7
VRRP Submenu	13-7
Adding a Virtual Router Instance	13-8
Deleting a Virtual Router Instance	13-11
Modifying a Virtual Router Instance	13-11
Shutting Down the VRRP Process	13-11
Restarting the VRRP Process	13-12
Resetting Statistics	13-12
Viewing VRRP Statistics	13-12
Viewing Statistics for All Instances	13-12
Viewing Statistics for a Single VRID	13-13
VRRP SNMP Traps	13-14
Viewing Configuration Parameters	13-15
14 Routing Domains	14-1
Introduction	14-1
Routing Domains and RIP	14-2
Routing Domains and GateD	14-2
Routing Domains UI Overview	14-3

Configuration Overview	14-4
Adding a Routing Domain	14-4
Deleting a Routing Domain	14-6
Adding Groups and VLANs to a Routing Domain	14-6
Deleting Interfaces From a Routing Domain	14-6
Configuring Global Parameters for Routing Domains	14-7
Modifying a Routing Domain	14-7
Viewing Routing Domain Configuration	14-8
Viewing All Routing Domains	14-8
Viewing Information for a Particular Routing Domain	14-9
Index	I-1

