

# Index

- ! commands 2-11
- + or - commands 14-5
- ? command 2-2, 2-10
- 10/100 auto-sensing ports 1-11
- 10/100** command 12-2
- 10/100 ports 12-3, 12-6
- 10/100cfg** command 1-11, 12-3, 12-5
- 10/100vc** command 1-11, 12-6
- 802.1Q 12-1, 13-1
- 802.2 pass through 15-11, 16-31

## A

- ab** command 3-8
- access rate 25-9, 25-17
- addprtchnl** command 12-9
- addvp** command 16-5, 16-16, 16-27, 16-42, 16-57
  - translations 15-11
- adjacency
  - definition for XMAP 18-2
- admin login 2-17, 5-2
- aipxsr** command 24-12
- aisr** command 22-16
- application example 1-2
- ARP protocol 22-3
- ASCII terminal commands 2-3
- at** command 16-16
- atvl** command 17-19, 19-27
- Authenticated Groups 16-1
  - as mobile group 16-5
  - configuring 16-26
- Authentication 16-1
- Authentication Management Console (AMC)
  - software 16-5
- autoencaps** command 15-25
- auto-sensing ports
  - see 10/100 auto-sensing ports
- auto-switch
  - diagram 16-29
  - timer 16-29
- Auto-Switch bridge mode 16-28

- AutoTracker
  - application examples 21-1
  - configuring policies 17-4
  - DHCP MAC address policy 17-3
  - DHCP policy 17-25
  - DHCP policy example 17-23
  - DHCP port policy 17-3
  - MAC address policy 17-2
  - menu 19-2
  - network address policy 17-2
  - policies 17-1, 19-3
  - port binding policy 17-2
  - port policy 17-2
  - protocol policy 17-2
  - user-defined policy 17-2
- AutoTracker policies
  - in mobile group 16-32
- avlbootpmode** command 23-1

## B

- backbones 12-7
  - Ethernet 12-7
- backplane threshold 8-4
- back-to-back configuration 25-5
- back-to-back configurations 25-5
- Banyan Vines
  - translations for 15-8
  - VLAN for 19-31
- BECN 26-8
- boot configuration A-1
- BOOTP relay 23-3
  - and authentication 23-4
- br** command 14-3, 16-16
- BRI. See ISDN, Basic Rate Interface
- bridge 14-5
- bridge forwarding table 14-6
- bridge mode 16-28
  - non-Ethernet default 16-28
  - optimized 16-28
  - Spanning Tree 16-28
- bridge port
  - statistics 14-12
- bridging
  - Frame Relay 26-11, 26-48
- bsadd** command 31-3

**bsdelete** command 31-9  
**bsmodify** command 31-7

## C

cables B-1  
CAM threshold 8-5  
**camstat** command 6-21  
**caplog** command 7-12  
**cas** command 13-5  
    Frame Relay bridging 26-48  
    Frame Relay routing 26-51  
    Frame Relay trunking 26-53  
**cats** command 16-2  
**cb** command 3-8  
**cd** command 16-59  
chassis summary 6-3  
**chnlinfo** command 12-12  
**cmdlog** command 7-10  
command history 2-11  
Committed Information Rate (CIR)  
    Frame Relay 26-6  
configuration files 3-2  
**conlog** command 7-11  
console management port 1-11  
consumable resources 8-2  
**cp** command 3-6  
CPU threshold 8-5  
**cratvl** command 19-4, 19-16, 19-31  
**crechnl** command 12-8  
credit  
    transmit 16-29  
**crgp** command 16-5, 16-18, 19-4  
    translations 15-11  
**crmvcvl** command 20-5

## D

**das** command 13-9  
    Frame Relay 26-57  
date 6-8  
Daylight Savings Time (DST) 6-8, 6-12  
**db** command 3-8  
**dbrmap** command 14-17  
**debuglog** command 7-14  
def\_group variable 16-11  
default group 16-11  
default VLAN 19-4, 19-5  
    routing 21-7

**defvl** command 19-5  
**delechnl** command 12-10  
**delprtchnl** command 12-11  
DES 9-4  
DHCP 23-3  
    application example 17-23  
    overview 23-3  
    policies 17-3  
    with non-DHCP clients 23-7  
DHCP client 17-24  
DHCP server 17-24  
diag login 2-17, 5-2  
diag user login 33-4  
diagnostics  
    configuring 33-13  
    configuring for Ethernet slots 33-14  
    displaying available tests 33-12  
    login 33-4  
    running 33-6  
    temperature masking 33-5  
    test cable schematics 33-15  
diagnostics sub-menu 2-2, 33-4  
digital services 30-2  
Discard Eligibility  
    Frame Relay 26-7  
displaying Ethernet switch statistics 15-20  
Displaying IPX RIP/SAP Filters on page 25-22  
    24-21  
DLCI 26-4  
DLCMI 26-20  
domain bridging  
    mapping table 14-17  
domain name servers 11-1  
DST 6-8  
**dt** command 6-8  
duplicate MAC addresses 6-20  
dynamic port assignment 16-2

## E

E1  
    fractional 25-2  
    framing 30-2  
**eb** command 3-8  
**echo** command 2-16  
**edit** command 3-7  
edit commands tutorial 3-11, 3-12  
encapsulation 15-1  
    IP 15-1  
    IPX 15-1, 15-3

- error messages 32-5
  - ethdef** command 15-18
  - Ethernet
    - 10/100 ports 12-3
    - 802.1Q 12-1
    - auto-sensing ports 12-3
    - auto-switch bridge mode 16-28
    - backbones 12-7
    - default translations 15-12, 15-18
    - duplex mode 12-6
    - Ethertype translation 15-13
    - high-density ports 12-5
    - link mode configuration 12-5
    - LLC translation 15-15
    - OmniChannel 12-1
    - path MTU discovery 22-38
    - port mapping 16-63
    - port mirroring 16-54
    - port monitoring 16-58
    - SNAP translation 15-14
  - Ethernet 10/100 ports 12-6
    - auto-negotiation 12-6
    - configuring 12-3
  - Ethernet modules
    - configuring tests 33-14
    - displaying switch statistics 15-20
  - Ethernet ports
    - configuring 1-11
    - LEDs 1-10
  - event 11-3
  - events** command 11-5
- ## F
- facility datalink 30-5
  - Fast Ethernet
    - configuring 12-6
  - FECN 26-9
  - file** command 2-2, 3-1
  - files 3-3
    - configuration 3-2
    - file name directory 3-3
    - flash memory 3-2
    - image 3-2
    - managing 3-1
    - required 3-2
  - Filter Command. See UI Table Filtering
  - flc** command 14-19
  - flood limit 16-29
    - configuring 14-19
    - displaying 14-20
  - fls** command 14-20
  - fping** command 22-21
  - fr** command 26-17
  - fradd** command 26-26
  - frame flooding 19-15
  - Frame Relay
    - back-to-back configurations 26-2
    - BECN 26-8
    - bridging 26-11, 26-48
    - cables 26-3, B-1
    - CIR 26-6
    - congestion control 26-6
    - control signals 26-37
    - Discard Eligibility 26-7
    - DLCI 26-4
    - DLCMI 26-20
    - errors 26-40
    - FECN 26-9
    - IP routing 26-12
    - IPX routing 26-15
    - polling 26-20
    - port configuration 26-18
    - Routing Group 26-50
    - self-configuration 26-5
    - statistics 26-32
    - translations 26-10
    - trunking 26-16, 26-53
    - viewing parameters 26-27
    - Virtual Circuit 26-4, 26-11
    - Virtual Circuit configuration 26-26
    - virtual ports 26-11
  - Frame Relay boards
    - ipxsap** command with, 24-10
  - frclear** command 26-45
  - frdelete** command 26-30
  - frmodify** command 26-18
  - frstatus** command 26-32
  - frview** command 26-27
  - fsck** command 3-14
  - FTP
    - commands 3-3
  - FTP client 3-1
  - ftp** command 3-3

### FTP commands

- ? 3-3
- ascii 3-3
- binary 3-3
- bye 3-3
- cd 3-3
- delete 3-3
- dir 3-3
- get 3-3
- hash 3-3
- lpwd 3-3
- ls 3-3
- put 3-3
- pwd 3-3
- quit 3-3
- remotehelp 3-3
- user 3-3

FTP servers 3-1, 3-2

**fwtlv** command 17-22, 19-30

## G

generic service relays 23-18

### GMAP

- configuring 18-11
- gap time 18-11
- update time 18-12

**gmapgaptime** command 18-11

**gmapholdtime** command 18-12

**gmapls** command 18-13

**gmapst** command 18-11

**gmapupdtype** command 18-12

**gmcfg** command 16-11, 19-2

**gmstat** command 19-2

**gp** command 16-16, 16-36

### Group 16-1

- authenticated 16-1, 16-26
- changing parameters 16-38
- creating 16-17
- deleting 16-41
- flood limits 14-20
- IP address 16-19
- IP routing in 16-19
- mobile 16-1
- non-mobile 16-1, 16-14
- port assignment to 16-2
- viewing 16-36
- mobile 16-5, 16-26
- WAN routing 16-18, 16-33

Group Mobility 16-2

- enabling switch-wide 16-11

## H

hardware diagnostics 33-1

**hdcfg** command 8-2

**hdstat** command 8-6, 8-7

Health Statistics 8-1

- management menu 8-1

- resource thresholds 8-2

Hello messages

- and XMAP 18-2

**help** command 2-2

**history** command 2-11

**hmstat** command 8-8

**hpstat** command 8-8

**hreset** command 8-9

## I

**ib** command 3-9

ICMP protocol 22-3

ICMP statistics and errors 22-19

**icmps** command 22-19

image files 3-2

**imgcl** command 3-5

**info** command 6-6

**interface** command 2-2

Interswitch Protocols (XIP) 18-1

- submenu 18-1

Inverse ARP 26-12

### IP

- abbreviated address format 2-13

- address 3-2

- BOOTP relay 23-3

- DHCP 23-3

- framing type 16-22

- RIP mode 16-20

IP address

- changing in group 16-39

**ip** command 22-7

IP protocol 22-3

- IP RIP Filters
  - adding "global" filters 22-30
  - adding specific filters 22-31
  - configuring 22-30
  - deleting filters 22-33
  - displaying all filters 22-34
  - displaying global filters 22-35
  - displaying specific filters 22-35
  - filter precedence 22-32
- IP routing 16-19
  - adding an IP address to ARP table 22-9
  - adding IP static routes 22-16
  - Address Resolution Protocol 22-3
  - flushing the RIP Routing Table 22-29
  - Internet Control Message Protocol 22-3
  - Internet Protocol 22-3
  - Open Shortest Path First Protocol 22-2
  - PING command 22-21
  - PINGing a host 22-21
  - removing IP static routes 22-18
  - Routing Information Protocol 22-2
  - Simple Network Management Protocol 22-3
  - TELNET protocol 22-3
  - tracing an IP route 22-29
  - Transmission Control Protocol 22-3
  - User Datagram Protocol 22-3
  - viewing ICMP statistics and errors 22-19
  - viewing IP statistics and errors 22-12
  - viewing RIP statistics and errors 22-24
  - viewing TCP statistics 22-25
  - viewing the Address Translation Table 22-8
  - viewing the IP routing table 22-14
  - viewing the IP-to-MAC Table 22-36
  - viewing the TCP Connection Table 22-27
  - viewing the UDP listener table 22-23
  - viewing UDP statistics and errors 22-22
- ipf** command 22-34
- ipmac** command 22-36
- ipr** command 22-14
- ips** command 22-12
- IP-to-MAC Table
  - displaying all entries 22-36
  - displaying specific entries 22-37
  - flushing entries 22-37
- IPX
  - address mapping 15-5
  - triggered RIP and SAP 16-35
  - VLANs 21-4
- ipx** command 24-4
- IPX RIP
  - description of protocol 24-2
- IPX RIP/SAP Filtering
  - adding global filters 24-18
  - adding specific filters 24-19
  - configuring NetWare for WAN links 24-33
  - default setting of filters 24-17
  - deleting filters 24-21
  - displaying all filters 24-22
  - displaying global filters 24-23
  - displaying specific filters 24-23
  - filter precedence 24-24
  - uses for filters 24-17
- IPX routing
  - adding an IPX static route 24-12
  - configuring IPX Serialization Packet Filtering 24-25
  - configuring IPX Watchdog Spoofing 24-27
  - configuring NetWare for WAN links 24-33
  - configuring SPX Keepalive Spoofing 24-29
  - disabling IPX Router Complex 24-14
  - displaying IPX Routing Table 24-5
  - enabling IPX Router Complex 24-14
  - flushing RIP/SAP tables 24-14
  - GNS Output filters 24-17
  - PINGing an IPX node 24-15
  - removing IPX static routes 24-13
  - RIP Input filters 24-17
  - RIP Output filters 24-17
  - RIP/SAP Filters
    - configuring 24-17
  - SAP Input filters 24-17
  - SAP Output filters 24-17
  - the IPX submenu 24-4
  - viewing IPX statistics 24-8
  - viewing SAP Bindery 24-10
- IPX Serialization Packet Filtering
  - configuring 24-25
- IPX static routes
  - removing 24-13
- IPX Watchdog Spoofing
  - configuring 24-27
- ipxdrt** command 24-38
- ipxext** command 24-37
- ipxf** command 24-22
- ipxfilter** command 24-18
- ipxflush** command 24-14
- ipxoff** command 24-14
- ipxping** command 24-15
- ipxr** command 24-5

- ipxs** command 24-8
- ipxsap** command 24-10
- ipxserialf** 24-25
- ipxserialf** command 24-25
- ipxspoof** 24-27
- ipxt** command 24-35
- ipxtimer** command 24-35
- ISDN
  - Basic Rate Interface (BRI) 25-2
- isdn** command 29-3
- ISDN Ports
  - accessing the ISDN menu 29-3
  - deleting an ISDN configuration entry 29-5
  - displaying ISDN configuration entry status 29-7
  - modifying an ISDN configuration entry 29-4
  - viewing an ISDN configuration entry 29-6
- isdnd** command 29-5
- isdnm** command 29-4
- isdns** command 29-7
- isdnv** command 29-6

## K

- kill** command 2-21

## L

- lb** command 3-9
- learning 15-26
- LEDs
  - Ethernet port LEDs 1-10
  - management LEDs 1-9
- Line Interface Unit (LIU) 30-5, 30-8
- link** command 28-2
- linkadd** command 28-3, 28-4
- linkdelete** command 28-11
- linkmodify** command 28-9
- linkstatus** command 28-15
- linkview** command 28-12
- LLC 15-2, 15-15
- load** command 3-4
- login accounts 2-17, 5-2
- logout** command 2-2
- lookup** command 2-10
- ls** command 3-4, 3-2

## M

- MAC 14-14, 14-15
- MAC devices
  - VLAN membership 17-22, 19-30
- main menu 2-2
- mas** command 13-7
  - Frame Relay 26-56
- maskta** command 33-5
- mcvl** command 20-13
- MD5 9-4
- media access control - see MAC
- memory management 6-19
- memory threshold 8-5
- memstat** command 6-19
- Mobile Groups 16-1, 16-5
  - aging out devices 16-11
  - AutoTracker policies 16-32
  - configuring 16-26
  - def\_group 16-11
  - default group 16-11
  - dynamic port assignment 16-5
  - Ethernet and Token Ring ports 16-2
  - move\_from\_def 16-12
  - move\_to\_def 16-11
  - multiple 16-2
  - policies 17-1, 17-20
  - ports in 16-5
  - primary group 16-12
  - static port assignment 16-5
  - viewing 17-19
- modatvl** command 17-6, 17-18, 19-24
- modmcvl** command 20-9, 20-12
- modvl** command 16-20, 16-38, 19-4, 19-19
- modvp** command 16-43, 16-57
  - translations 15-11
- move\_from\_def variable 16-12
  - set in mpm.cmd 16-12
- move\_to\_def variable 16-11
- MPM Module
  - serial port 6-14
- MTU 22-38
- multicast claiming 6-23

- multicast VLANs 19-1, 20-1
  - creating 20-4
  - deleting 20-11
  - device assignment in 20-2
  - frame flooding in 20-3
  - modifying 20-9
  - multicast addresses 20-6
  - multicast claiming, compared 20-2
  - policies 20-12
  - recipients 20-1, 20-7
  - viewing 20-13
- multiple spanning tree 13-2
- multiple user sessions 2-18

## N

- names** command 11-1
- nb** command 3-9
- net** command 31-2
- NetBIOS relays 23-10
- network address policy 19-7
  - precedence 17-2
- Network Time Protocol 9-1
- networking** command 2-2, 22-6
- newfs** command 3-15
- noecho** command 2-16
- non-Ethernet ports 16-28
- non-mobile group 16-14
- Non-mobile Groups 16-1
- ntaccess** command 9-5
- ntaccess** command 9-36
- ntadmin** command 9-5
- ntadmin** command 9-33
- ntconfig** command 9-5
- ntinfo** command 9-5
- ntinfo** command 9-15
- NTP
  - advertised precision 9-14
  - client/server 9-8
  - client/server authentication 9-9
  - current leap second 9-30
  - event timer subsystem 9-28
  - I/O subsystem 9-27
  - key ID 9-34
  - key type 9-35
  - list of peers 9-15
  - local server information 9-21
  - local server statistics 9-23
  - loop filter information 9-26

- packet count statistics 9-29
- peer association 9-12
- peer associations 9-14
- peer memory usage 9-26
- peer summary information 9-16
- primary receive timeout 9-33
- reset subsystem counters 9-28
- server statistics 9-24
- specify password 9-34
- system flag 9-35
- trusted list 9-37
- version number 9-20
- ntpaddpeer** command 9-12
- ntpaddserv** command 9-13
- ntpauth** command 9-38
- ntpbcast** command 9-13
- ntpckey** command 9-37
- ntpcres** command 9-39
- ntpctlk** command 9-37
- ntpctlstat** command 9-29
- ntpctrap** command 9-41
- ntpdelay** command 9-33
- ntpdisable** command 9-35
- ntpdkey** command 9-38
- ntpdres** command 9-41
- ntpdtrap** command 9-42
- ntpenable** command 9-35
- ntpiconfig** command 9-6
- ntpiconfig** command 9-8
- ntpinfo** command 9-21
- ntpio** command 9-27
- ntpkeyid** command 9-34
- ntpkeytype** command 9-35
- ntpleap** command 9-30
- ntploop** command 9-26
- ntplpeers** command 9-15
- ntpmem** command 9-26
- ntpmlist** command 9-31
- ntpmmon** command 9-31
- ntpmres** command 9-41
- ntppasswd** command 9-34
- ntppeers** command 9-16
- ntpprec** command 9-14
- ntppreset** command 9-28
- ntppstat** command 9-24
- ntpreqk** command 9-36
- ntpreset** command 9-28
- ntpshowpeer** command 9-18
- ntpstat** command 9-23

- ntpptimeo** command 9-33
- ntptimer** command 9-28
- ntpunconfig** command 9-14
- ntpvers** command 9-20
- ntpvkey** command 9-37
- ntpvres** command 9-40
- ntpvtrap** command 9-42
- ntstats** command 9-5, 9-23

## O

- OA-512 1-5
  - application example 1-2
  - power cords 1-13
  - rear panel 1-12
  - slot designations 1-8
- OA-512-BRI-S/T 1-19
  - jumper settings 1-20
- OA-512-BRI-U 1-17
- OA-512-FT1/FE1 1-15
  - jumper settings 1-16
- OA-512-USP 1-21
- OmniAccess 16-1
  - OA-512 1-5
  - OA-512-BRI-S/T 1-19
    - jumper settings 1-20
  - OA-512-BRI-U 1-17
  - OA-512-FT1/FE1 1-15
    - jumper settings 1-16
  - OA-512-USP 1-21
  - slot conventions 25-8, 25-14, 27-4, 28-1, 29-4, 30-1
- OmniChannel 12-1, 12-7
  - creating 12-8
  - Ethernet 12-7
  - ports 12-9
  - primary/secondary ports 12-11
- optimized bridge mode 16-28
- OSPF protocol 22-2
- output translations 15-27

## P

- password 2-17, 5-2
  - changing 5-2
- path MTU discovery 22-38
- ping** command 22-21
- pin-outs B-2
- pmapcr** command 16-16

- pmapdel** command 16-16
- pmapmod** command 16-16
- pmapv** command 16-16
- pmcfg** command 16-59
- pmdelete** command 16-61
- pmon** command 16-60
- pmpause** command 16-61
- pmstat** command 16-62
- PMTU 22-38
- Point-to-Point Protocol (PPP)
  - accessing the PPP menu 27-5
  - adding a PPP entity 27-8
  - deleting a PPP entity 27-20
  - displaying PPP entity status 27-17
  - modifying a PPP entity 27-13
  - setting global parameters 27-6
  - viewing PPP entity configurations 27-14
- policies
  - AutoTracker 17-1
  - configuring 17-4
  - DHCP 17-25
  - DHCP example 17-23
  - DHCP MAC address 17-3
  - DHCP port 17-3
  - IP 19-7
  - IPX 19-7
  - MAC address 17-2
  - network address 17-2, 19-7
  - port 17-2, 19-9
  - port binding 17-2
  - protocol 17-2
  - user-defined 17-2
- port configuration 25-9
- port mapping 16-16
  - example 16-63
  - operation of 16-64
  - relationship to policies 16-63
  - subset of ports 16-64
- port mirroring 16-31, 16-54
  - disabling 16-57
  - enabling 16-57
  - operation of 16-54
  - RMON probe 16-55
- Port Monitoring 16-58
  - menu 16-58
  - starting a session 16-60
  - statistics 16-62
- port monitoring resources 16-59



port policy 19-9  
     backbone connections 19-12  
     inactive VLANs 19-12  
     silent stations 19-12  
     with VAP 18-9  
     usefulness 19-12  
 port tests  
     cabling 33-8, 33-15  
 ports 16-47  
     assignment to Group 16-2  
     Frame Relay 26-1  
     information 16-47  
     spanning tree 14-27  
     statistics 16-50  
     translations 15-19  
 power cords 1-13  
**ppp** command 27-5  
**pppadd** command 27-8  
**pppdelete** command 27-20  
**pppglobal** command 27-6  
**pppmodify** command 27-13  
**pppstatus** command 27-17  
**pppview** command 27-14  
 probes 11-3  
**probes** command 11-4  
**prty\_disp** command 16-16  
**prty\_mod** command 16-16  
**pw** command 2-10, 5-2  
**pwd** command 3-2

## R

**rb** command 3-10  
 rear panel 1-12  
 reboot 5-3  
     - see also boot  
**reboot** command 5-3  
 receive threshold 8-3  
 re-executing commands 2-11  
 reg\_port\_rule variable 19-9  
**relayc** 23-2  
**relayc** command 23-1  
**relays** command 23-22  
 remote trunking stations 14-16  
**res** command 11-1  
 resource thresholds 8-2  
 RIP protocol 22-2  
**ripflush** command 22-29  
**rips** command 22-24  
**ripxsr** command 24-13  
**risr** command 22-18  
**rm** command 3-4  
**rmatvl** command 19-4, 19-26  
**rmgp** command 16-41  
**rmmcvl** command 20-11  
 RMON 11-3  
**rmvp** command 16-44  
 routing  
     default VLAN 21-7  
     Frame Relay 26-50

## S

sampling interval 8-6  
 SAP  
     description of protocol 24-2  
 SAP Bindery  
     viewing the, 24-10  
**sc** command 6-3  
 Search Command. See UI Table Filtering  
**seclog** command 7-14  
 security 5-1  
**security** command 2-2  
**selgp** command 14-5  
**ser** command 3-4, 6-14  
 serial port 6-14  
     parameters 6-14  
**si** command 6-4  
 single spanning tree 13-2  
**slot** command 6-16  
 slot designations 1-8, 25-8, 25-14, 27-4, 28-1, 29-4, 30-1  
 slot table 6-16  
 SNAP 15-2, 15-14  
 SNMP protocol 22-3  
 SNMP statistics 10-7  
 SNMP traps 10-7  
**snmps** command 10-7  
 software  
     switch 3-3  
 Spanning Tree 16-28  
     non-mobile group 16-15  
 spanning tree 14-25  
     parameters 14-22, 14-25, 14-29  
     ports 14-27  
 split clocking 25-11  
 SPX  
     description of protocol 24-2

- SPX Keepalive Spoofing
    - configuring 24-29
    - SPX-Packet tolerance counting 24-29
  - spxspoof** 24-29
  - static bridge address 14-11
    - configuring 14-8
  - static port assignment 16-2
  - static routes
    - adding IP 22-16
    - removing IP 22-18
  - statistics 25-20
    - module level 8-8
    - port level 8-8
    - port monitoring 16-62
    - resetting 8-9
    - switch level 8-6
  - STATUS ENQUIRIES
    - Frame Relay 26-5, 26-20, 26-21
  - summary** command 2-2, 6-1
  - swch** command 15-19, 15-20
  - switch
    - software 3-3
  - switch** command 2-2, 15-17
  - switch menu 15-17
  - switch software
    - Boot prompt 3-5
    - loading with FTP 3-2
    - loading with ZMODEM 3-4
  - swlogc** command 7-6
  - syscfg** command 6-20
  - syslog** command 7-2
  - systat** command 6-17
  - system boot A-2
    - commands 3-6
    - See also boot
  - system** command 2-2
  - system description 6-20
  - system info 3-13, 6-5
  - system menu 3-13, 6-5
  - system prompt 2-4
  - system statistics 6-17
  - system variables 6-2
- ## T
- T1
    - fractional 25-2
    - framing 30-2
  - T1/E1 menu 30-3
  - T1/E1 ports 30-1
    - alarms 30-10
    - Extended Superframe 30-2, 30-4
    - facility datalink 30-5
    - line coding 30-5, 30-8
    - Line Interface Unit (LIU) 30-5, 30-8
    - loopback 30-6, 30-9
    - remote statistics 30-19
    - signaling 30-6, 30-9
    - statistics 30-16
    - Superframe 30-2, 30-4
  - Table Filtering. See UI Table Filtering
  - task utilization statistics 6-18
  - taskstat** command 6-18
  - TCP protocol 22-3
  - tcpc** command 22-27
  - tcps** command 22-25
  - te** command 30-3
  - technical support 32-1
  - telcs** command 30-17
  - telis** command 30-18
  - TELNET command
    - using 22-28
  - telnet** command 22-28
  - telts** command 30-16
  - temod** command 30-4, 30-7
    - configuring a T1 port 30-4
    - configuring an E1 port 30-7
  - temperature sensor 6-17
  - tercs** command 30-20
  - teris** command 30-20
  - terts** command 30-19
  - tes** command 30-10, 30-12, 30-14
    - viewing a T1 port 30-12
    - viewing an E1 port 30-14
  - test** command 33-6
  - testcfg** command 33-13
  - testdisp** command 33-12
  - time 6-8
  - time slot 30-2
  - time zone 6-8
  - traceroute** command 22-29
  - translations
    - automatic 15-25
    - default options 15-11
    - Ethernet 15-12
    - Ethertype 15-13
    - LLC 15-15
    - SNAP 15-14

- transmission states
  - XMAP 18-3
- transmit credit 16-29
- transmit/receive threshold 8-3
- traps
  - configuring 10-2
- troubleshooting 32-1
  - chassis error messages 32-7
  - hardware problems 32-4
  - module connection error messages 32-8
  - serial port error messages 32-6
  - shutdown error messages 32-5
  - software problems 32-2
  - startup error messages 32-5

## U

- UDP 22-3
- UDP relay 23-1
- udpl** command 22-23
- udps** command 22-22
- UI Table Filtering 2-23
  - Filter Command 2-26
    - combining Search Command with 2-28
    - more mode and 2-23
  - Search Command 2-24
    - combining Filter Command with 2-28
    - more mode and 2-23
    - renewing a search 2-25
  - wildcards and 2-30
- Universal Serial Port 25-2
- Universal Time Coordinate (UTC) 6-8
- uplink submodules 1-4, 1-14–1-21
  - OA-512-BRI-S/T 1-19
    - jumper settings** 1-20
  - OA-512-BRI-U 1-17
  - OA-512-FT1/FE1 1-15
    - jumper settings** 1-16
  - OA-512-USP 1-21
- User Interface 2-1, 2-3
- user login 2-17, 5-2
- USP. See Universal Serial Port.
- UTC 6-8

## V

- VAP
  - configuring 18-9
  - databases 18-8
  - relation to port policies 18-9
- vas** command 13-8
  - Frame Relay 26-55
- ve** command 16-52
- verbose 2-8
- vi** command 15-16, 16-47
- via** command 16-45
- viatrl** command 17-20, 19-28
- view** command 3-6
- viewing parameters 25-14
- vigl** command 16-13
- vimcrl** command 20-14, 20-15
- virtual ports 16-14
  - adding 16-42
  - deleting 16-44
  - errors 16-52
  - format 16-30
  - information on 16-45
  - modifying 16-43
  - statistics for 16-47, 16-50
  - VLAN membership 19-29
  - VLAN/group membership 17-21
- virtual router ports 19-19
  - creating 16-19
- vivl** command 17-21, 19-29
- VLAN Advertisement Protocol
  - see VAP
- vlan** command 2-2, 16-16
- VLAN policies
  - deleting 19-25, 20-10
  - modifying 19-26, 20-11
  - viewing 17-20, 19-28, 20-14

VLANs 16-14, 19-1  
  application examples 21-1  
  backbone 21-9  
  Banyan Vines 19-31  
  bridges 14-3  
  creating 19-16  
  default 19-4  
  deleting 19-26  
  deleting policies in 19-25, 20-10  
  frame flooding in 19-15  
  IP routing in, 22-4  
  IPX networks 21-4  
  logical policies 21-2  
  modifying 19-24  
  multicast 20-1  
  network address policies 21-2  
  policies 17-2, 19-3  
  port policy 19-9, 19-18  
  router ports 19-15  
  router traffic in 19-7  
  secondary traffic 19-6  
  viewing 17-19, 19-27  
**vlap** command 18-9  
**vs** command 16-50

## W

**wan** command 25-8  
WAN Links  
  accessing the LINK menu 28-2  
  adding a link record 28-3  
  deleting link records 28-11  
  displaying link status 28-15  
  modifying a link record 28-9  
  viewing link records 28-12  
WAN routing 16-18, 16-33  
**wb** command 3-10  
**who** command 2-19  
**wpmmodify** command 25-8  
**wpstatus** command 25-20  
**wpview** command 25-14  
**write** command 2-20

## X

**xlat** command 22-8  
XMAP  
  adjacency 18-2  
  and remote switches 18-4  
  common transmission time 18-7  
  configuring 18-5  
  discovery transmission time 18-6  
  transmission states 18-3  
  well-known MAC address 18-3  
**xmapcmntime** command 18-7  
**xmapdisctime** command 18-6  
**xmapls** command 18-5  
**xmapst** command 18-5

## Z

ZMODEM 3-1, 3-4, A-1