

OmniSwitch® Omni Switch/Router™ User Manual

Release 4.1



SwitchExpertSM Service Programs: An Alcatel service agreement brings your company the assurance of 7x24 no-excuses technical support. You'll also receive regular software updates to maintain and maximize your Alcatel product's features and functionality and on-site hardware replacement through our global network of highly qualified service delivery partners. Additionally, with 24-hour-a-day access to Alcatel's Service and Support web page, you'll be able to view and update any case (open or closed) that you have reported to Alcatel's technical support, open a new case or access helpful release notes, technical bulletins, and manuals. For more information on Alcatel's Service Programs, see our web page at www.ind.alcatel.com, call us at 1-800-995-2696, or email us at switchexpert@ind.alcatel.com.

This Manual documents Release 4.1 OmniSwitch and Omni Switch/Router hardware and software. The functionality described in this Manual is subject to change without notice.

Copyright© 2000 by Alcatel Internetworking, Inc. All rights reserved. This document may not be reproduced in whole or in part without the express written permission of Alcatel Internetworking, Inc.

Alcatel[®] and the Alcatel logo are registered trademarks of Alcatel. Xylan[®], OmniSwitch[®], PizzaSwitch[®] and OmniStack[®] are registered trademarks of Alcatel Internetworking, Inc. X-Cell[™], Omni Switch/Router[™], OmniAccess[™], PizzaPort[™], X-Vision[™], AutoTracker[™], SwitchManager[™], SwitchStart[™], SwitchExpertSM, WebView[™], PolicyView[™] and the Xylan logo are trademarks of Alcatel Internetworking, Inc. All other brand and product names are trademarks of their respective companies.



26801 West Agoura Road
Calabasas, CA 91301
(818) 880-3500 FAX (818) 880-3505
info@ind.alcatel.com

US Customer Support—(800) 995-2696
International Customer Support—(818) 878-4507
Internet—<http://www.ind.alcatel.com>

Cautions

FCC Compliance: This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in this guide, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user will be required to correct the interference at his own expense.

The user is cautioned that changes and modifications made to the equipment without approval of the manufacturer could void the user's authority to operate this equipment. It is suggested that the user use only shielded and grounded cables to ensure compliance with FCC Rules.

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus out in the radio interference regulations of the Canadian department of communications.

Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la Class A prescrites dans le reglement sur le brouillage radioelectrique edicte par le ministere des communications du Canada.

Lithium Batteries Caution: There is a danger of explosion if the Lithium battery in your chassis is incorrectly replaced. Replace the battery only with the same or equivalent type of battery recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. The manufacturer's instructions are as follows:

Return the module with the Lithium battery to Alcatel. The Lithium battery will be replaced at Alcatel's factory.

Table of Contents

1	Omni Switch/Router Chassis and Power Supplies	1-1
	Omni Switch/Router User Interface (UI) Software	1-2
	Omni Switch/Router Network Management Software (NMS)	1-2
	Omni Switch/Router Distributed Switching Fabric	1-3
	Omni Switch/Router Fabric Capacity	1-4
	Omni Switch/Router Applications and Configurations	1-5
	Omni Switch/Router as the Backbone Connecting Several Networks	1-5
	Omni Switch/Router as the Central Backbone Switch/Router and in the Wiring Closet	1-6
	Omni Switch/Router Chassis and Power Supplies	1-7
	OmniS/R-5	1-7
	OmniS/R-5 Technical Specifications	1-9
	OmniS/R-9	1-10
	OmniS/R-9 Technical Specifications	1-12
	Omni Switch/Router Power Requirements	1-13
	Grounding a Chassis	1-18
	The Omni Switch/Router Hardware Routing Engine (HRE-X)	1-19
	Valid HRE-X Configurations	1-20
	Connecting a DC Power Source to an OmniS/R-PS5-DC375 or an OmniS/R9-DC650	1-21
	Installing DC Power Source Wire Leads	1-21
2	The Omni Switch/Router MPX	2-1
	Omni Switch/Router Management Processor Module (MPX) Features	2-1
	MPX Technical Specifications	2-1
	MPX Serial and Ethernet Management Ports	2-4
	Ethernet Management Port	2-5
	Configuring MPX Serial Ports	2-6
	Flash Memory and Omni Switch/Router Software	2-7
	Flash Memory Guidelines	2-8
	MPX Redundancy	2-9
	Change-Over Procedure	2-9
	MPX Redundancy Commands	2-10

3 Omni Switch/Router Switching Modules	3-1
Handling Fiber and Fiber Optic Connectors	3-3
Gigabit Ethernet Modules	3-5
GSX-FM/FS/FSH-2W	3-5
GSX-FM/FS/FSH-2W Technical Specifications	3-6
GSX-FM/FS-4W	3-8
GSX-FM/FS-4W Technical Specifications	3-9
Auto-Sensing 10/100 Ethernet Modules	3-11
Ethernet RJ-45 Pinouts	3-11
Ethernet RJ-45 Specifications	3-11
ESX-100C-12W	3-11
ESX-100C-12W Technical Specifications	3-12
ESX-100C-32W	3-14
ESX-100C-32W Technical Specifications	3-15
Fast (100 Mbps) Ethernet Modules	3-17
ESX-100FM/FS-12W	3-17
ESX-100FM/FS-12W Technical Specifications	3-18
10 Mbps Ethernet Modules	3-20
ESX-FM-24W	3-20
ESX-FM-24W Technical Specifications	3-21
Token Ring Modules	3-23
Token Ring RJ-45 Pinouts	3-23
Token Ring RJ-45 Specifications	3-23
TSX-C-32W	3-24
TSX-C-32W Technical Specifications	3-24
TSX-CD-16W	3-26
TSX-CD-16W Technical Specifications	3-27
ATM Uplink Modules	3-29
ASX-155FM/FS/FSH	3-30
ASX-155FM/FS/FSH Technical Specifications	3-31
ASX-155RFM/RFS-1W	3-33
ASX-155RFM/RFS-1W Technical Specifications	3-34
ASX-622RFS/RFM-1W	3-36
ASX-622RFM/RFS-1W Technical Specifications	3-37
ASX-DS3	3-39
ASX-DS3 Technical Specifications	3-40
ASX-E3	3-42
ASX-E3 Technical Specifications	3-43

FDDI Modules	3-45
FDDI MiniDIN Pinouts	3-46
FDDI MiniDIN Specifications	3-46
FSX-FM	3-46
FSX-FM Technical Specifications	3-47
FSX-FS	3-49
FSX-FS Technical Specifications	3-50
FSX-FSH	3-52
FSX-FSH Technical Specifications	3-53
WAN Modules	3-55
WAN Pinouts	3-55
WAN BRI Port Specifications (S/T Interface)	3-56
WAN BRI Port Specifications (U Interface)	3-56
WAN T1/E1 Port Specifications	3-57
WAN Serial Port Specifications	3-58
WSX-S-2W	3-60
WSX-S-2W Technical Specifications	3-60
WSX-SC	3-62
WSX-SC Technical Specifications	3-63
WSX-FT1/E1-SC	3-65
WSX-FT1/E1-SC Technical Specifications	3-66
WSX-FE1-SC Cabling/Jumper Settings	3-68
WSX-BRI-SC	3-69
WSX-BRI-SC Technical Specifications	3-70

4 The OmniSwitch Chassis	4-1
OmniSwitch Components	4-1
OmniSwitch Frame and Management Buses	4-1
ATM Cell Switching Matrix	4-2
OmniSwitch Chassis Types	4-2
OmniSwitch Failure-Resistant Features	4-3
Omni-3wx	4-4
Power Supply	4-4
Omni-3wx Technical Specifications	4-5
Omni-5 (Discontinued)	4-6
Power Supplies	4-6
Omni-5 Technical Specifications	4-7
Omni-9 (Discontinued)	4-8
Power Supplies	4-8
Omni-9 Technical Specifications	4-9
Omni-5e	4-10
Power Supplies	4-10
Omni-5e Technical Specifications	4-11
Omni-9e	4-12
Power Supplies	4-12
Omni-9e Technical Specifications	4-13
Omni-5x	4-14
Power Supplies	4-14
Omni-5x Technical Specifications	4-15
Omni-9x	4-16
Power Supplies	4-16
Omni-9x Technical Specifications	4-17
Omni-5wx	4-18
Power Supplies	4-18
Omni-5wx Technical Specifications	4-19
Omni-9wx	4-20
Power Supplies	4-21
Omni-9wx and Omni-9wx-PLUS Technical Specifications	4-21

5 OmniSwitch Power Supplies	5-1
Omni-3wx Power Supplies	5-2
Omni-3wx Power Supply Specifications	5-2
Omni-5 Power Supplies	5-3
Omni-5 PS5 and PS5-DC-48 Specifications	5-3
Omni-5e Power Supplies	5-4
Omni-5e PS5-250 and PS5-DC250 Technical Specifications	5-4
Omni-5x Power Supplies	5-5
Omni-5x PS5-250 and PS5-DC250 Specifications	5-5
Omni-5wx Power Supplies	5-6
Omni-5wx PS5-250 and PS5-DC-250 Technical Specifications	5-6
Omni-9 Power Supply	5-7
Omni-9 PS9-350T Specifications	5-7
Omni-9e Power Supplies	5-8
Omni-9e PS9-500 and PS9-DC500 Specifications	5-8
Omni-9x Power Supplies	5-9
Omni-9wx and Omni-9wx-PLUS Power Supplies	5-10
Omni-9wx PS9-500T Specifications	5-10
Omni-9wx PS9-500P and PS9-DC500 Specifications	5-11
Omni-9wx-PLUS PS9-650P Specifications	5-11
Power Requirements	5-12
CSM-622 Modules	5-12
Omni-5, Omni-9, Omni-9e (350 watt) Chassis	5-13
Omni-5e and Omni-9e (500 watt) Chassis	5-13
FCC Class B Approvals	5-14
Removing and Installing a Power Supply	5-19
Removing a Power Supply	5-19
Installing a Power Supply	5-19
Connecting a DC Power Source	5-20
Installing DC Power Source Wire Leads	5-21
Replacing a Power Supply Fuse (older chassis models)	5-24
Grounding a Chassis	5-25
Power Cords	5-26
Backup Power System (BPS)	5-27
Operation with One Power Supply Installed in the BPS	5-27
Operation with Two Power Supplies Installed in the BPS	5-28
Front Panel	5-29
Rear Panel	5-30
Connecting a BPS to an Omni-3wx	5-31
BPS Technical Specifications	5-32
Backup Power System (BPS) Technical Specifications	5-32
BPS Power Supplies	5-33

6	The Management Processor Module (MPM)	6-1
	Original MPM	6-1
	MPM-II	6-1
	MPM-1G	6-2
	MPM-III	6-2
	MPM-C	6-2
	MPM Types Matrix	6-3
	Serial and Ethernet Management Ports	6-6
	Modem Port Jumpers	6-7
	MPM-III Ethernet Management Port	6-9
	Flash Memory and Switch Software	6-10
	Flash Memory Guidelines	6-12
	MPM Redundancy	6-13
	Change-Over Procedure	6-13
	MPM Redundancy Commands	6-14
	Hardware Routing Engines	6-15
	MPM-II and MPM-1G HRE and HRE-Plus	6-15
	MPM-III HRE-VX	6-16
	FDDI Trunking Ports and Large Routed Frames	6-16
7	OmniSwitch Switching Modules	7-1
	Installing a Switching Module	7-4
	Removing a Switching Module	7-6
	Hot Swapping a Switching Module	7-7
	Diagnostic Tests	7-9
	High-Speed Module (HSM)	7-10
	Content Addressable Memory (CAM)	7-11
	Module LEDs	7-13
	Ethernet (10 Mbps) Modules	7-14
	ESM-C-12	7-15
	ESM-C-12 Technical Specifications	7-15
	ESM-C-8 (Discontinued)	7-17
	ESM-C-8 Technical Specifications	7-17
	ESM-F-8	7-19
	ESM-F-8 Technical Specifications	7-19
	ESM-T-12	7-21
	ESM-T-12 Technical Specifications	7-21
	ESM-U-6	7-23
	ESM-U Technical Specifications	7-24
	Installing Ethernet Universal Adapter Boards	7-26
	Grounding and Termination on the 10BASE-2 Adapter Board	7-27

Fast Ethernet (100 Mbps) Modules	7-28
ESM-100C	7-29
ESM-100C Technical Specifications	7-30
ESM-100C-FD	7-33
ESM-100C-FD Technical Specifications	7-33
ESM-100Fx-FD	7-35
ESM-100Fx-FD Technical Specifications	7-35
ESM-100C-5	7-37
ESM-100C-5 Technical Specifications	7-38
ESM-100CFx-5	7-40
ESM-100CFx-5 Technical Specifications	7-41
ATM Access Modules	7-43
ATM Pinouts	7-44
ATM RJ-45 Specifications	7-44
ATM RJ-48C Specifications	7-44
ASM-155Fx	7-45
ASM-155Fx Technical Specifications	7-46
ASM-155C	7-48
ASM-155C Technical Specifications	7-48
ASM2-155F	7-50
ASM2-155FM/S Technical Specifications	7-51
ASM2-155RF	7-53
ASM2-155RFM/S Technical Specifications	7-54
ASM2-622F (Discontinued)	7-56
ASM2-622FM/S Technical Specifications	7-57
ASM2-622RF	7-59
ASM2-622RFM/S Technical Specifications	7-60
ASM-DS3	7-62
ASM-DS3 Technical Specifications	7-63
ASM-E3	7-65
ASM-E3 Technical Specifications	7-65
ASM-CE	7-67
ASM-CE Technical Specifications	7-67
ASM2-DS3	7-70
ASM2-DS3 Technical Specifications	7-71
ASM2-E3	7-73
ASM2-E3 Technical Specifications	7-74

FDDI and CDDI Modules	7-76
FDDI and CDDI Pinouts	7-77
FDDI MiniDIN Specifications	7-77
CDDI RJ-45 Specifications	7-77
FSM-M	7-78
FSM-M Technical Specifications	7-78
FSM-S	7-80
FSM-S Technical Specifications	7-80
FSM-SH	7-82
FSM-SH Technical Specifications	7-82
FSM-C	7-84
FSM-C Technical Specifications	7-84
FSM-M-C	7-86
FSM-M-C Technical Specifications	7-86
Token Ring Modules	7-88
Token Ring Pinouts	7-89
Token Ring RJ-45 Specifications	7-89
TSM-C-6 (Discontinued)	7-90
TSM-C-6 Technical Specifications	7-90
TSM-F-6	7-92
TSM-F-6 Technical Specifications	7-92
TSM-F-6 Port Configurations	7-94
TSM-CD-6 (Discontinued)	7-96
TSM-CD-6 Technical Specifications	7-97
TSM-CD-16W	7-99
TSM-CD-16W Technical Specifications	7-100
High-Density, 10/100, and Gigabit Ethernet Modules	7-102
Ethernet Pinouts	7-102
Ethernet RJ-45 Specifications	7-102
ESM-100C-12	7-103
ESM-100C-12 Technical Specifications	7-103
ESM-100FM/FS-8	7-105
ESM-100FM/FS-8 Technical Specifications	7-105
ESM-C-16	7-107
ESM-C-16 Technical Specifications	7-107
ESM-C-32W	7-109
ESM-C-32W Technical Specifications	7-109
ESM-FM-16W	7-111
ESM-FM-16W Technical Specifications	7-111
ESM-100C-32W Ethernet Module	7-113
ESM-100C-32W Technical Specifications	7-114
ESM-T-24W	7-116
ESM-T-24W Technical Specifications	7-116
GSM-F-2W Gigabit Ethernet Module	7-118
GSM-F-2W Technical Specifications	7-119

8 The User Interface	8-1
Main Menu Summary	8-2
General User Interface Guidelines	8-3
Monitoring Your Switch	8-3
Entering Command Names	8-3
Quitting a Command	8-4
Scrolling	8-4
The UI Configuration Menu	8-4
Configuring the System Prompt	8-5
Configuring More Mode for the User Interface	8-6
Setting Verbose/Terse Mode for the User Interface	8-9
Configuring the Auto Logout Time	8-11
Viewing Commands	8-12
Changing Passwords	8-12
Command History and Re-Executing Commands	8-13
Abbreviating IP Addresses	8-15
User Interface Display Options	8-17
Setting Echo/NoEcho for User Entry	8-18
Login Accounts	8-19
Multiple User Sessions	8-20
Listing Other Users	8-21
Communicating with Other Users	8-22
Deleting Other Sessions	8-23
Advanced Kill Command Options	8-25
UI Table Filtering (Using Search and Filter Commands)	8-26
The Search Command	8-27
Renewing a Search	8-28
The Filter Command	8-29
Combining Search and Filter Commands	8-31
Using Wildcards with Search and Filter Commands	8-33
Wildcard Command Options	8-33
9 Installing Switch Software	9-1
Using FTP Server	9-2
Using FTP Client	9-3
Using ZMODEM	9-4
Using ZMODEM with the load Command	9-4
Using ZMODEM With the Boot Line Prompt	9-5

10	Configuring Management Processor Modules	10-1
	Changing Serial Port Communication Parameters	10-2
	Changing Port Speed When Communication With The Switch Lost	10-3
	Configuring the Modem Port	10-3
	Modem Port Mode	10-3
	Configuring SLIP	10-4
	Configuring the Ethernet Management Port	10-5
	Ethernet Management Ports and Redundant Management Processor Modules	10-7
	The MPM Command/Menu	10-9
	Displaying MPM Redundancy	10-9
	MPM Menu Commands	10-9
	Using MPM Commands with Software Release 3.2 and Later	10-10
	Listing the Secondary MPM Files	10-11
	Transferring a File to the Secondary MPM	10-11
	Replacing a File on the Secondary MPM	10-12
	Loading a File from the Secondary MPM	10-12
	Removing a File from the Secondary MPM	10-13
	Giving Up Control to the Secondary MPM	10-14
	Setting the Load Suffix	10-14
	Setting Automatic Config Synchronization	10-15
	Enabling Automatic Config Synchronization	10-15
	Disabling Automatic Config Synchronization	10-15
	Synchronizing Configuration Data	10-16
	Synchronizing Image Files	10-16
	Loading a File From the Primary MPM	10-17
	Gaining Control from the Primary MPM	10-18
	Resetting a Secondary MPM	10-19
	Displaying and Setting the Swap State	10-20
	Displaying the Swap State	10-20
	Enabling the Swap Mode	10-20
	Disabling the Swap Mode	10-21
11	Managing Files	11-1
	File Menu	11-1
	Displaying the Current Directory	11-2
	Command and Image File Placement	11-2
	Configuration and Log File Generation	11-2
	Changing Directories	11-2
	Listing Switch Files	11-3

Deleting Switch Files	11-4
Deleting Multiple Files	11-4
Deleting All Image Files	11-5
Copying System Files	11-6
Displaying Text Files	11-6
Editing Text Files	11-7
Clearing the Text Buffer	11-7
Loading an ASCII File into the Text Buffer	11-8
Listing the Contents of the Text Buffer	11-8
Adding Lines of Text to the Text Buffer	11-8
Deleting a Line of Text from the Text Buffer	11-9
Inserting a Line of Text into the Text Buffer	11-9
Editing a Line Name of Text in the Text Buffer	11-9
Creating a File Name for the Text Buffer	11-10
Creating a Text File from the Text Buffer	11-10
Real-World Examples	11-11
Real-World Example 1	11-11
Real-World Example 2	11-12
System Menu	11-13
Checking the Flash File System	11-14
Creating a New File System	11-15
12 Switch Security	12-1
Changing Passwords	12-2
Rebooting the Switch	12-3
Secure Switch Access	12-4
Configuring Secure Switch Access Users Database	12-4
Configuring Secure Access IP Protocols	12-6
Viewing Secure Access Violations Log	12-9
13 Configuring Switch-Wide Parameters	13-1
Summary Menu	13-1
Displaying the MIB-II System Group Variables	13-2
Displaying the Chassis Summary	13-3
Displaying Current Router Interface Status	13-4
System Menu	13-5
Displaying Basic System Information	13-6
Setting the System Date and Time	13-8
Viewing Slot Data	13-14
Viewing System Statistics	13-15
Viewing Task Utilization Statistics	13-16
Viewing MPM Memory Statistics	13-17

Checking the Flash File System	13-18
Creating a New File System	13-19
Configuring a System Description	13-20
Viewing CAM Information	13-21
Configuring CAM Distribution	13-22
OmniSwitch CAM Distribution	13-22
Omni Switch/Router CAM Distribution	13-23
Viewing System Logs	13-24
Configuring the Syslog Parameters	13-24
Configuring the Log Configuration	13-28
Displaying the Command History Log	13-29
Displaying the Connection Log	13-30
Duplicate MAC Address Support	13-31
Multicast Claiming	13-33
Disabling Flood Limits	13-33
14 Switch Logging	14-1
Logging Overview	14-1
Configuring the Syslog Parameters	14-2
Configuring Switch Logging	14-6
Displaying the Command History Entries in the FFS Log	14-10
Displaying the Connection Entries in the FFS Log	14-11
Displaying Screen (Console) Capture Entries in the FFS Log	14-12
Displaying Debug Entries in the FFS Log	14-14
Displaying Secure Access Entries in the FFS Log	14-14
15 Health Statistics	15-1
The Health Statistics Management Menu	15-1
Setting Resource Thresholds	15-2
Setting Bandwidth Thresholds	15-3
Setting Miscellaneous Thresholds	15-4
Setting the Sampling Interval	15-6
View Switch-Level Statistics	15-6
View Module-Level Statistics	15-7
View Port-Level Statistics	15-8
Reset Health Statistics	15-8

16	Network Time Protocol	16-1
	Introduction	16-1
	Stratum	16-2
	Using NTP in a Network	16-2
	NTP and Authentication	16-4
	Network Time Protocol Management Menu	16-5
	NTP Configuration Menu	16-6
	Configuring an NTP Client	16-6
	Configuring an NTP Client/Server	16-8
	Configuring Client/Server Authentication	16-9
	Configuring a New Peer Association	16-12
	Configuring a New Server	16-13
	Configuring a Broadcast Time Service	16-13
	Unconfigure Existing Peer Associations	16-14
	Set the Server's Advertised Precision	16-14
	NTP Information Menu	16-15
	Display List of Peers the Server Knows About	16-15
	Display Peer Summary Information	16-16
	Display Alternate Peer Summary Information	16-17
	Display Detailed Information for One or More Peers	16-18
	Print Version Number	16-20
	Display Local Server Information	16-21
	NTP Statistics Menu	16-23
	Display Local Server Statistics	16-23
	Display Server Statistics Associated with Particular Peer(s)	16-24
	Display Loop Filter Information	16-26
	Display Peer Memory Usage Statistics	16-26
	Display I/O Subsystem Statistics	16-27
	Display Event Timer Subsystem Statistics	16-28
	Reset Various Subsystem Statistics Counters	16-28
	Reset Stat Counters Associated With Particular Peer(s)	16-28
	Display Packet Count Statistics from the Control Module	16-29
	Display the Current Leap Second State	16-30
	Turn the Server's Monitoring Facility On or Off	16-31
	Display Data The Server's Monitor Routines Have Collected	16-31
	NTP Administration Menu	16-33
	Set the Primary Receive Timeout	16-33
	Set the Delay Added to Encryption Time Stamps	16-33
	Specify the Host Whose NTP Server We Talk To	16-34
	Specify a Password to Use for Authenticated Requests	16-34
	Set Key ID to Use for Authenticated Requests	16-34
	Set Key Type to Use for Authenticated Requests (DES MD5)	16-35
	Set a System Flag (Auth, Bclient, Monitor, Stats)	16-35
	Clear a System Flag (Auth, Bclient, Monitor, Stats)	16-35

NTP Access Control Menu	16-36
Change the Request Message Authentication Key ID	16-36
Change the Control Message Authentication Key ID	16-37
Add One or More Key ID's to the Trusted List	16-37
Display the Trusted Key ID List	16-37
Remove One or More Key ID's from the Trusted List	16-38
Display the State of the Authentication Code	16-38
Create Restrict Entry/Add Flags to Entry	16-39
View the Server's Restrict List	16-40
Remove Flags from a Restrict Entry	16-41
Delete a Restrict Entry	16-41
Configure a Trap in the Server	16-41
Display the Traps Set in the Server	16-42
Remove a Trap (Configured or Otherwise) from the Server	16-42
 17 SNMP (Simple Network Management Protocol)	 17-1
Introduction	17-1
Configuring SNMP Parameters and Traps	17-2
Procedure for Defining a New Network Management Station	17-4
Viewing SNMP Statistics	17-7
Trap Tables	17-10
SNMP Standard Traps	17-10
Extended Traps	17-21
 18 DNS Resolver and RMON	 18-1
Introduction	18-1
Configuring the DNS Resolver	18-1
The Names Submenu	18-1
Remote Network Monitoring (RMON)	18-3
Probes and Events	18-3
Ethernet Probes	18-3
History Probes	18-3
Alarm Probes	18-3
Monitoring Probes	18-4
Monitoring Events	18-5
Configuring Router Port MAC Addresses	18-6
Restoring Router Port Mac Addresses	18-6

19	Managing Ethernet Modules	19-1
	Overview of OmniSwitch and Omni Switch/Router Ethernet Modules	19-1
	Early Generation OmniSwitch Ethernet Modules	19-2
	High-Density, 10/100, and Gigabit Ethernet (Mammoth) Modules	19-3
	The Ethernet Management Menus	19-4
	Configuring 10/100 Auto-Sensing Ports (High-Density 10/100 Modules)	19-5
	Connecting High-Density 10/100 Modules to Non-Auto-Negotiating Links	19-6
	Configuring High-Density Ethernet Ports (10 Mbps and Fast Ethernet Modules)	19-7
	High-Density Modules With 10 Mbps Ports	19-7
	Viewing Configurations for High-Density and 10/100 Ethernet Modules	19-8
	OmniChannel	19-9
	Creating an OmniChannel	19-10
	Adding Ports to an OmniChannel	19-11
	Deleting an OmniChannel	19-12
	Deleting Ports from an OmniChannel	19-12
	Viewing OmniChannel Parameters	19-13
	Configuring Older Fast Ethernet Ports	19-14
	Viewing Fast Ethernet Configurations	19-15
	Selecting the Aggressive Ethernet Back-Off Algorithm	19-16
20	Managing 802.1Q Groups	20-1
	IEEE 802.1Q Sections Not Implemented	20-1
	Application Example	20-2
	X802.1Q vs. IEEE 802.1Q	20-3
	Single vs. Multiple Spanning Tree	20-3
	Giga I and II ASIC Modules	20-5
	Assigning an 802.1Q Group to a Port	20-6
	Configuring 802.1Q on 10/100 Ethernet Ports	20-6
	Configuring 802.1Q on Gigabit Ethernet Ports	20-8
	Modifying 802.1Q Groups	20-10
	Viewing 802.1Q/X802.1Q Groups in a Port	20-11
	Viewing 802.1Q Statistics for 10/100 Ports	20-12
	Deleting 802.1Q/X802.1Q Groups from a Port	20-13

21	Managing Token Ring Modules	21-1
	Bigfoot and Early-Generation Token Ring Modules	21-2
	Early-Generation Modules	21-2
	Bigfoot Modules	21-3
	Source Routing	21-4
	Hop Counts	21-4
	Virtual Rings	21-5
	Local Virtual Rings	21-5
	Spanning Tree Leaf Rings	21-6
	Setting Up Virtual Rings	21-6
	Source Route Traffic Across a Backbone	21-7
	Virtual Rings Using Trunks	21-9
	Token Ring Copy Bit Stamping	21-10
	Source Routing to Transparent Bridging (SRTB)	21-11
	Token Ring UI Commands	21-12
	Token Ring Submenu	21-12
	Bridging Submenu	21-13
	Configuring Source Routing/Virtual Rings	21-14
	Source Routing/Virtual Ring Parameters	21-14
	Source Routing/Virtual Ring Configuration Steps	21-15
	Displaying Source Routing Parameters	21-17
	Configuring the Interface Type on Early-Generation Modules	21-20
	Configuring the Interface Type on a TSM-F-6	21-20
	Configuring the Interface Type on a TSM-CD-6	21-22
	Configuring Port Parameters for Early-Generation Token Ring Modules	21-23
	Configuring Auto-Sensing Ports for Bigfoot Modules	21-24
	Manually Configuring Token Ring Ports on Bigfoot Modules	21-26
	Configuring the Locally-Administered Token Ring Base MAC Address for	
	Bigfoot Modules	21-28
	Disabling the Locally-Administered Token Ring Base MAC Address for	
	Bigfoot Modules	21-29
	Displaying the Token Ring Interface Type	21-30
	Displaying Token Ring Base MAC Addresses	21-31
	Displaying Base MAC Addresses for Bigfoot Modules	21-31
	Displaying the Base MAC Address for Early-Generation Modules	21-32
	Displaying Token Ring Port Status	21-33
	Displaying Token Ring Port Error Statistics	21-35
	Displaying the Status Table for Token Ring Modules	21-36

22	Managing FDDI Switching Modules	22-1
	FDDI Topology Overview	22-1
	FDDI Ring of Trees	22-2
	FDDI Wrapped Ring	22-3
	FDDI Station Modes	22-3
	Dual-Homing in Concentrator (NAC) Mode	22-4
	Interface Menu	22-5
	FDDI Commands	22-5
	Viewing the FDDI Configuration Table	22-6
	Viewing the FDDI Configuration Table	22-7
	Configuring Station Information	22-8
	Viewing the Station Status	22-10
	Viewing the MAC Status Table	22-11
	Viewing the MAC Address Table	22-12
	Viewing the MAC Statistics Table	22-13
	Viewing the MAC Counters Table	22-14
	Configuring the Station Timers	22-15
	Viewing the Port Configuration Table	22-16
	Viewing the Port Status Table	22-18
	Viewing the Port Counters Table	22-19
	Configuring the Port Parameters	22-20
	Introduction to FDDI Services	22-21
	Services Menu	22-21
	Group Multiplexing/Trunking	22-22
	FDDI Group Multiplexing	22-22
	FDDI Trunk Ports	22-22
	The FDDI Virtual Bridge Port	22-23
	FDDI Trunking	22-24
	802.10	22-24
	Domain Bridging	22-25
	Creating an FDDI Group Multiplexing Service	22-26
	Modifying an FDDI Group Multiplexing Service	22-28
	Deleting an FDDI Group Multiplexing Service	22-30
	Viewing Information on All FDDI Group Multiplexing Services	22-31

23	Configuring Bridging Parameters	23-1
	Configuration Overview	23-3
	Bridge Management Menu	23-4
	Selecting a Default Group	23-6
	Using the + or - to Change Groups	23-6
	Bridging Commands	23-7
	Displaying Bridge Forwarding Table	23-7
	Configuring a Static Bridge Address	23-9
	Modifying a Static Bridge Address	23-10
	Deleting a Static Bridge Address	23-11
	Displaying Static Bridge Addresses	23-12
	Displaying Bridge Port Statistics	23-13
	Displaying Media Access Control (MAC) Information for a Specific MAC address	23-15
	Displaying Media Access Control (MAC) Information for all MAC addresses	23-16
	Display Statistics of Bridge MAC Addresses	23-16
	Clear Statistics of Bridge MAC Addresses	23-17
	Display Remote Trunking Stations	23-17
	View the Domain Bridge Mapping Table	23-18
	Setting Flood Limits	23-20
	Setting Flood Limits for a Group	23-20
	Displaying Group Flood Limits	23-21
	Configuring Spanning Tree	23-22
	Configuring Spanning Tree Parameters	23-24
	Display Spanning Tree Bridge Parameters	23-27
	Configuring Spanning Tree Port Parameters	23-29
	Displaying Spanning Tree Port Parameters	23-31
	Configuring Source Routing	23-33
	SAP Filtering	23-33
	Enabling SAP Filtering	23-33
	Disabling SAP filtering	23-34
	Configuring SAP Filtering	23-34
	Viewing SAP Filtering	23-35
	Configuring Source Route to Transparent Bridging	23-36
	Enabling SRTB for a Group	23-37
	Disabling SRTB for a Group	23-38
	Viewing the RIF Table	23-39
	Clearing the RIF Table	23-40

24	Configuring Frame Translations	24-1
	Any-to-Any Switching	24-1
	Translating the Frame	24-2
	The MAC Header	24-3
	Canonical versus Non-Canonical	24-3
	Abbreviated Addresses	24-3
	Functional Addresses and Multicasts	24-3
	The RIF Field	24-4
	Source Route Termination by Proxy Not Supported	24-4
	Encapsulation	24-5
	Protocols other than IP and IPX	24-5
	The SNAP Conversion	24-6
	Other Conversions	24-6
	Summary of Non-IPX Encapsulation Transformation Rules	24-6
	IPX Encapsulation Transformation Rules	24-7
	The Network Header	24-8
	Address Mapping	24-8
	Address Mapping in IP: ARP	24-8
	Address Mapping in IPX	24-9
	Frame Size Requirements	24-10
	Insertion of Frame Padding	24-10
	Stripping of Padding for all IEEE 802.3 Frames.	24-10
	No stripping of non-IPX Ethertype Frames	24-10
	IPX Specific Stripping	24-10
	MTU Handling	24-11
	IP Fragmentation	24-11
	ICMP Based MTU Discovery	24-11
	IPX Packet Size Negotiation	24-11
	Other Protocols	24-11
	Banyan Vines	24-12
	Configuring Encapsulation Options	24-13
	Forwarding versus Flooding	24-13
	Port Based Translation Options	24-13
	MAC Address Based Translation Options	24-13
	“Native” versus “Non-Native” on Ethernet	24-14
	“Native” versus “Non-Native” on FDDI and Token Ring	24-14
	No Translation on Trunk or PTOp ports	24-14
	The Proprietary Token Ring IPX Option	24-14
	The User Interface	24-15
	The addvp, modvp and crgp Commands	24-15
	The Default Translation Option	24-15
	Ethernet Factory Default Translations	24-16
	FDDI Factory Default Translations	24-16
	Token Ring Factory Default Translations	24-17

ATM LANE Factory Default Translations	24-17
The Ethertype Option	24-18
The SNAP Option	24-19
The LLC Option	24-21
Interaction with the new interface	24-22
The “vi” Command	24-22
The Switch Menu	24-23
Proprietary IPX Token Ring	24-23
Factory Defaults	24-23
Default Ethernet Translations	24-24
Default FDDI Translations	24-25
Default Token Ring Translations	24-26
Port Translations	24-28
Configuring Additional Ports	24-29
Displaying Ethernet Switch Statistics	24-29
Any to Any MAC Translations	24-33
Default Autoencapsulation	24-34
Translational Bridging	24-35
Learning	24-35
Translations across Trunks	24-35
Dissimilar LAN Switching Capabilities	24-36
Switching Between Similar LANs	24-36
Switching Between Ethernet LANs Across a Trunked Backbone	24-37
Switching Between Similar LANs across a Native Backbone	24-38
25 Managing Groups and Ports	25-1
How Ports Are Assigned to Groups	25-2
Static Port Assignment	25-2
Dynamic Port Assignment (Group Mobility)	25-2
How Dynamic Port Assignment Works	25-3
Mobile Groups	25-5
Configuring Mobile Groups	25-5
Turning Group Mobility On or Off	25-6
Understanding Port Membership in Mobile Groups	25-7
How a Device Is Dropped from the Default Mobile Group (def_group)	25-8
How a Port’s Primary Mobile Group Changes (move_from_def)	25-9
How a Port Ages Out of a Mobile Group (move_to_def)	25-10
Configuring Switch-Wide Group Mobility Variables	25-11
Viewing Ports in a Mobile Group	25-13
Viewing a Port’s Mobile Group Affiliations	25-13
Dynamic LANE Services	25-14
Dynamic LANE Services and Non-Dynamic LANE Services	25-14
Creating Auto-Activated LANE Services	25-15
Deleting an Auto-Activated Service	25-15
Viewing Auto-Activated Services	25-16

Non-Mobile Groups and AutoTracker VLANs	25-17
Routing in a Non-Mobile Group	25-17
Spanning Tree and Non-Mobile Groups	25-18
Group and Port Software Commands	25-19
Creating a New Group	25-20
Step 1. Entering Basic Group Information	25-21
Step 2. Configuring the Virtual Router Port (Optional)	25-22
Step 3. Set Up Group Mobility and User Authentication	25-27
Step 4. Configuring Virtual Ports	25-28
Step 5. Configure Auto-Activated LANE Ports (Mobile Groups Only)	25-33
Step 6. Configuring AutoTracker Policies (Mobile Groups Only)	25-34
Creating a WAN Routing Group	25-35
Creating an ATM CIP Group	25-38
Viewing Current Groups	25-40
Modifying a Group or VLAN	25-42
Viewing Your Changes	25-43
Saving Your Changes	25-43
Canceling Your Changes	25-43
Changing the IP Address	25-43
Changing the IP Subnet Mask	25-43
Enabling IP or IPX Routing	25-44
Deleting a Group	25-45
Adding Virtual Ports	25-46
Modifying a Virtual Port	25-47
Deleting a Virtual Port	25-48
Viewing Information on Ports in a Group	25-49
Viewing Detailed Information on Ports	25-51
Viewing Port Statistics	25-54
Viewing Port Errors	25-56
Port Mirroring	25-58
How Port Mirroring Works	25-58
What Happens to the Mirroring Port	25-58
Using Port Mirroring With External RMON Probes	25-59
Setting Up Port Mirroring	25-61
Disabling Port Mirroring	25-61
Port Monitoring	25-62
Port Monitoring Menu	25-62
RAM Disk System for Data Capture Files	25-63
Configuring RAM Drive Resources (pmcfg)	25-63
Changing the Default System Directory (cd)	25-63

Starting a Port Monitoring Session (pmon)	25-64
If You Chose Dump to Screen	25-65
If You Did Not Choose Dump to Screen	25-65
Ending a Port Monitoring Session	25-66
Viewing Port Monitoring Statistics (pmstat)	25-66
Port Mapping	25-67
Groups/VLANs and Port Mapping	25-67
The Details of Port Mapping	25-68
Who Can Talk to Whom?	25-69
Port Mapping Limitations	25-69
Creating a Port Mapping Set	25-70
Adding Ports to a Port Mapping Set	25-71
Removing Ports from a Port Mapping Set	25-72
Viewing a Port Mapping Set	25-73
Deleting a Port Mapping Set	25-73
Priority VLANs	25-74
Configuring VLAN Priority	25-75
Viewing VLAN Priority	25-75
26 Configuring Group and VLAN Policies	26-1
AutoTracker Policy Types	26-2
Defining and Configuring AutoTracker Policies	26-4
Where These Procedures Start	26-4
Defining a Port Policy	26-5
Defining a MAC Address Policy	26-6
Defining a Protocol Policy	26-7
Defining a Network Address Policy	26-9
Defining Your Own Rules	26-11
Defining a Port Binding Policy	26-13
Defining a DHCP Port Policy	26-17
Defining a DHCP MAC Address Policy	26-18
Viewing Mobile Groups and AutoTracker VLANs	26-19
Viewing Policy Configurations	26-20
Viewing Virtual Ports' Group/VLAN Membership	26-21
View VLAN Membership of MAC Devices	26-22
Application Example: DHCP Policies	26-23
The VLANs	26-23
DHCP Servers and Clients	26-24
DHCP Port and MAC Rules	26-25

27 Interswitch Protocols	27-1
Interswitch Protocol Commands	27-1
XMAP	27-2
XMAP Transmission States	27-3
Discovery Transmission State	27-3
Common Transmission State	27-4
Passive Reception State	27-4
Common Transmission and Remote Switches	27-4
Configuring XMAP	27-5
Enabling or Disabling XMAP	27-5
Viewing a List of Adjacent Switches	27-5
Configuring the Discovery Transmission Time	27-6
Configuring the Common Transmission Time	27-7
VLAN Advertisement Protocol (VAP)	27-8
VAP and Port Policies	27-9
Configuring VAP	27-9
GMAP	27-10
GMAP Updating Rules	27-10
Configuring GMAP	27-11
Enabling and Disabling GMAP	27-11
Configuring the Gap Time	27-11
Configuring the Interpacket Update Time	27-12
Configuring the Hold Time	27-12
Displaying GMAP Statistics by MAC Address	27-13
28 Managing AutoTracker VLANs	28-1
The AutoTracker Menu	28-2
AutoTracker VLANs	28-3
AutoTracker VLAN Policies	28-3
The Default VLAN	28-4
How Devices are Assigned to AutoTracker VLANs	28-5
The defvl Command	28-5
Devices that Generate a Secondary Traffic Type	28-6
Router Traffic in IP and IPX Network Address VLANs	28-7
Port Policy Functionality	28-9
Frame Flooding in AutoTracker VLANs	28-15
Routing Between AutoTracker VLANs	28-15
Creating AutoTracker VLANs	28-16
Step A. Entering Basic VLAN Information	28-16
Step B. Defining and Configuring VLAN Policies	28-18
Step C. Configuring the Virtual Router Port (Optional)	28-19

Modifying an AutoTracker VLAN	28-24
Deleting an AutoTracker VLAN	28-26
Viewing AutoTracker VLANs	28-27
Viewing Policy Configurations	28-28
Viewing Virtual Ports' VLAN Membership	28-29
View VLAN Membership of MAC Devices	28-30
Creating a VLAN for Banyan Vines Traffic	28-31
29 Multicast VLANs	29-1
How Devices are Assigned to Multicast VLANs	29-2
Multicast VLANs and Multicast Claiming	29-2
Frame Flooding in Multicast VLANs	29-3
Creating Multicast VLANs	29-4
Step A. Entering Basic Information	29-5
Step B. Defining the Multicast Address	29-6
Step C. Defining the Recipients of Multicast Traffic	29-7
Defining Recipients By Port	29-7
Defining Recipients By MAC Address	29-8
Modifying Multicast VLANs	29-9
Deleting a Multicast VLAN	29-11
Modifying a Multicast Address Policy	29-12
Viewing Multicast VLANs	29-13
Viewing Multicast VLAN Policies	29-14
Viewing the Virtual Interface of Multicast VLANs	29-15
30 AutoTracker VLAN Application Examples	30-1
Application Example 1	30-2
VLANs Based on Logical Policies	30-2
Application Example 2	30-4
VLANs in IPX Networks	30-4
IPX VLAN Assignment at Bootup	30-5
Application Example 3	30-7
IPX Network Address VLANs and Translated Frames	30-7
Application Example 4	30-8
Routing in IPX Networks	30-8
Application Example 5	30-10
Traversing a Backbone	30-10

31 IP Routing	31-1
Introduction	31-1
IP Routing Overview	31-2
Routing Protocols	31-2
Transport Protocols	31-3
Application-Layer Protocols	31-3
Additional IP Protocols	31-3
Setting Up IP Routing on the Switch	31-4
The Networking Menu	31-6
The IP Submenu	31-7
Viewing the Address Translation (ARP) Table	31-8
Displaying All Entries in the ARP Table	31-8
Adding Entries to the ARP Table	31-9
Deleting Entries from the ARP Table	31-10
Flushing Temporary Entries from the ARP Table	31-10
Finding a Specific IP Address in the ARP Table	31-10
Finding a Specific MAC Address in the ARP Table	31-11
Viewing IP Statistics and Errors	31-12
Viewing the IP Forwarding Table	31-15
Adding an IP Static Route	31-16
Removing an IP Static Route	31-17
Viewing ICMP Statistics and Errors	31-18
Using the PING Command	31-20
Viewing UDP Statistics and Errors	31-21
Viewing the UDP Listener Table	31-22
Viewing RIP Statistics and Errors	31-23
Viewing TCP Statistics	31-24
Viewing the TCP Connection Table	31-26

Using the TELNET Command	31-27
Tracing an IP Route	31-28
Flushing the RIP Routing Tables	31-29
Configuring IP RIP Filters	31-30
Adding a “Global” IP RIP Filter	31-30
Adding an IP RIP Filter For a Specific Group or VLAN	31-31
IP RIP Filter Precedence	31-32
Deleting IP RIP Filters	31-33
Displaying IP RIP Filters	31-34
Displaying a List of All IP RIP Filters	31-34
Displaying a List of “Global” IP RIP Filters	31-35
Displaying a List of Specific IP RIP Filters	31-35
Viewing the IP-to-MAC Address Table	31-36
Displaying All Entries in the IP-to-MAC Table	31-36
Displaying Information for a Specific IP Address	31-37
Flushing Entries from the Table	31-37
Path MTU Discovery	31-38
32 UDP Forwarding	32-1
UDP Relay and RIF Stripping	32-1
UDP Relay Hardware/Software Support	32-2
UDP Relay Configuration Screen	32-3
BOOTP/DHCP Relay	32-4
Overview of DHCP	32-4
DHCP and the OmniSwitch or OmniS/R	32-4
BOOTP/DHCP Relay and Source Routing	32-5
BOOTP/DHCP Relay and Authentication	32-5
External BOOTP Relay	32-6
Internal BOOTP/DHCP Relay	32-7
Example 1	32-7
Example 2	32-8
Enabling BOOTP/DHCP Relay	32-9
Configuring BOOTP/DHCP Relay Parameters	32-10

NetBIOS Relays	32-11
Overview of NetBIOS	32-11
NetBIOS Relay Application	32-12
Configuring NBNS Relay	32-13
Next-Hop Addresses for NBNS	32-14
Forwarding VLANs for NBNS Relay	32-15
Configuring NBDD Relay	32-16
Next-Hop Addresses for NBDD	32-17
Forwarding VLANs for NBDD Relay	32-18
Generic Service UDP Relay	32-19
Generic Services Menu	32-19
Adding a Generic Service	32-19
Modifying a Generic Service	32-21
Deleting a Generic Service	32-22
Viewing UDP Relay Statistics	32-23
33 IPX Routing	33-1
Introduction	33-1
IPX Routing Overview	33-2
IPX Protocols	33-2
Setting Up IPX Routing on the Switch	33-3
The IPX Submenu	33-4
Viewing the IPX Routing Table	33-5
Displaying All Entries in the IPX Routing Table	33-5
Using IPXR with Frame Relay or ISDN Boards	33-6
Displaying a List of Specific IPX Routes	33-7
Viewing IPX Statistics	33-8
Viewing the IPX SAP Bindery	33-10
Using IPXSAP with Frame Relay or ISDN Boards	33-11
Displaying a List of Specific SAP Servers	33-11
Adding an IPX Static Route	33-12
Removing an IPX Static Route	33-13
Turning the IPX Router Complex On and Off	33-14
Flushing the IPX RIP/SAP Tables	33-15
Using the IPXPING Command	33-16

Configuring IPX RIP/SAP Filtering	33-18
Adding a “Global” IPX RIP/SAP Filter	33-19
Adding an IPX RIP/SAP Filter for a Specific Group or VLAN	33-20
Deleting an IPX RIP/SAP Filter	33-22
Displaying IPX RIP/SAP Filters	33-23
Displaying a List of All IPX Filters	33-23
Displaying a List of “Global” IPX Filters	33-24
Displaying a List of Specific IPX Filters	33-24
IPX RIP/SAP Filter Precedence	33-25
Configuring IPX Serialization Packet Filtering	33-26
Enabling IPX Serialization Filtering	33-26
Disabling IPX Serialization Filtering	33-27
Configuring IPX Watchdog Spoofing	33-28
Enabling IPX Watchdog Spoofing	33-28
Disabling IPX Watchdog Spoofing	33-29
Configuring SPX Keepalive Spoofing	33-30
Enabling SPX Keepalive Spoofing	33-30
Disabling SPX Keepalive Spoofing	33-31
Controlling IPX Type 20 Packet Forwarding	33-32
Configuring NetWare to Minimize WAN Connections	33-33
Configuring RIP and SAP Timers	33-35
Adding a RIP and SAP Timer	33-35
Viewing RIP and SAP Timers	33-36
Configuring Extended RIP and SAP Packets	33-37
Enabling or Disabling Extended RIP and SAP Packets	33-37
Viewing the Current Status of Extended Packets	33-37
Configuring an IPX Default Route	33-38
Adding an IPX Default Route	33-38
Viewing the Status of an IPX Default Route	33-38
Disabling an IPX Default Route	33-38

34 HRE-X Filtering	34-1
Overview	34-1
Filtering Precedence	34-2
IP Rule Precedence	34-2
IPX Rule Precedence	34-3
Hardware/Software Requirements	34-3
HRE-X Filtering Configuration Overview	34-4
HRE-X Filtering UI	34-5
Activating Configuration Changes	34-5
Creating Filtering Groups and Rules	34-6
IP Filtering Groups	34-6
Creating IP Filtering Groups	34-7
Modifying IP Filtering Groups	34-8
Adding Rules to IP Filtering Groups	34-8
IPX Filtering Groups	34-10
Creating IPX Filtering Groups	34-11
Modifying an IPX Filtering Group	34-11
Adding a Rule to an IPX Group	34-12
Service Filtering Groups	34-12
Creating a Service Filtering Group	34-13
Modifying a Service Filtering Group	34-14
Configuring Global Parameters	34-15
Activating Filtering Groups	34-16
Deactivating Filtering Groups	34-16
Displaying Filters	34-17
Displaying Active Filters	34-17
Displaying Active IP Filters	34-19
Displaying Active IPX Filters	34-20
Displaying the Disposition for Particular Flows	34-21
Disposition for IP Flows	34-21
Disposition for IPX Flows	34-22
Resetting the Counters	34-23
Displaying All Filters	34-24
Displaying IP Filtering Groups	34-25
Displaying IPX Filtering Groups	34-26
Displaying Service Groups	34-27
Configuring a List of Filtering Rules	34-28
Removing Filtering Groups and Services	34-29

35	Managing ATM Access Modules	35-1
	Early Generation OmniSwitch ATM Access Modules	35-2
	SAHI-Based ATM Access Modules	35-3
	FCSM ATM Access Ports	35-4
	LAN Switch with ATM Uplinks	35-5
	The ATM Menu	35-6
	Modifying an ATM Access Port Configuration	35-7
	Creating a Virtual Channel Connection	35-12
	Modifying a Virtual Channel Connection	35-16
	Deleting a Virtual Channel Connection	35-16
	Creating a Virtual ATM Address	35-17
	Modifying Virtual ATM Addresses	35-18
	Deleting a Virtual ATM Address	35-18
	Viewing ATM Port Configuration Information	35-19
	Information on the Ports for One ATM Access Module	35-22
	Information on One Port	35-23
	Viewing SSCOP, ILMI, and PHY	35-24
	Viewing SSCOP, ILMI, and PHY Information on All Ports	35-24
	Viewing SSCOP, ILMI, and PHY Information on One ATM Access Module	35-26
	Viewing SSCOP, ILMI, and PHY Information on One Port	35-27
	Viewing Virtual Channel Connections	35-28
	Information on the Ports for One ATM Access Module	35-31
	Information on One Port	35-33
	Information on One Virtual Path	35-34
	Information on One Virtual Channel	35-35
	Viewing Virtual ATM Addresses	35-36
	Viewing the ATM Layer Statistics Table	35-38
	Viewing the ATM Layer Rx Error Statistics Table	35-39
	ATM Layer Receive Error Statistics Table For One ATM Access Module	35-41
	ATM Layer Receive Error Statistics Table For One ATM Access Port	35-42
	Viewing the ATM Layer Tx Error Statistics Table	35-43
	ATM Layer Transmit Error Statistics Table For One ATM Access Module	35-44
	ATM Layer Transmit Error Statistics Table For One ATM Access Port	35-44
	Viewing the ATM Connection Statistics Table	35-45
	Information on the Ports for one ATM Access Module	35-46
	Information on One Port	35-46
	Information on One Virtual Channel	35-47

Viewing the ATM Connection Rx Error Statistics Table	35-48
Viewing the ATM Connection Tx Error Statistics Table	35-50
Traffic Shaping (ASM2/ASX Modules)	35-52
Configuring ASM2/ASX Traffic Shaping	35-52
Viewing Traffic Shaping Parameters	35-55
36 Managing Circuit Emulation Modules	36-1
The ASM-CE	36-2
The ASM-CE Ports: An Overview	36-3
The CSM-CE	36-4
Circuit Emulation T1/E1 Ports	36-5
Configuring a Circuit Emulation Module	36-6
Circuit Emulation Services	36-7
Circuit Emulation Clocking Modes	36-8
Synchronous Clocking	36-8
Synchronous Residual Time Stamp (SRTS) Clocking	36-8
Adaptive Clocking	36-9
Application Example - ASM-CE	36-10
The Circuit Emulation Menu	36-11
Creating a Virtual Channel Connection on a T1/E1 Port	36-12
Creating a Soft Permanent Virtual Circuit (SPVC) on T1/E1 Ports	36-17
Creating a Virtual Channel Connection on a Serial Port	36-21
Configuring a Circuit Emulation T1/E1 Port	36-23
Configuring a Circuit Emulation Serial Port	36-25
Modifying a Virtual Channel Connection	36-27
Deleting a Virtual Circuit	36-28
Viewing Circuit Emulation Information	36-29
Viewing Information on All Circuit Emulation Boards in a Switch	36-29
Viewing Information on One Module	36-31
Viewing Information for a T1 or E1 Port	36-32
Viewing Information for a Serial Port	36-33
Viewing Information for a T1/E1 Virtual Circuit	36-34
Viewing Information for a Serial Port Virtual Circuit	36-35
Clearing ATM Circuit Emulation Statistics	36-36

37 LANE Server Configuration	37-1
Introduction	37-1
LAN Emulation Components	37-1
LANE Component Interactions	37-2
LAN-to-ATM Communication	37-3
Overview of LES/BUS and LECS Configuration	37-4
The LANE Service Menu (LSM)	37-4
Configuring LES/BUS and LECS	37-5
Making SubMenu Option Selections	37-6
Specifying a Global ELAN Name	37-7
Creating a LES/BUS Pair	37-8
Modifying a LES/BUS Pair	37-11
Deleting a LES/BUS Pair	37-12
Creating the LECS	37-13
Modifying the LECS	37-15
Deleting the LECS	37-16
Adding ELANs to the LECS	37-17
Deleting an ELAN from the LECS	37-19
Adding Policies to ELANs in the LECS	37-20
Deleting Policies from ELANs in the LECS	37-22
Displaying a List of LES/BUS Pairs	37-23
Displaying LES/BUS Pair Status	37-24
Displaying LES/BUS Pair Statistics	37-26
Displaying LES/BUS Configuration	37-32
Displaying LECs in a LES/BUS Pair	37-33
Displaying MAC Addresses for a LES/BUS Pair	37-34
Displaying Registered Route Descriptor for a LES/BUS Pair	37-35
Displaying Detailed LEC Information	37-36
Displaying LECS Status	37-38
Displaying LECS Statistics	37-39
Displaying LECS Configuration	37-41
Displaying ELANs in the LECS	37-42
Displaying ELAN Policies in the LECS	37-43

38	Configuring ATM Services	38-1
	Introduction	38-1
	ATM Services	38-1
	PVC/SVC Support	38-2
	LANE Client (LEC) Services	38-3
	Token Ring vs. Ethernet Networks	38-4
	Source-Routed Traffic	38-5
	LANE Version 2.0	38-5
	LAN Emulated Client Start-Up and Back-Off Timers	38-6
	ATM Trunking	38-8
	Groups over ATM	38-8
	VLANs over ATM	38-9
	Spanning Tree and Trunking	38-9
	Translations Across Trunks	38-9
	ATM Trunking and Older ATM Access Modules	38-10
	Classical IP Routing	38-11
	LLC Header Encapsulation	38-11
	IP to ATM Address Resolution	38-11
	IP Over ATM Signaling	38-11
	Typical CIP over ATM Configuration	38-12
	Point-to-Point Bridging	38-13
	VLAN Clusters	38-14
	Method 1	38-15
	Method 2	38-15
	1483 Scaling Services	38-16
	Configuring ATM Services	38-18
	Services Menu	38-18
	Creating a Service	38-19
	Creating a LANE Client Service	38-20
	Setting LANE Client Parameters	38-22
	Creating a Trunking Service	38-24
	Creating a Classical IP Service	38-26
	Creating a PTOp Bridging Service	38-28
	Creating a VLAN Cluster Service	38-30
	Creating a 1483 Scaling Service	38-32
	Editing and Displaying 1483 Mapping Parameters	38-35

Modifying a Service	38-39
Modifying a LANE Client Service	38-39
Modifying a Trunking Service	38-40
Modifying a Classical IP Service	38-41
Adding Static ARP Entries for CIP	38-43
Modifying a PTOp Bridging Service	38-44
Modifying a VLAN Cluster Service	38-45
Modifying VLAN Cluster Parameters	38-46
Modifying a 1483 Scaling Service	38-47
Deleting a Service	38-49
Deleting Static ATM ARP Entries for CIP	38-50
Viewing ATM Access Port Services	38-51
Viewing General Service Statistics on a Port	38-52
Viewing Service Statistics for a LANE Client	38-53
Viewing the LANE LE_ARP Table	38-56
Viewing ATM Service Statistics for Classical IP	38-58
Viewing the CIP ARP Table	38-60
Viewing Service Statistics for VLAN Clusters	38-61
Viewing 1483 Scaling Service Parameters	38-62
39 Multi-Protocol Over ATM (MPOA)	39-1
Introduction	39-1
Network Functionality and MPOA	39-1
MPOA Requirements	39-4
The MPOA Client (MPC)	39-4
The MPOA Network	39-7
The MPOA Management Menu	39-10
Configuring an MPOA Client Service	39-11
Viewing Client Service Status	39-14
Viewing Client Service Statistics	39-15
Viewing Entries in the Ingress Cache Table	39-19
Viewing Entries in the Egress Cache Table	39-20
Viewing MPOA Servers	39-21

40 SONET Error Collection	40-1
SONET Overview	40-2
SONET Error Collection Intervals	40-2
SONET Protocol Layers	40-2
Path Layer	40-2
Line Layer	40-3
Section Layer	40-3
Medium Layer	40-3
SONET Connections	40-3
Enabling and Disabling SONET Error Collection	40-4
Displaying SONET Error Collection Status	40-4
Enabling SONET Error Collection	40-4
Disabling SONET Error Collection	40-4
The SONET Error Collection Menu	40-5
Enabling SONET Error Collection on ATM Ports	40-6
Enabling SONET Error Collection on a Single Port	40-6
Enabling SONET Error Collection on all ATM Ports on a Switching Module	40-7
Enabling SONET Error Collection on all ATM Ports in a Switch	40-7
Viewing the SONET Medium Table	40-8
Viewing the SONET Medium Table for a Single ATM Port	40-8
Viewing the SONET Medium Table for All ATM Ports on a Switching Module	40-9
Viewing the SONET Medium Table for all ATM Ports	40-9
Viewing SONET Error Statistics Tables	40-10
Viewing SONET Error Statistics for the Current Interval	40-10
Section Table Statistics	40-12
Line Table Statistics	40-13
Path Table Statistics	40-14
Viewing SONET Error Statistics for a Single Interval	40-16
Viewing SONET Error Statistics for All Intervals	40-18
Viewing Individual SONET Error Statistics Tables	40-20
Clearing SONET Error Statistics Tables for the Current Interval	40-21
Clearing Error Statistics for All Tables	40-21
Clearing Error Statistics for a Single Table	40-22
Viewing the Summary of SONET Error Statistics	40-23

41	Cell Switching Modules (CSMs)	41-1
	Virtual Circuits	41-1
	Dynamic Input Buffering With Output Control	41-1
	Quality of Service (QoS)	41-2
	Partial Packet Discard (PPD) and Early Packet Discard (EPD)	41-2
	Dual Leaky Buckets	41-2
	Available Bit Rate Traffic	41-2
	MPM-C and MPM-III Signaling Performance	41-2
	ATM Switching Applications and Configurations	41-3
	Frame-Based LAN Switch With ATM Uplinks	41-3
	Hybrid LAN/ATM Switch	41-4
	Pure ATM Campus Switch	41-5
	Distributed Cell Switching Fabric	41-6
	Buffer Management	41-7
	Cell Buffers	41-7
	Module Mix for OmniSwitch Configurations	41-9
	Pure LAN Switch	41-9
	Hybrid LAN/ATM Switch	41-10
	Pure ATM Switch	41-11
	Cell Switching Modules	41-12
	CSM Pinouts	41-13
	CSM RJ-45 Specifications	41-13
	CSM RJ-48C Specifications	41-13
	Frame-to-Cell Switching Module (FCSM)	41-14
	FCSM I (FCSM-155)	41-16
	FCSM I Redundancy	41-16
	FCSM II	41-19
	FCSM II Technical Specifications	41-19
	The Cell Switching Management Processor Module (MPM-C)	41-20
	MPM-C Technical Specifications	41-21
	MPM-C Serial and Ethernet Management Ports	41-24
	Ethernet Management Port	41-24
	Configuring MPM-C Serial Ports	41-25
	Flash Memory and OmniSwitch Software	41-25
	MPM-C Redundancy	41-25
	Redundancy for MPM Functions	41-25
	Redundancy for FCSM Functions	41-25
	ATM Services on the MPM-C	41-26
	CSM-155F	41-27
	CSM-155 Technical Specifications	41-28
	Jumper Settings	41-30

CSM-622	41-31
CSM-622 Technical Specifications	41-32
Jumper Settings	41-34
CSM-155C-8	41-35
CSM-155C-8 Technical Specifications	41-36
Jumper Settings	41-38
CSM-A25-12	41-39
CSM-A25-12 Technical Specifications	41-39
CSM-A25-24W	41-41
CSM-A25-24 Technical Specifications	41-41
CSM-U	41-43
CSM-U Technical Specifications	41-43
CSM-AB-155F	41-45
CSM-AB-155F Technical Specifications	41-46
Jumper Settings	41-47
CSM-AB-155C	41-48
CSM-AB-155C Technical Specifications	41-49
Jumper Settings	41-50
CSM-AB-T1/E1-4W	41-51
CSM-AB-T1/E1 Technical Specifications	41-52
CSM-AB-DS3/E3-2W	41-53
CSM-AB-DS3/E3 Technical Specifications	41-54
CSM-AB-CE-T1/E1-4W	41-55
CSM-AB-CE Technical Specifications	41-56
CSM-AB-CE-E1-4W Impedance Jumper Numbers	41-56
CSM-AB-CE-E1-4W Grounding Jumper Numbers	41-57
CSM-AB-CM	41-58
CSM-AB-CM Technical Specifications	41-59
CSM-AB-CM Port Type Jumper Settings	41-60
CSM-AB-CM Port Shield Jumper Settings	41-60
CSM-AB-IMA-T1/E1-8W	41-61
CSM-AB-IMA-T1-8W/CSM-AB-IMA-E1-8W Technical Specifications	41-62
CSM-AB-IMA-E1-8W Jumpers	41-63
CSM-AB-IMA-E1-8W Impedance Jumper Numbers	41-63
CSM-AB-IMA-E1-8W Grounding Jumper Numbers	41-64

42 Managing Cell Switching Modules (CSMs)	42-1
Virtual Circuits	42-3
VPis and VCIs	42-4
Point-to-Point Virtual Circuits	42-5
Point-to-Multipoint Virtual Circuits	42-5
PVCs, SVCs, and Soft PVCs	42-6
ATM Traffic Types	42-7
Quality of Service (QoS)	42-9
Flow Control	42-11
Resource Management	42-11
Explicit Forward Congestion Indication (EFCI)	42-11
Traffic Management	42-12
Cell Loss Priority (CLP) and Policing	42-13
Traffic Contract Descriptors	42-14
Understanding Traffic Descriptor Names	42-15
Traffic Contract Enforcement	42-16
Traffic Policing and Leaky Bucket Algorithms	42-17
Dual Leaky Buckets	42-19
Leaky Buckets and Class of Service	42-20
Class of Service Profiles	42-21
Constant Bit Rate (CBR)	42-21
Variable Bit Rate, Real Time (rt_VBR)	42-22
Variable Bit Rate, Non-Real Time (nrt_VBR)	42-22
Available Bit Rate (ABR)	42-23
Unspecified Bit Rate (UBR)	42-23
The ATM Menu	42-24
FCSM Modules in ATM Menu Commands	42-26
Modifying a Port Configuration	42-27
Creating a Permanent Virtual Circuit	42-31
Setting Up Basic VC Parameters	42-31
Configuring Point-to-Multipoint Virtual Circuits	42-35
Configuring Traffic Parameters	42-37
Configuring Statistics and Priority Parameters	42-42
Configuring VP Switching	42-43
Modifying a Virtual Circuit	42-45
Deleting a Virtual Circuit	42-45

CSM Port Auto Configuration	42-46
Modifying CSM Port Auto Configuration	42-46
Modifying One or More CSM Boards	42-48
Modifying One or More Ports	42-49
Viewing CSM Port Auto Configuration	42-50
Information on the Ports for One or More CSM Boards	42-52
Information on One or More Single Ports	42-53
Information on One Virtual Instance	42-54
Viewing Port Configurations	42-55
Information on the Ports for One CSM Board	42-61
Information of One Port	42-63
Viewing SSCOP, ILMI, and PHY	42-64
Viewing SSCOP, ILMI, and PHY Information on All Ports	42-64
Viewing SSCOP, ILMI, and PHY Information on One CSM Board	42-67
Viewing SSCOP, ILMI, and PHY Information on One Port	42-69
Viewing Virtual Connections	42-71
Information on All Virtual Circuits in a Switch	42-71
Information on the Ports for One CSM Virtual Circuit	42-77
Information on One Port	42-79
Information on One Virtual Path	42-81
Information on One Virtual Channel	42-83
43 Advanced CSM Management	43-1
Soft PVCs	43-3
Creating a Soft PVC	43-3
Configuring Traffic Parameters	43-6
Configuring Statistics and Priority Parameters	43-11
Configuring Point-to-Multipoint Soft PVCs	43-12
Modifying a Point-to-Multipoint Soft PVC	43-14
Configuring Soft PVC Retry Parameters	43-15
Configuring Broadband Bearer Capability Parameters	43-15
Viewing Soft PVCs	43-17
Virtual UNI/NNI Using Virtual Path (VP) Tunneling	43-20
Extending PNNI Over Public Networks	43-20
Virtual Path Mux	43-21
Signaling Hop Reduction	43-21
Creating a VP Tunnel	43-22
Displaying VP Tunnel Information	43-24
Viewing SSCOP, ILMI, and PHY	43-26
Modifying a VP Tunnel	43-29
Deleting a VP Tunnel	43-29
Configuring a LECS ATM Address	43-30
Mapping Service Registry Table Addresses to the Well-Known Address	43-31
Modifying Existing Addresses in the Service Registry Table	43-32

Viewing ATM Layer Statistics	43-33
Viewing ATM Layer Receive Error Statistics	43-35
Information on the Ports for One CSM Board	43-38
Information on One Port	43-39
Viewing ATM Connection Statistics Table	43-40
Information on All ATM Boards in a Switch	43-40
Information on the Ports for one CSM Board	43-42
Information on One Port	43-43
Information on One Virtual Path	43-44
Information on One Virtual Channel	43-44
Viewing Connection Receive Error Statistics	43-45
Intelligent Multicast Replication	43-47
Multicast Replication Trees	43-49
Enabling Intelligent Multicast Replication	43-50
Disabling Intelligent Multicast Replication	43-50
Displaying Intelligent Multicast Replication Performance Gain	43-51
Displaying Intelligent Multicast Replication Trees	43-52
44 Inverse Multiplexing Over ATM (IMA)	44-1
IMA Hardware	44-2
IMA Software	44-2
IMA Configuration Overview	44-3
IMA Process Overview	44-4
Adding and Deleting Links in an IMA Group	44-4
Cell Switching Module (CSM) Ports and IMA Groups (CSM-AB-IMA-T1/E1-8W Submodule)	44-5
Sample IMA Network	44-6
IMA Application Example	44-8
How to Set Up this Network	44-9
IMA Theory of Operation	44-11
IMA Link State Machine (LSM)	44-11
IMA Synchronization Process	44-12
The IMA Submenu	44-13
User Interface Command Syntax	44-14
Creating IMA Groups	44-15
Adding and Modifying IMA Group Membership	44-18
Adding IMA Group Membership	44-18
Modifying IMA Group Membership	44-20
Modifying IMA Groups	44-21
Modifying IMA Groups with T1 Ports (Short-Haul Line)	44-21
Modifying IMA Groups with T1 Ports (Long-Haul Line)	44-24
Modifying IMA Groups with E1 Ports	44-25

Configuring IMA Link Parameters	44-28
Conducting an IMA Test	44-29
Starting an IMA Test	44-29
Ending an IMA Test	44-31
Restarting an IMA Group	44-32
Deleting IMA Groups	44-32
Upgrading Flash Memory on CSM-AB-IMA-T1/E1-8W Submodules	44-33
Displaying the Summary Status of IMA Groups	44-35
Displaying the Summary Status of All IMA Groups	44-35
Displaying the Summary Status of a Single IMA Group	44-38
Displaying the Detailed Status of a Single IMA Group with Link Status	44-41
Displaying the Summary Status of IMA Links	44-44
Displaying the Summary Status of All IMA Links	44-44
Displaying the Detailed Status of a Single IMA Link	44-46
Displaying the Statistics for an IMA Group	44-48
Displaying Summary Statistics for an IMA Group	44-48
Displaying Detailed Statistics for an IMA Group	44-50
Displaying 24-Hour Performance Statistics on a Local Group	44-54
Displaying Current Performance Statistics on a Local Group	44-55
Displaying Performance Statistics Intervals on a Local Group	44-56
Displaying Detailed Statistics for IMA Links	44-57
Displaying 24-Hour Performance Statistics on a Local Link	44-60
Displaying Current Performance Statistics on a Local Link	44-63
Displaying Performance Statistics Intervals on a Local Link	44-64
Clearing IMA Group Statistics	44-67
Clearing IMA Link Statistics	44-67
Troubleshooting IMA Networks	44-68

45	Configuring and Monitoring PNNI	45-1
	PNNI Configuration	45-3
	PNNI Port Type Configuration	45-3
	Running PNNI Software	45-3
	Loading the PNNI Module	45-4
	Default ATM Address	45-4
	Static Routes/IISP	45-4
	Elements of a PNNI Network	45-5
	Multiple Peer Group Networks	45-6
	Peer Group Leader (PGL) Election Algorithm	45-8
	Complex Representation	45-9
	PNNI Identifiers	45-11
	Level Identifier	45-11
	Node ID	45-11
	Port ID	45-12
	Peer Group ID	45-12
	Summary Addresses	45-13
	PNNI Packet Types	45-14
	Hello packets	45-14
	Database Summary packets	45-14
	PNNI Topology State Element (PTSE) Request packets	45-14
	PNNI Topology State Packets (PTSPs)	45-14
	PNNI Topology State Element (PTSE) Acknowledgment packets	45-14
	Metrics and Attributes	45-15
	Summarization and Reachability	45-17
	PNNI Network Initialization	45-18
	Step 1. Discover Attached ATM End Stations	45-18
	Step 2. Discover Neighbor Nodes	45-19
	Step 3. Send Topology Information for Updating Other Nodes	45-20
	Step 4. Compute the Topology of the Peer Group	45-20
	Establishing a Connection	45-21
	Step 1. Receive a Call Request	45-21
	Step 2. Locate Called Parties	45-22
	Step 3. Path Selection	45-23
	Step 4. Send Setup Message	45-24
	Step 5. Process Setup Message	45-25
	Step 6. Send Call Proceeding Message	45-26
	Step 7. Send Connect Message	45-26
	Step 8. Data Flow	45-26
	The PNNI Menu and Submenus	45-27
	Summary Form of PNNI Commands	45-30
	Displaying PNNI Command Help (Multi-Peer Group PNNI Only)	45-30

Configuring General PNNI Parameters	45-31
Configuring PNNI Operation Limits	45-34
Selecting Metrics Used in Path Computations	45-36
Configuring Multi-Peer Group Operation	45-37
Configuring Node-Specific Parameters	45-39
Configuring Single-Peer Group Nodes	45-39
Configuring PTSE and Hello Timers	45-41
Configuring Multiple-Peer Group Nodes	45-43
Configuring Peer Group Leader Nodes	45-44
Configuring Port Parameters	45-46
Viewing General PNNI Information	45-49
Viewing Node-Specific Information	45-52
Viewing Timer Information	45-56
Viewing PNNI Neighbor Information	45-58
Summary Form of pnbrs	45-59
Viewing Port Information	45-60
Summary Form of ppinfo	45-61
Viewing Link Information	45-62
Summary Form of plink	45-64
Viewing the PTSE Database	45-65
Standard Output	45-65
Verbose Mode Output	45-66
Summary Mode Output	45-68
Viewing End-Point Adjacencies	45-69
Configuring PNNI Scope Mapping Parameters	45-70
Viewing the PNNI Map Table	45-73
Summary Form of pmap	45-74
Network Diagram of pmap Summary Display	45-75
Viewing the PNNI Nodal Map Table	45-76
Summary Form of pnmap	45-78
Viewing Current PNNI Calls	45-79

Viewing Current DTLs	45-80
Summary Form of pdtl	45-80
Viewing Basic Port Statistics	45-81
Viewing Port Error Statistics	45-82
Viewing Port PTSE Statistics	45-83
Halting PNNI Operations	45-84
Restarting PNNI	45-85
Resetting PNNI Statistics Counters	45-86
Viewing PNNI Configuration Information	45-87
Removing PNNI Configuration Information	45-87
Verifying Routes	45-88
Operating PNNI with Redundant MPMs	45-89
Configuring Node Information on Redundant MPMs	45-89
Verifying PNNI Node Information on Redundant MPMs	45-90
FCSM I PNNI Frame Size Guidelines	45-92
46 Managing IISP and PNNI Routes	46-1
Setting Up Static Routes	46-1
The PNNI/IISP Route Management Menu	46-2
Configuring a PNNI/IISP Static Route Property	46-3
Configuring QoS and Metrics for Inbound and Outbound Routes	46-5
Configuring the Associated Transit Network	46-6
Deleting a PNNI/IISP Static Route Property	46-8
Adding a PNNI/IISP Static Route Address	46-9
Deleting a PNNI/IISP Static Route Address	46-11
Viewing PNNI/IISP Static Route Properties	46-13
Viewing PNNI/IISP Static Route Prefixes	46-14
Viewing Learned PNNI/IISP Routes to Reachable Addresses	46-15
Summary Output for proutea	46-16
Viewing PNNI/IISP Learned Routes to Other Nodes	46-17
Summary Output for prouten	46-18

47	Clocking ATM Networks	47-1
	Introduction	47-1
	ATM Data Traffic	47-1
	Selecting Clocking Sources	47-2
	Configuring Transmit Clocking (Port-Level Clocking)	47-2
	Modules that Require 8 kHz Timing	47-2
	Modules that Require 19.44 MHz Timing	47-3
	Timing Considerations for DS3/E3 and PLCP	47-3
	Timing Modes	47-3
	Bus-Level Clocking	47-4
	Bus Lines	47-4
	Clocking Summary	47-5
	Viewing/Configuring Clocking	47-7
	Viewing the Clocking Configuration	47-8
	Viewing Configured Ports	47-8
	Viewing Clocking on All Ports	47-9
	Configuring Clocking	47-10
	Modifying the Clocking Configuration (CSM Ports)	47-10
	Examples	47-11
	Modifying the Clock Switching Time (CSM Ports)	47-11
	Modifying the Transmit Clocking Source	47-12
	Modifying the Transmit Clocking Source (T1/E1 Ports)	47-13
	Clock Backup	47-14
	Backup Design	47-14
48	Managing WAN Switching Modules	48-1
	Introduction	48-1
	Supported Physical Interfaces	48-2
	Universal Serial Port	48-2
	ISDN Basic Rate Interface Port	48-2
	Fractional T1 Port	48-2
	Fractional E1 Port	48-2
	Supported Protocols	48-3
	Application Examples	48-3
	Frame Relay WSM/WSX Using Serial Ports	48-3
	Back-to-Back WSM/WSX Using T1 Ports	48-4
	Combined Frame Relay with ISDN Backup	48-5
	OmniSwitch WAN Modules	48-6
	WAN Pinouts	48-6
	WAN BRI Port Specifications (S/T Interface)	48-7
	WAN BRI Port Specifications (U Interface)	48-7
	WAN T1/E1 Port Specifications	48-8
	WAN Serial Port Specifications	48-9

WSM-S/SC	48-11
WSM Technical Specifications	48-11
WSM-FT1/FE1	48-13
WSM-FT1/E1 Technical Specifications	48-13
Cabling/Jumper Settings	48-15
WSM-BRI	48-16
WSM-BRI Technical Specifications	48-16
Cable Interfaces for Universal Serial Ports	48-19
DTE/DCE Type and Transmit/Receive Pins	48-19
Data Compression	48-20
Loopback Detection	48-20
The WAN Port Software Menu	48-22
Setting Configuration Parameters	48-22
Modifying a Port	48-22
Serial Port Example	48-23
ISDN-BRI Port Example	48-25
Fractional T1 Port Example	48-25
Viewing Configuration Parameters for the WSM	48-26
Viewing Parameters for all WSMs in the Chassis	48-26
Viewing Parameters for all Ports in a Single WSM	48-27
Viewing Port Parameters	48-28
Deleting Ports	48-31
Obtaining Status and Statistical Information	48-32
Obtaining Information on All Boards in a Switch	48-32
Obtaining Information on the Ports for a Single WSM Board	48-34
Viewing Information on a Single Port	48-36
Configuring 31 Timeslots on a WAN E1 Port	48-39
49 Managing Frame Relay	49-1
Back-to-Back Frame Relay Configurations	49-2
Universal Serial Port Cable Interfaces	49-3
“Physical” and “Logical” Devices	49-3
Compression	49-4
Virtual Circuits and DLCIs	49-5
WSM Self-Configuration and Virtual Circuits	49-6
Congestion Control	49-7
Regulation Parameters	49-7
Discard Eligibility (DE) Flag	49-8
Interaction Among Congestion Parameters	49-8
Notification By BECN	49-9
Notification By FECN	49-10
Frame Formats Supported	49-11
Bridging Services	49-12

Frame Relay IP Routing	49-13
The Frame Relay Subnet and “Split Horizon”	49-14
Frame Relay IPX Routing	49-16
Trunking	49-17
The Frame Relay Software Menu	49-18
Setting Configuration Parameters	49-19
Modifying a Port	49-19
Modifying a Virtual Circuit	49-25
Adding a Virtual Circuit	49-28
Viewing Configuration Parameters for the WSM	49-29
Viewing Parameters for all WSMs in the Chassis	49-29
Viewing Port Parameters	49-30
Viewing Virtual Circuit Parameters	49-31
Deleting Ports and Virtual Circuits	49-32
Deleting a Virtual Circuit	49-32
Deleting a Port and Its Virtual Circuits	49-33
Obtaining Status and Statistical Information	49-34
Information on All Boards in a Switch	49-34
Information on the Ports for One WSM Board	49-36
Information on One Port	49-37
Information on One Virtual Circuit	49-43
Resetting Statistics Counters	49-46
Resetting Statistics for a WSM Board	49-46
Resetting Statistics for a WSM Port	49-46
Resetting Statistics for a Virtual Circuit (DLCI)	49-46
Managing Frame Relay Services	49-47
Configuring a Bridging Service	49-49
Configuring a WAN Routing Service	49-51
Step 1. Set Up a Frame Relay Routing Group	49-51
Step 2. Set Up a Frame Relay Routing Service	49-52
Configuring a Trunking Service	49-54
Viewing Frame Relay Services	49-56
Modifying a Frame Relay Service	49-57
Deleting a Frame Relay Service	49-58

50	Point-to-Point Protocol	50-1
	PPP Connection Phases	50-1
	Data Compression	50-2
	Multi-Link PPP	50-2
	Multilink Modes of Operation	50-3
	Overview of PPP Configuration Procedures	50-3
	The PPP Submenu	50-5
	PPP Configuration Overview	50-5
	Setting Global PPP Parameters	50-6
	Adding a PPP Entity	50-8
	Modifying a PPP Entity	50-13
	Viewing PPP Entity Configurations	50-14
	Displaying the Configuration of All PPP Entities	50-14
	Displaying the Configuration of a Specific PPP Entity	50-15
	Displaying PPP Entity Status	50-17
	Displaying the Status of All PPP Entities	50-17
	Displaying the Status of a Specific PPP Entity	50-18
	Deleting a PPP Entity	50-20
51	WAN Links	51-1
	Introduction	51-1
	Configuring WAN Interfaces	51-1
	The Link Submenu	51-2
	Adding a WAN Link	51-3
	Adding WSM Port Links	51-3
	Adding ISDN Call Links	51-4
	Modifying a WAN Link	51-9
	Modifying ISDN Links	51-9
	Modifying WSM Links	51-10
	Deleting WAN Links	51-11
	Viewing WAN Links	51-12
	Displaying All Existing WAN Links	51-12
	Displaying Information for a Specific WAN Link	51-13
	Displaying Link Status	51-15
	Displaying Status for All WAN Links	51-15
	Displaying Status for a Specific WAN Link	51-16

52	Managing ISDN Ports	52-1
	Overview of ISDN	52-1
	Basic Rate Interface (BRI) Versus Primary Rate Interface (PRI)	52-1
	“U”, “S/T” , and “R” Interfaces	52-2
	The “B,” “D,” and “H” Channels	52-2
	The ISDN Submenu	52-3
	Switch Configuration	52-3
	Modifying an ISDN Configuration Entry	52-4
	Deleting an ISDN Configuration Entry	52-5
	Viewing an ISDN Configuration Entry	52-6
	Displaying ISDN Configuration Entry Status	52-7
	Displaying Status of All ISDN Ports	52-7
	Displaying Status of a Specific ISDN Slot	52-8
	Displaying Status of a Specific ISDN Port	52-9
53	Managing T1 and E1 Ports	53-1
	T1 and E1 Overview	53-2
	The T1/E1 Menu	53-3
	Configuring a T1 Port	53-4
	Configuring an E1 Port	53-8
	Viewing T1/E1 Configuration and Alarm Information	53-11
	Viewing Information for all T1/E1 Ports in the Switch	53-11
	Viewing Information for T1/E1 Ports on One Module	53-12
	Viewing Information For a T1 Port	53-13
	Viewing Information For an E1 Port	53-15
	Viewing T1/E1 Local Statistics	53-17
	Viewing Total Local Statistics	53-17
	Viewing Current Local Statistics	53-18
	Viewing Local Historical Statistics	53-19
	Viewing T1 Remote Statistics	53-20
	Viewing Total Remote Statistics	53-20
	Viewing Current Remote Statistics	53-21
	Viewing Remote Historical Statistics	53-21
	Clearing the Framer Statistics for a T1/E1 Port	53-22

54	Managing DS3/E3 Modules	54-1
	DS3/E3 Overview	54-1
	DS3 Framing	54-1
	E3 Framing	54-1
	DS3/E3 Port Management Menu	54-2
	Configuring a DS3 Port	54-2
	Configuring an E3 Port	54-4
	Viewing DS3/E3 Configuration and Alarm Information	54-7
	Viewing Information for all DS3/E3 Ports in the Switch	54-7
	Viewing Information for DS3/E3 Ports on a Board	54-8
	Viewing Information for a DS3 Port	54-9
	Viewing Information for an E3 Port	54-10
	Viewing DS3/E3 Local Statistics	54-13
	Viewing DS3/E3 Local Total Statistics	54-13
	Displayed Statistics	54-14
	Viewing DS3/E3 Local Current Statistics	54-15
	Viewing DS3/E3 Local Interval (Historical) Statistics	54-16
	Viewing ATM Physical Layer Statistics for DS3 (CbitParity PLCP Sublayer)	54-17
	Status Definitions for DS3	54-18
	Statistics Definitions for DS3	54-19
	Viewing ATM Physical Layer Statistics for DS3 (CbitParity ADM Sublayer)	54-20
	Viewing ATM Physical Layer Statistics for DS3 (M23 Type PLCP Sublayer)	54-21
	Viewing ATM Physical Layer Statistics for DS3 (M23 Type ADM Sublayer)	54-22
	Viewing ATM Physical Layer Statistics for E3 (G.751 PLCP Sublayer)	54-23
	Status Definitions for E3 G.751 PLCP	54-24
	Statistics Definitions for E3, PLCP G.751	54-24
	Viewing ATM Physical Layer Statistics for E3 (G.751 ADM Sublayer)	54-25
	Statistics Definitions for E3, ADM G.751	54-25

Viewing ATM Physical Layer Statistics for E3 (G.832 ADM Sublayer)	54-26
Status Definitions for G.832 ADM	54-26
Statistics definitions for E3, ADM G.832	54-27
Viewing ATM Physical Layer Interval Statistics for DS3 (CbitParity PLCP Sublayer)	54-28
Viewing ATM Physical Layer Interval Statistics for DS3 (CbitParity ADM Sublayer)	54-29
Viewing ATM Physical Layer Interval Statistics for DS3 (M23 Type PLCP Sublayer)	54-30
Viewing ATM Physical Layer Interval Statistics for DS3 (M23 Type ADM Sublayer)	54-31
Viewing ATM Physical Layer Interval Statistics for E3 (G.832 PLCP Sublayer)	54-32
Viewing ATM Physical Layer Interval Statistics for E3 (G.751 ADM Sublayer)	54-33
Clearing Interval Statistics	54-33
55 Backup Services	55-1
Introduction	55-1
Backup Services Commands	55-2
Accessing the Backup Services Menu	55-2
Adding a Backup Service	55-3
Adding a backup for a Physical Port	55-3
Backing Up a Frame Relay PVC	55-6
Modifying a Backup Service	55-8
Modifying a backup for a Physical Port	55-8
Modifying a Frame Relay PVC Backup Service	55-9
Viewing Backup Service(s) Configurations	55-10
Viewing the Configurations of All Backup Services	55-10
Viewing the Configuration of a Single Backup Service (bsview Command)	55-10
Deleting a Backup Service	55-10

56	Managing Channelized DS3 Modules	56-1
	Introduction	56-1
	Digital Signal Level X (DSX)	56-2
	Supported Physical Interfaces	56-3
	BNC	56-3
	Balanced T1	56-3
	Supported Protocols	56-3
	Application Examples	56-4
	Internet Services Provider Point-of-Presence	56-4
	Local Exchange Carrier's Central Office	56-5
	Channelized DS3 Module	56-6
	Channelized DS3 Module Technical Specifications	56-6
	Channelized DS3 Module Configuration Overview	56-8
	The Channelized DS3 Module Management Menu	56-10
	Physical Configuration Commands	56-11
	Logical Configuration Commands	56-11
	Configuring a DS3 Port	56-13
	Configuring a DS3 Port using C-Bit Parity	56-16
	Maintenance Data Link (MDL) Field Descriptions	56-17
	Viewing Cumulative Statistics and Errors of a Local DS3 Port	56-19
	Viewing Current 15-Minute Statistics and Errors of a Local DS3 Port	56-21
	Viewing 15-Minute Interval (Historical) Statistics and Errors of a Local DS3 Port	56-22
	Clearing Interval Statistics and Errors of a Local DS3 Port	56-24
	Viewing Configuration and Statistical Parameters for a DS3 Port	56-24
	Viewing Received MDL Messages	56-26
	Configuring a DS1 Channel	56-27
	Setting DS1 Collection Statistics for a DS3 Port	56-31
	Viewing Cumulative Statistics and Errors of a Local DS1 Channel	56-31
	Viewing Current 15-Minute Statistics of a Local DS1 Channel	56-33
	Viewing 15-Minute Interval Statistics and Errors of a Local DS1 Channel	56-34
	Clearing Interval Statistics of a Local DS1 Channel	56-36
	Viewing Configuration and Statistical Parameters for a DS1 Channel	56-37
	Adding a Logical Port Configuration	56-38
	Adding a Logical Port Configuration to a Clear Channel DS3 Port	56-40
	Modifying a Logical Port Configuration	56-40
	Deleting a Logical Port	56-42
	Viewing Logical Port Configuration and Statistics	56-44
	Clear Statistics for a Logical Port	56-46
	Modify the Protocol Configuration of a Logical Port using PPP	56-47
	Modify the Protocol Configuration of a Logical Port using Frame Relay	56-50
	Display Protocol Configuration and Statistics of a Logical Port using PPP	56-54

Display Protocol Configuration and Statistics of a Logical Port using Frame Relay	56-58
Clear Protocol Statistics of a Logical Port	56-63
Add Frame Relay DLCI on a Logical Port	56-64
Delete Frame Relay DLCI on a Logical Port	56-65
Adding a Router Interface	56-66
Modifying a Router Interface Configuration	56-67
Deleting a Router Interface	56-67
Viewing Router Interfaces	56-68
Clearing Statistics for a Router Interface	56-68
Creating a Bridging or Trunking Service	56-69
Deleting Services	56-71
Viewing Service Configurations	56-71
Modifying Service Configurations	56-73
Deleting the Module Configuration	56-74
57 Troubleshooting	57-1
Detecting Problems	57-1
Reporting Problems	57-2
Report Hardware Details	57-2
Report Software Details	57-3
Understanding Problems	57-4
Software Installation Problems	57-4
Operational Problems	57-5
Deadlocked VLAN	57-5
Probable Cause	57-6
Solution	57-6
Problems with IP Applications	57-6
Probable Cause	57-6
Solution	57-6
Protocol Problems	57-7
Probable Cause	57-7
Solution	57-7
Hardware Problems	57-8
LEDs Do Not Light on All Modules	57-8
Probable Cause	57-8
Solution	57-8
Amber Color in LEDs	57-8
Probable Cause	57-8
Solution	57-8
Non-Blinking OK2 LED	57-8
Probable Cause	57-8
Solution	57-8

TEMP LED is Amber	57-9
Solution	57-9
STA LED Is Off	57-9
Probable Cause	57-9
Solution	57-9
Cannot Use SLIP Line on an MPM	57-9
Probable Cause	57-9
Solution	57-9
Error Messages	57-10
Understanding Error Messages	57-10
Correcting Errors	57-10
Module Startup/Shutdown Error Messages	57-10
Serial Port Configuration Errors	57-11
Module Connection Errors	57-11
Chassis Error Messages	57-12
Chassis Error Messages Table	57-12
58 Running Hardware Diagnostics	58-1
Running Diagnostics	58-3
Login to Run Diagnostics	58-4
Resetting a Switching Module	58-5
Disabling a Switching Module	58-5
Temperature Masking	58-6
Running Hardware Diagnostics	58-7
Sample Command Lines	58-11
Halting Diagnostic Tests in Progress	58-11
Port Tests	58-11
OmniSwitch Port Test Wrap Cable/Plug Requirements	58-12
Omni Switch/Router Port Test Wrap Cable/Plug Requirements	58-20
Sample Test Session: Ethernet Module	58-23
Displaying Available Diagnostic Tests	58-26
Configuring the Diagnostic Test Environment	58-27
Configuring Tests for Ethernet Modules	58-28
Configuring Tests for Token Ring Modules	58-29
Running Cell Fabric Tests on OmniSwitch CSMs	58-30
Running Frame Fabric Tests on Omni Switch/Routers	58-32
Running Diagnostics on an Entire Chassis	58-34
Diagnostic Test Cable Schematics	58-36

A	The Boot Line Prompt	A-1
	Entering the Boot Prompt	A-2
	Boot Prompt Basics	A-3
	Resuming Switch Boot (@)	A-3
	Displaying Current Configuration (p)	A-4
	Loading the Last Configured Boot File (l)	A-4
	Listing Available Files in the Flash Memory (L)	A-5
	Deleting All Files in the Flash Memory (P)	A-5
	Deleting Specific Files in the Flash Memory (R)	A-5
	Saving Configuration Changes (S)	A-6
	Viewing Version Number (V)	A-6
	Configuring a Switch with an MPX/MPM-C/MPM-III	A-7
	Configuring a Switch with an MPM/MPM-II/MPM-1G	A-10
B	Custom Cables	B-1
	V.35 DTE Cable (For WSM-to-DCE Device Connection)	B-2
	V.35 DCE Cable (For WSM-to-DTE Device Connection)	B-3
	RS232 DTE Cable (For WSM-to-DCE Device Connection)	B-4
	RS232 DCE Cable (For WSM-to-DTE Device Connection)	B-5
	RS530 DTE Cable (For WSM-to-DCE Device Connection)	B-6
	RS530 DCE Cable (For WSM-to-DTE Device Connection)	B-7
	X.21 DTE Cable (For WSM-to-DCE Device Connection)	B-8
	X.21 DCE Cable (For WSM-to-DTE Device Connection)	B-9
	RS449 DTE Cable (For WSM-to-DCE Device Connection)	B-10
	RS-449 DCE Cable Assembly (For WSM-to-DTE Device 75W Connection)	B-11
	RJ-45 to DB15F Cable Assembly (For T1/E1 Port 120W Connections)	B-12
	RJ-45 to BNC Cable Assembly (For E1 75W Port Connections)	B-13
	Index	I-1

