

Part No. 030451-10, Rev. C
May 2000

OmniStack® User Manual

Release 4.1



www.alcatel.com

SwitchExpertSM Service Programs: An Alcatel service agreement brings your company the assurance of 7x24 no-excuses technical support. You'll also receive regular software updates to maintain and maximize your Alcatel product's features and functionality and on-site hardware replacement through our global network of highly qualified service delivery partners. Additionally, with 24-hour-a-day access to Alcatel's Service and Support web page, you'll be able to view and update any case (open or closed) that you have reported to Alcatel's technical support, open a new case or access helpful release notes, technical bulletins, and manuals. For more information on Alcatel's Service Programs, see our web page at www.ind.alcatel.com, call us at 1-800-995-2696, or email us at switchexpert@ind.alcatel.com.

**This Manual documents Release 4.1 OmniStack hardware and software.
The functionality described in this Manual is subject to change without notice.**

Copyright© 2000 by Alcatel Internetworking, Inc. All rights reserved. This document may not be reproduced in whole or in part without the express written permission of Alcatel Internetworking, Inc.

Alcatel® and the Alcatel logo are registered trademarks of Alcatel. Xylan®, OmniSwitch®, PizzaSwitch® and OmniStack® are registered trademarks of Alcatel Internetworking, Inc. X-Cell™, Omni Switch/Router™, OmniAccess™, PizzaPort™, X-Vision™, AutoTracker™, SwitchManager™, SwitchStart™, SwitchExpertSM, WebView™, PolicyView™ and the Xylan logo are trademarks of Alcatel Internetworking, Inc. All other brand and product names are trademarks of their respective companies.



26801 West Agoura Road
Calabasas, CA 91301
(818) 880-3500 FAX (818) 880-3505
info@ind.alcatel.com

US Customer Support—(800) 995-2696
International Customer Support—(818) 878-4507
Internet—<http://www.ind.alcatel.com>

Cautions

FCC Compliance: This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in this guide, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user will be required to correct the interference at his own expense.

The user is cautioned that changes and modifications made to the equipment without approval of the manufacturer could void the user's authority to operate this equipment. It is suggested that the user use only shielded and grounded cables to ensure compliance with FCC Rules.

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus out in the radio interference regulations of the Canadian department of communications.

Le present appareil numerique n'emet pas de bruits radioelectriques depassant les limites applicables aux appareils numeriques de la Class A prescrites dans le reglement sur le brouillage radioelectrique edicte par le ministere des communications du Canada.

Lithium Batteries Caution: There is a danger of explosion if the Lithium battery in your chassis is incorrectly replaced. Replace the battery only with the same or equivalent type of battery recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. The manufacturer's instructions are as follows:

Return the module with the Lithium battery to Alcatel. The Lithium battery will be replaced at Alcatel's factory.

Table of Contents

1 OmniStack Switches	1-1
Introduction	1-1
HRE Availability	1-1
OmniStack Workgroup Switches	1-1
Handling Fiber and Fiber Optic Connectors	1-3
Applications and Configurations	1-5
Configuration Example #1	1-5
Configuration Example #2	1-6
Configuration Example #3	1-7
Configuration Example #4	1-8
Configuration Example #5	1-9
OmniStack Slot Designations	1-10
OmniStack 1024C	1-11
Front Panel	1-11
Configuring the Ethernet Ports	1-12
The Console Management Port	1-12
Rear Panel	1-13
Technical Specifications	1-14
OmniStack 1024C Technical Specifications	1-14
OmniStack 1024F	1-15
Configuring the Ethernet Ports	1-16
The Console Management Port	1-16
Rear Panel	1-17
Technical Specifications	1-18
OmniStack 1024F Technical Specifications	1-18
OmniStack 1024CF	1-20
Front Panel	1-20
Configuring the Ethernet Ports	1-21
The Console Management Port	1-21
Rear Panel	1-22
Technical Specifications	1-23
OmniStack 1024CF Technical Specifications	1-23
OmniStack 1032C	1-25
Front Panel	1-25
Configuring the Ethernet Ports	1-26
The Console Management Port	1-26
Rear Panel	1-27
Technical Specifications	1-28
OmniStack 1032C Technical Specifications	1-28

OmniStack 1032F	1-29
Front Panel	1-29
Configuring the Ethernet Ports	1-30
The Console Management Port	1-30
Rear Panel	1-31
Technical Specifications	1-32
OmniStack 1032F Technical Specifications	1-32
OmniStack 1032CF	1-33
Front Panel	1-33
Configuring the Ethernet Ports	1-34
The Console Management Port	1-34
Rear Panel	1-35
Technical Specifications	1-36
OmniStack 1032CF Technical Specifications	1-36
OmniStack 2032	1-37
Front Panel	1-37
Configuring the Ethernet Ports	1-38
The Console Management Port	1-38
Rear Panel	1-39
Technical Specifications	1-40
OmniStack 2032 Technical Specifications	1-40
OmniStack 3032	1-41
Front Panel	1-41
Configuring the Ethernet Ports	1-42
The Console Management Port	1-42
Rear Panel	1-43
Technical Specifications	1-44
OmniStack 3032 Technical Specifications	1-44
OmniStack 3032E	1-45
Front Panel	1-45
Configuring the Ethernet Ports	1-45
Rear Panel	1-46
Technical Specifications	1-47
OmniStack 3032E Technical Specifications	1-47
OmniStack 4016	1-48
Front Panel	1-48
Configuring the Ethernet Ports	1-49
The Console Management Port	1-49
Rear Panel	1-50
Technical Specifications	1-51
OmniStack 4016 Technical Specifications	1-51

OmniStack 4024C	1-52
Front Panel	1-52
Configuring the Ethernet Ports	1-53
The Console Management Port	1-53
Rear Panel	1-54
Technical Specifications	1-55
OmniStack 4024C Technical Specifications	1-55
OmniStack 4024F	1-56
Front Panel	1-56
Configuring the Ethernet Ports	1-57
The Console Management Port	1-57
Rear Panel	1-58
Technical Specifications	1-59
OmniStack 4024F Technical Specifications	1-59
OmniStack 4024CF	1-61
Front Panel	1-61
Configuring the Ethernet Ports	1-62
The Console Management Port	1-62
Rear Panel	1-63
Technical Specifications	1-64
OmniStack 4024CF Technical Specifications	1-64
OmniStack 4024G	1-66
Front Panel	1-66
Configuring the Ethernet Ports	1-68
The Console Management Port	1-68
Rear Panel	1-69
Technical Specifications	1-70
OmniStack 4024G Technical Specifications	1-70
OmniStack 5024	1-72
Front Panel	1-72
Configuring the Ethernet Ports	1-73
The Console Management Port	1-73
Rear Panel	1-74
Technical Specifications	1-75
OmniStack 5024 Technical Specifications	1-75
OmniStack Management LEDs	1-76
OmniStack Ethernet Port LEDs	1-77
OmniStack 1024 and 4024 Management LEDs	1-78
OmniStack 1024 and 4024 Ethernet Port LEDs	1-79
OmniStack Hardware Routing Engine (HRE-OSTK)	1-80

Backup Power System	1-81
Operation with One Power Supply Installed in the BPS	1-81
Operation with Two Power Supplies Installed in the BPS	1-81
Front Panel	1-83
Rear Panel	1-83
Technical Specifications	1-84
Backup Power System (BPS) Technical Specifications	1-84
BPS Power Supplies	1-85
Removing or Installing a BPS Power Supply	1-85
Installing a Power Supply	1-85
Removing a BPS Power Supply	1-86
Connecting a DC Power Source to the BPS-DC-PS-250	1-87
Installing DC Power Source Wire Leads	1-87
Power Cords	1-90
OmniStack Pinouts	1-91
Management Console Port	1-91
10BaseT/100BaseT Ports	1-91
Backup Power System (BPS) connector	1-91
2 OmniStack Uplink Submodules	2-1
Introduction	2-1
Available Uplink Submodules	2-1
Installing an OmniStack Uplink Submodule	2-2
Handling Fiber and Fiber Optic Connectors	2-3
OSESM-100C-4: Ethernet 10/100BaseTx Submodule	2-5
Front Panel	2-5
Configuring the Ethernet Ports	2-5
Technical Specifications	2-6
OSESM-100C-4 Technical Specifications	2-6
OSESM-100FM/FS-2: Ethernet 100BaseFx Submodules	2-7
Front Panel	2-7
Configuring the Ethernet Ports	2-7
Technical Specifications	2-8
OSESM-100FM-2 Technical Specifications	2-8
OSESM-100FS-2 Technical Specifications	2-8
OSASM2-155FM/FS/FSH-1: ATM 155 Mbps Submodules	2-9
Front Panel	2-9
Technical Specifications	2-10
OSASM2-155FM-1 Technical Specifications	2-10
OSASM2-155FS-1 Technical Specifications	2-10
OSASM2-155FSH-1 Technical Specifications	2-11

OSASM2-155RFM/RFS-1: ATM 155 Mbps Submodules	2-12
Front Panel	2-12
Technical Specifications	2-13
OSASM2-155RFM-1 Technical Specifications	2-13
OSASM2-155RFS-1 Technical Specifications	2-14
OSASM2-622RFM/RFS-1: ATM 622 Mbps Submodules	2-15
Front Panel	2-15
Technical Specifications	2-16
OSASM2-622RFM-1 Technical Specifications	2-16
OSASM2-622RFS-1 Technical Specifications	2-17
OSASM2-DS3/E3-1: ATM 44.736 Mbps and 34.368 Mbps Submodules	2-18
Front Panel	2-18
Technical Specifications	2-19
OSASM2-DS3-1 Technical Specifications	2-19
OSASM2-E3-1 Technical Specifications	2-19
OSGSM-FM/FS-2 Gigabit Ethernet Submodules	2-20
Front Panel	2-20
Technical Specifications	2-21
OSGSM-FM-2 Technical Specifications	2-21
OSGSM-FS-2 Technical Specifications	2-21
3 The User Interface	3-1
Main Menu Summary	3-2
General User Interface Guidelines	3-3
Monitoring Your Switch	3-3
Entering Command Names	3-3
Quitting a Command	3-3
Scrolling	3-3
The UI Configuration Menu	3-4
Configuring the System Prompt	3-4
Configuring More Mode for the User Interface	3-5
Enabling and Disabling Verbose Mode for the User Interface	3-8
Configuring the Auto Logout Time	3-9
Viewing Commands	3-10
Changing Passwords	3-10
Command History and Re-Executing Commands	3-11
Abbreviating IP Addresses	3-13
User Interface Display Options	3-15
Setting Echo/NoEcho for User Entry	3-16
Login Accounts	3-17

Multiple User Sessions	3-18
Listing Other Users	3-19
Communicating with Other Users	3-20
Deleting Other Sessions	3-21
Advanced Kill Command Options	3-22
UI Table Filtering (Using Search and Filter Commands)	3-23
The Search Command	3-24
Renewing a Search	3-25
The Filter Command	3-26
Combining Search and Filter Commands	3-28
Using Wildcards with Search and Filter Commands	3-30
Wildcard Command Options	3-30
4 Installing Switch Software	4-1
Using FTP Server	4-2
Using FTP Client	4-3
Using ZMODEM	4-4
Using ZMODEM with the load Command	4-4
Using ZMODEM With the Boot Line Prompt	4-5
5 Managing Files	5-1
File Menu	5-1
Displaying the Current Directory	5-2
Listing Switch Files	5-2
Required Command and Image Files	5-2
Configuration and Log File Generation	5-2
File Name Directory	5-3
Removing Switch Files	5-4
Removing Multiple Files	5-4
Removing All Image Files	5-5
Copying System Files	5-6
Viewing Text Files	5-6

Editing Text Files	5-7
Adding Lines of Text to the Text Buffer	5-8
Clearing the Text Buffer	5-8
Deleting a Line of Text from the Text Buffer	5-8
Editing a Line Name of Text in the Text Buffer	5-8
Inserting a Line of Text into the Text Buffer	5-9
Listing the Contents of the Text Buffer	5-9
Naming the Text Buffer	5-9
Reading an ASCII File into the Text Buffer	5-10
Writing a Text File from the Text Buffer	5-10
Real-World Examples	5-11
Real-World Example 1	5-11
Real-World Example 2	5-12
System Menu	5-13
Checking the Flash File System	5-14
Creating a New File System	5-15
6 Switch Security	6-1
Changing Passwords	6-2
Rebooting the Switch	6-3
Secure Switch Access	6-4
Configuring Secure Switch Access Users Database	6-4
Configuring Secure Access IP Protocols	6-6
Viewing Secure Access Violations Log	6-9
7 Configuring Switch-Wide Parameters	7-1
Summary Menu	7-1
Displaying the MIB-II System Group Variables	7-2
Displaying the Chassis Summary	7-3
Displaying Current Router Interface Status	7-4
System Menu	7-5
Displaying Basic System Information	7-6
Setting the System Date and Time	7-8
Configuring the Serial Port Parameters	7-14
Viewing Slot Data	7-16
Viewing System Statistics	7-17
Viewing Task Utilization Statistics	7-18
Viewing MPM Memory Statistics	7-19
Checking the Flash File System	7-20

Creating a New File System	7-21
Configuring a System Description	7-22
Viewing CAM Information	7-23
Duplicate MAC Address Support	7-24
Multicast Claiming	7-25
Disabling Flood Limits	7-25
8 Switch Logging	8-1
Logging Overview	8-1
Configuring the Syslog Parameters	8-2
Configuring Switch Logging	8-6
Displaying the Command History Entries in the FFS Log	8-10
Displaying the Connection Entries in the FFS Log	8-11
Displaying Screen (Console) Capture Entries in the FFS Log	8-12
Displaying Debug Entries in the FFS Log	8-14
Displaying Secure Access Entries in the FFS Log	8-14
9 Health Statistics	9-1
The Health Statistics Management Menu	9-1
Setting Resource Thresholds	9-2
Setting Bandwidth Thresholds	9-3
Setting Miscellaneous Thresholds	9-4
Setting the Sampling Interval	9-6
View Switch-Level Statistics	9-6
View Module-Level Statistics	9-8
View Port-Level Statistics	9-8
Reset Health Statistics	9-9
10 Network Time Protocol	10-1
Introduction	10-1
Stratum 1	0-2
Using NTP in a Network	10-2
NTP and Authentication	10-4
Network Time Protocol Management Menu	10-5

NTP Configuration Menu	10-6
Configuring an NTP Client	10-6
Field Descriptions	10-7
Configuring an NTP Client/Server	10-8
Field Descriptions	10-9
Configuring Client/Server Authentication	10-9
Field Descriptions	10-11
Configuring a New Peer Association	10-12
Configuring a New Server	10-13
Configuring a Broadcast Time Service	10-13
Unconfigure Existing Peer Associations	10-14
Set the Server's Advertised Precision	10-14
NTP Information Menu	10-15
Display List of Peers the Server Knows About	10-15
Display Peer Summary Information	10-16
Field Descriptions	10-17
Display Alternate Peer Summary Information	10-17
Display Detailed Information for One or More Peers	10-18
Field Descriptions	10-18
Print Version Number	10-20
Display Local Server Information	10-21
Field Descriptions	10-21
NTP Statistics Menu	10-23
Display Local Server Statistics	10-23
Field Descriptions	10-24
Display Server Statistics Associated with Particular Peer(s)	10-24
Field Descriptions	10-25
Display Loop Filter Information	10-26
Field Descriptions	10-26
Display Peer Memory Usage Statistics	10-26
Field Descriptions	10-26
Display I/O Subsystem Statistics	10-27
Field Descriptions	10-27
Display Event Timer Subsystem Statistics	10-28
Field Descriptions	10-28
Reset Various Subsystem Statistics Counters	10-28
Reset Stat Counters Associated With Particular Peer(s)	10-28
Display Packet Count Statistics from the Control Module	10-29
Field Descriptions	10-29
Display the Current Leap Second State	10-30
Field Descriptions	10-30
Turn the Server's Monitoring Facility On or Off	10-31
Display Data The Server's Monitor Routines Have Collected	10-31
Field Descriptions	10-32

NTP Administration Menu	10-33
Set the Primary Receive Timeout	10-33
Set the Delay Added to Encryption Time Stamps	10-33
Specify the Host Whose NTP Server We Talk To	10-34
Specify a Password to Use for Authenticated Requests	10-34
Set Key ID to Use for Authenticated Requests	10-34
Set Key Type to Use for Authenticated Requests (DES MD5)	10-35
Set a System Flag (Auth, Bclient, Monitor, Stats)	10-35
Clear a System Flag (Auth, Bclient, Monitor, Stats)	10-35
NTP Access Control Menu	10-36
Change the Request Message Authentication Key ID	10-36
Change the Control Message Authentication Key ID	10-37
Add One or More Key ID's to the Trusted List	10-37
Display the Trusted Key ID List	10-37
Remove One or More Key ID's from the Trusted List	10-38
Display the State of the Authentication Code	10-38
Field Descriptions	10-38
Create Restrict Entry/Add Flags to Entry	10-39
View the Server's Restrict List	10-40
Field Descriptions	10-40
Remove Flags from a Restrict Entry	10-41
Delete a Restrict Entry	10-41
Configure a Trap in the Server	10-41
Display the Traps Set in the Server	10-42
Field Descriptions	10-42
Remove a Trap (Configured or Otherwise) from the Server	10-42
11 SNMP (Simple Network Management Protocol)	11-1
Introduction	11-1
Configuring SNMP Parameters and Traps	11-2
Procedure for Defining a New Network Management Station	11-4
Viewing SNMP Statistics	11-7
Trap Tables	11-10
SNMP Standard Traps	11-10
Extended Traps	11-21

12 DNS Resolver and RMON	12-1
Introduction	12-1
Configuring the DNS Resolver	12-1
The Names Submenu	12-1
Remote Network Monitoring (RMON)	12-3
Probes and Events	12-3
Ethernet Probes	12-3
History Probes	12-3
Alarm Probes	12-3
Monitoring Probes	12-4
Monitoring Events	12-5
13 Managing Ethernet Modules	13-1
The Ethernet Management Menus	13-2
Configuring 10/100 Auto-Sensing Ethernet Ports	13-3
Configuring High-Density Ethernet Ports	13-5
Viewing Configurations for Ethernet Ports	13-6
OmniChannel	13-7
Creating an OmniChannel	13-8
Adding Ports to an OmniChannel	13-9
Deleting an OmniChannel	13-10
Deleting Ports from an OmniChannel	13-11
Viewing OmniChannel Parameters	13-12
14 Managing 802.1Q Groups	14-1
IEEE 802.1Q Sections Not Implemented	14-1
Application Example	14-2
X802.1Q vs. IEEE 802.1Q	14-3
Single vs. Multiple Spanning Tree	14-3
Giga I and II ASIC Modules	14-5
Assigning an 802.1Q Group to a Port	14-6
Configuring 802.1Q on 10/100 Ethernet Ports	14-6
Configuring 802.1Q on Gigabit Ethernet Ports	14-8
Modifying 802.1Q Groups	14-10
Viewing 802.1Q/X802.1Q Groups in a Port	14-11
Deleting 802.1Q/X802.1Q Groups from a Port	14-12

15	Configuring Bridging Parameters	15-1
	Configuration Overview	15-3
	Bridge Management Menu	15-4
	Selecting a Default Group	15-6
	Using the + or - to Change Groups	15-6
	Bridging Commands	15-7
	Displaying Bridge Forwarding Table	15-7
	Field Descriptions	15-8
	Configuring a Static Bridge Address	15-9
	Field Descriptions	15-10
	Modifying a Static Bridge Address	15-10
	Deleting a Static Bridge Address	15-11
	Displaying Static Bridge Addresses	15-12
	Displaying Bridge Port Statistics	15-13
	Displaying Media Access Control (MAC) Information	
	for a Specific MAC address	15-15
	Displaying Media Access Control (MAC) Information	
	for all MAC addresses	15-16
	Display Statistics of Bridge MAC Addresses	15-16
	Clear Statistics of Bridge MAC Addresses	15-17
	Display Remote Trunking Stations	15-17
	View the Domain Bridge Mapping Table	15-18
	Setting Flood Limits	15-20
	Setting Flood Limits for a Group	15-20
	Displaying Group Flood Limits	15-21
	Configuring Spanning Tree	15-22
	Configuring Spanning Tree Parameters	15-24
	Display Spanning Tree Bridge Parameters	15-27
	Configuring Spanning Tree Port Parameters	15-29
	Displaying Spanning Tree Port Parameters	15-31
	Configuring Source Routing	15-33
	Configuring Source Routing/Virtual Rings	15-33
	Source Routing/Virtual Ring Parameters	15-34
	Source Routing/Virtual Ring Configuration Steps	15-34
	Displaying Source Routing Parameters	15-36
	SAP Filtering	15-38
	Enabling SAP Filtering	15-38
	Disabling SAP filtering	15-39
	Configuring SAP Filtering	15-39
	Viewing SAP Filtering	15-40

Configuring Source Route to Transparent Bridging	15-41
Enabling SRTB for a Group	15-42
Disabling SRTB for a Group	15-43
Viewing the RIF Table	15-44
Field Descriptions	15-44
Clearing the RIF Table	15-45
16 Configuring Frame Translations	16-1
Any-to-Any Switching	16-1
Translating the Frame	16-2
The MAC Header	16-3
Canonical versus Non-Canonical	16-3
Abbreviated Addresses	16-3
Functional Addresses and Multicasts	16-3
The RIF Field	16-4
Source Route Termination by Proxy Not Supported	16-4
Encapsulation	16-5
Protocols other than IP and IPX	16-5
The SNAP Conversion	16-6
Other Conversions	16-6
Summary of Non-IPX Encapsulation Transformation Rules	16-6
IPX Encapsulation Transformation Rules	16-7
The Network Header	16-8
Address Mapping	16-8
Address Mapping in IP: ARP	16-8
Address Mapping in IPX	16-9
Frame Size Requirements	16-10
Insertion of Frame Padding	16-10
Stripping of Padding for all IEEE 802.3 Frames.	16-10
No stripping of non-IPX Ethertype Frames	16-10
IPX Specific Stripping	16-10
MTU Handling	16-11
IP Fragmentation	16-11
ICMP Based MTU Discovery	16-11
IPX Packet Size Negotiation	16-11
Other Protocols	16-11
Banyan Vines	16-12

Configuring Encapsulation Options	16-13
Forwarding versus Flooding	16-13
Port Based Translation Options	16-13
MAC Address Based Translation Options	16-13
“Native” versus “Non-Native” on Ethernet	16-14
“Native” versus “Non-Native” on FDDI and Token Ring	16-14
No Translation on Trunk or PTOP ports	16-14
The Proprietary Token Ring IPX Option	16-14
The User Interface	16-15
The addvp, modvp and crgp Commands	16-15
The Default Translation Option	16-15
Ethernet Factory Default Translations	16-16
FDDI Factory Default Translations	16-16
Token Ring Factory Default Translations	16-17
ATM LANE Factory Default Translations	16-17
The Ethertype Option	16-18
The SNAP Option	16-19
The LLC Option	16-21
Interaction with the new interface	16-22
The “vi” Command	16-22
The Switch Menu	16-23
Proprietary IPX Token Ring	16-23
Factory Defaults	16-23
Default Ethernet Translations	16-24
Default FDDI Translations	16-25
Default Token Ring Translations	16-26
Port Translations	16-28
Configuring Additional Ports	16-29
Displaying Ethernet Switch Statistics	16-29
Any to Any MAC Translations	16-33
Default Autoencapsulation	16-34
Translational Bridging	16-35
Learning	16-35
Translations across Trunks	16-35
Dissimilar LAN Switching Capabilities	16-36
Switching Between Similar LANs	16-36
Switching Between Ethernet LANs Across a Trunked Backbone	16-37
Switching Between Similar LANs across a Native Backbone	16-38

17 Managing Groups and Ports	17-1
How Ports Are Assigned to Groups	17-2
Static Port Assignment	17-2
Dynamic Port Assignment (Group Mobility)	17-2
How Dynamic Port Assignment Works	17-3
Mobile Groups	17-5
Configuring Mobile Groups	17-5
Turning Group Mobility On or Off	17-6
Understanding Port Membership in Mobile Groups	17-7
How a Device Is Dropped from the Default Mobile Group (def_group)	17-8
How a Port's Primary Mobile Group Changes (move_from_def)	17-9
How a Port Ages Out of a Mobile Group (move_to_def)	17-10
Configuring Switch-Wide Group Mobility Variables	17-11
Viewing Ports in a Mobile Group	17-13
Viewing a Port's Mobile Group Affiliations	17-13
Dynamic LANE Services	17-14
Dynamic LANE Services and Non-Dynamic LANE Services	17-14
Creating Auto-Activated LANE Services	17-15
Deleting an Auto-Activated Service	17-15
Viewing Auto-Activated Services	17-16
Non-Mobile Groups and AutoTracker VLANs	17-17
Routing in a Non-Mobile Group	17-17
Spanning Tree and Non-Mobile Groups	17-18
Group and Port Software Commands	17-19
Creating a New Group	17-20
Step 1. Entering Basic Group Information	17-21
Step 2. Configuring the Virtual Router Port (Optional)	17-22
Step 3. Set Up Group Mobility and User Authentication	17-27
Step 4. Configuring Virtual Ports	17-28
Step 5. Configure Auto-Activated LANE Ports (Mobile Groups Only)	17-33
Step 6. Configuring AutoTracker Policies (Mobile Groups Only)	17-34
Creating a WAN Routing Group	17-35
Creating an ATM CIP Group	17-38
Viewing Current Groups	17-40
Modifying a Group or VLAN	17-42
Viewing Your Changes	17-43
Saving Your Changes	17-43
Canceling Your Changes	17-43
Changing the IP Address	17-43
Changing the IP Subnet Mask	17-43
Enabling IP or IPX Routing	17-44

Deleting a Group	17-45
Adding Virtual Ports	17-46
Modifying a Virtual Port	17-47
Deleting a Virtual Port	17-48
Viewing Information on Ports in a Group	17-49
Viewing Detailed Information on Ports	17-51
Viewing Port Statistics	17-54
Viewing Port Errors	17-56
Port Mirroring	17-58
How Port Mirroring Works	17-58
What Happens to the Mirroring Port	17-58
Using Port Mirroring With External RMON Probes	17-59
Setting Up Port Mirroring	17-61
Disabling Port Mirroring	17-61
Port Monitoring	17-62
Port Monitoring Menu	17-62
RAM Disk System for Data Capture Files	17-63
Configuring RAM Drive Resources (pmcfg)	17-63
Changing the Default System Directory (cd)	17-63
Starting a Port Monitoring Session (pmon)	17-64
If You Chose Dump to Screen	17-65
If You Did Not Choose Dump to Screen	17-65
Ending a Port Monitoring Session	17-66
Viewing Port Monitoring Statistics (pmstat)	17-66
Port Mapping	17-67
Groups/VLANs and Port Mapping	17-67
The Details of Port Mapping	17-68
Who Can Talk to Whom?	17-69
Port Mapping Limitations	17-69
Creating a Port Mapping Set	17-70
Adding Ports to a Port Mapping Set	17-71
Removing Ports from a Port Mapping Set	17-72
Viewing a Port Mapping Set	17-73
Deleting a Port Mapping Set	17-73
Priority VLANs	17-74
Configuring VLAN Priority	17-75
Viewing VLAN Priority	17-75

18	Configuring Group and VLAN Policies	18-1
	AutoTracker Policy Types	18-2
	Defining and Configuring AutoTracker Policies	18-4
	Where These Procedures Start	18-4
	Defining a Port Policy	18-5
	Defining a MAC Address Policy	18-6
	Defining a Protocol Policy	18-7
	Defining a Network Address Policy	18-9
	Defining Your Own Rules	18-11
	Defining a Port Binding Policy	18-13
	Defining a DHCP Port Policy	18-17
	Defining a DHCP MAC Address Policy	18-18
	Viewing Mobile Groups and AutoTracker VLANs	18-19
	Viewing Policy Configurations	18-20
	Viewing Virtual Ports' Group/VLAN Membership	18-21
	View VLAN Membership of MAC Devices	18-22
	Application Example: DHCP Policies	18-23
	The VLANs	18-23
	DHCP Servers and Clients	18-24
	DHCP Port and MAC Rules	18-25
19	Interswitch Protocols	19-1
	Interswitch Protocol Commands	19-1
	XMAP	19-2
	XMAP Transmission States	19-3
	Discovery Transmission State	19-3
	Common Transmission State	19-4
	Passive Reception State	19-4
	Common Transmission and Remote Switches	19-4
	Configuring XMAP	19-5
	Enabling or Disabling XMAP	19-5
	Viewing a List of Adjacent Switches	19-5
	Configuring the Discovery Transmission Time	19-6
	Configuring the Common Transmission Time	19-7
	VLAN Advertisement Protocol (VAP)	19-8
	VAP and Port Policies	19-9
	Configuring VAP	19-9

GMAP	19-10
GMAP Updating Rules	19-10
Configuring GMAP	19-11
Enabling and Disabling GMAP	19-11
Configuring the Gap Time	19-11
Configuring the Interpacket Update Time	19-12
Configuring the Hold Time	19-12
Displaying GMAP Statistics by MAC Address	19-13
20 Managing AutoTrackerVLANs	20-1
The AutoTracker Menu	20-2
AutoTracker VLANs	20-3
AutoTracker VLAN Policies	20-3
The Default VLAN	20-4
How Devices are Assigned to AutoTracker VLANs	20-5
The defvl Command	20-5
Devices that Generate a Secondary Traffic Type	20-6
Router Traffic in IP and IPX Network Address VLANs	20-7
Port Policy Functionality	20-9
Frame Flooding in AutoTracker VLANs	20-15
Routing Between AutoTracker VLANs	20-15
Creating AutoTracker VLANs	20-16
Step A. Entering Basic VLAN Information	20-16
Step B. Defining and Configuring VLAN Policies	20-18
Step C. Configuring the Virtual Router Port (Optional)	20-19
Modifying an AutoTracker VLAN	20-24
Deleting an AutoTracker VLAN	20-26
Viewing AutoTracker VLANs	20-27
Viewing Policy Configurations	20-28
Viewing Virtual Ports' VLAN Membership	20-29
View VLAN Membership of MAC Devices	20-30
Creating a VLAN for Banyan Vines Traffic	20-31

21 Multicast VLANs	21-1
How Devices are Assigned to Multicast VLANs	21-2
Multicast VLANs and Multicast Claiming	21-2
Frame Flooding in Multicast VLANs	21-3
Creating Multicast VLANs	21-4
Step A. Entering Basic Information	21-5
Step B. Defining the Multicast Address	21-6
Step C. Defining the Recipients of Multicast Traffic	21-7
Defining Recipients By Port	21-7
Defining Recipients By MAC Address	21-8
Modifying Multicast VLANs	21-9
Deleting a Multicast VLAN	21-11
Modifying a Multicast Address Policy	21-12
Viewing Multicast VLANs	21-13
Viewing Multicast VLAN Policies	21-14
Viewing the Virtual Interface of Multicast VLANs	21-15
22 AutoTracker VLAN Application Examples	22-1
Application Example 1	22-2
VLANs Based on Logical Policies	22-2
Application Example 2	22-4
VLANs in IPX Networks	22-4
IPX VLAN Assignment at Bootup	22-5
Application Example 3	22-7
IPX Network Address VLANs and Translated Frames	22-7
Application Example 4	22-8
Routing in IPX Networks	22-8
Application Example 5	22-10
Traversing a Backbone	22-10

23 IP Routing	23-1
Introduction	23-1
IP Routing Overview	23-2
Routing Protocols	23-2
Transport Protocols	23-3
Application-Layer Protocols	23-3
Additional IP Protocols	23-3
Setting Up IP Routing on the Switch	23-4
The Networking Menu	23-6
The IP Submenu	23-7
Viewing the Address Translation (ARP) Table	23-8
Displaying All Entries in the ARP Table	23-8
Adding Entries to the ARP Table	23-9
Deleting Entries from the ARP Table	23-10
Flushing Temporary Entries from the ARP Table	23-10
Finding a Specific IP Address in the ARP Table	23-10
Finding a Specific MAC Address in the ARP Table	23-11
Viewing IP Statistics and Errors	23-12
Viewing the IP Forwarding Table	23-14
Adding an IP Static Route	23-15
Removing an IP Static Route	23-16
Viewing ICMP Statistics and Errors	23-17
Using the PING Command	23-19
Viewing UDP Statistics and Errors	23-20
Viewing the UDP Listener Table	23-21
Viewing RIP Statistics and Errors	23-22
Viewing TCP Statistics	23-23
Viewing the TCP Connection Table	23-25
Using the TELNET Command	23-26
Tracing an IP Route	23-27
Flushing the RIP Routing Tables	23-27

Configuring IP RIP Filters	23-28
Adding a “Global” IP RIP Filter	23-28
Adding an IP RIP Filter For a Specific Group or VLAN	23-29
IP RIP Filter Precedence	23-30
Deleting IP RIP Filters	23-31
Displaying IP RIP Filters	23-32
Displaying a List of All IP RIP Filters	23-32
Displaying a List of “Global” IP RIP Filters	23-33
Displaying a List of Specific IP RIP Filters	23-33
Viewing the IP-to-MAC Address Table	23-34
Displaying All Entries in the IP-to-MAC Table	23-34
Displaying Information for a Specific IP Address	23-35
Flushing Entries from the Table	23-35
Path MTU Discovery	23-36
24 UDP Forwarding	24-1
UDP Relay Hardware/Software Support	24-1
UDP Relay Configuration Screen	24-2
BOOTP/DHCP Relay	24-3
Overview of DHCP	24-3
DHCP and the OmniStack	24-3
BOOTP/DHCP Relay and Source Routing	24-4
BOOTP/DHCP Relay and Authentication	24-4
External BOOTP relay	24-5
Internal BOOTP/DHCP Relay	24-6
Example 1	24-6
Example 2	24-7
Enabling BOOTP/DHCP Relay	24-8
Configuring BOOTP/DHCP Relay Parameters	24-9
NetBIOS Relays	24-10
Overview of NetBIOS	24-10
NetBIOS Relay Application	24-11
Configuring NBNS Relay	24-12
Next-Hop Addresses for NBNS	24-13
Forwarding VLANs for NBNS Relay	24-14
Configuring NBDD Relay	24-15
Next-Hop Addresses for NBDD	24-16
Forwarding VLANs for NBDD Relay	24-17
Generic Service UDP Relay	24-18
Generic Services Menu	24-18
Adding a Generic Service	24-18
Modifying a Generic Service	24-20
Deleting a Generic Service	24-21
Viewing UDP Relay Statistics	24-22

25 IPX Routing	25-1
Introduction	25-1
IPX Routing Overview	25-2
IPX Protocols	25-2
Setting Up IPX Routing on the Switch	25-2
The IPX Submenu	25-4
Viewing the IPX Routing Table	25-5
Displaying All Entries in the IPX Routing Table	25-5
Using IPXR with Frame Relay or ISDN Boards	25-6
Displaying a List of Specific IPX Routes	25-7
Viewing IPX Statistics	25-8
Viewing the IPX SAP Bindery	25-10
Using IPXSAP with Frame Relay or ISDN Boards	25-10
Displaying a List of Specific SAP Servers	25-11
Adding an IPX Static Route	25-12
Removing an IPX Static Route	25-13
Turning the IPX Router Complex On and Off	25-14
Flushing the IPX RIP/SAP Tables	25-14
Using the IPXPING Command	25-15
Configuring IPX RIP/SAP Filtering	25-17
Adding a “Global” IPX RIP/SAP Filter	25-18
Adding an IPX RIP/SAP Filter for a Specific Group or VLAN	25-19
Deleting an IPX RIP/SAP Filter	25-21
Displaying IPX RIP/SAP Filters	25-22
Displaying a List of All IPX Filters	25-22
Displaying a List of “Global” IPX Filters	25-23
Displaying a List of Specific IPX Filters	25-23
IPX RIP/SAP Filter Precedence	25-24
Configuring IPX Serialization Packet Filtering	25-25
Enabling IPX Serialization Filtering	25-25
Disabling IPX Serialization Filtering	25-26
Configuring IPX Watchdog Spoofing	25-27
Enabling IPX Watchdog Spoofing	25-27
Disabling IPX Watchdog Spoofing	25-28
Configuring SPX Keepalive Spoofing	25-29
Enabling SPX Keepalive Spoofing	25-29
Disabling SPX Keepalive Spoofing	25-30
Controlling IPX Type 20 Packet Forwarding	25-32
Configuring NetWare to Minimize WAN Connections	25-33

Configuring RIP and SAP Timers	25-35
Adding a RIP and SAP Timer	25-35
Viewing RIP and SAP Timers	25-35
Configuring Extended RIP and SAP Packets	25-37
Enabling or Disabling Extended RIP and SAP Packets	25-37
Viewing the Current Status of Extended Packets	25-37
Configuring an IPX Default Route	25-38
Adding an IPX Default Route	25-38
Viewing the Status of an IPX Default Route	25-38
Disabling an IPX Default Route	25-38
26 Managing ATM Ports	26-1
LAN Switch With ATM Uplinks	26-2
The ATM Menu	26-3
Modifying an ATM Access Port Configuration	26-4
Creating a Virtual Channel Connection	26-8
Modifying a Virtual Channel Connection	26-11
Deleting a Virtual Channel Connection	26-11
Creating a Virtual ATM Address	26-12
Modifying Virtual ATM Addresses	26-13
Deleting a Virtual ATM Address	26-13
Viewing ATM Port Configuration Information	26-14
Viewing SSCOP, ILMI, and PHY	26-17
Viewing Virtual Channel Connections	26-19
Viewing Virtual ATM Addresses	26-21
Viewing the ATM Layer Statistics Table	26-23
Viewing the ATM Layer Rx Error Statistics Table	26-24
Viewing the ATM Layer Tx Error Statistics Table	26-26
Viewing the ATM Connection Statistics Table	26-27
Viewing the ATM Connection Rx Error Statistics Table	26-28
Viewing the ATM Connection Tx Error Statistics Table	26-30
Traffic Shaping	26-32
Configuring Traffic Shaping	26-32
Viewing Traffic Shaping Parameters	26-34

27 LANE Server Configuration	27-1
Introduction	27-1
LAN Emulation Components	27-1
LANE Component Interactions	27-2
LAN-to-ATM Communication	27-3
Overview of LES/BUS and LECS Configuration	27-4
The LANE Service Menu (LSM)	27-4
Configuring LES/BUS and LECS	27-5
Making SubMenu Option Selections	27-6
Specifying a Global ELAN Name	27-7
Creating a LES/BUS Pair	27-8
Modifying a LES/BUS Pair	27-10
Deleting a LES/BUS Pair	27-11
Creating the LECS	27-12
Modifying the LECS	27-14
Deleting the LECS	27-15
Adding ELANs to the LECS	27-16
Deleting an ELAN from the LECS	27-18
Adding Policies to ELANs in the LECS	27-19
Deleting Policies from ELANs in the LECS	27-21
Displaying a List of LES/BUS Pairs	27-22
Displaying LES/BUS Pair Status	27-23
Displaying LES/BUS Pair Statistics	27-25
Displaying LES/BUS Configuration	27-31
Displaying LECs in a LES/BUS Pair	27-32
Displaying MAC Addresses for a LES/BUS Pair	7-33
Displaying Registered Route Descriptor for a LES/BUS Pair	27-34
Displaying Detailed LEC Information	27-35
Displaying LECS Status	27-37
Displaying LECS Statistics	27-38
Displaying LECS Configuration	27-40
Displaying ELANs in the LECS	27-41
Displaying ELAN Policies in the LECS	27-42

28 Configuring ATM Services	28-1
Introduction	28-1
ATM Services	28-1
PVC/SVC Support	28-2
Service	28-2
SVC	28-2
PVC	28-2
LANE Client (LEC) Services	28-3
Token Ring vs. Ethernet Networks	28-4
Source-Routed Traffic	28-5
LANE Version 2.0	28-5
LAN Emulated Client Start-Up and Back-Off Timers	28-6
ATM Trunking	28-8
Groups over ATM	28-8
VLANs over ATM	28-9
Spanning Tree and Trunking	28-9
Translations Across Trunks	28-9
Classical IP Routing	28-10
LLC Header Encapsulation	28-10
IP to ATM Address Resolution	28-10
IP Over ATM Signaling	28-10
Typical CIP over ATM Configuration	28-11
Point-to-Point Bridging	28-12
VLAN Clusters	28-13
Method 1	28-14
Method 2	28-14
Configuring ATM Services	28-15
Services Menu	28-15
Creating a Service	28-16
Creating a LANE Client Service	28-18
Setting LANE Client Parameters	28-20
Creating a Trunking Service	28-22
Creating a Classical IP Service	28-24
Creating a PTOB Bridging Service	28-26
Creating a VLAN Cluster Service	28-28
Modifying a Service	28-30
Modifying a LANE Client Service	28-30
Modifying a Trunking Service	28-31
Modifying a Classical IP Service	28-32
Adding Static ARP Entries for CIP	28-34
Modifying a PTOB Bridging Service	28-35
Modifying a VLAN Cluster Service	28-36
Modifying VLAN Cluster Parameters	28-37

Deleting a Service	28-38
Deleting Static ATM ARP Entries for CIP	28-39
Viewing ATM Access Port Services	28-40
Viewing General Service Statistics on a Port	28-41
Viewing Service Statistics for a LANE Client	28-42
Viewing the LANE LE_ARP Table	28-45
Viewing ATM Service Statistics for Classical IP	28-46
Viewing the CIP ARP Table	28-48
Viewing Service Statistics for VLAN Clusters	28-49
29 Multi-Protocol Over ATM (MPOA)	29-1
Introduction	29-1
Network Functionality and MPOA	29-1
MPOA Requirements	29-4
The MPOA Client (MPC)	29-4
The MPOA Network	29-7
The MPOA Management Menu	29-10
Configuring an MPOA Client Service	29-11
Viewing Client Service Status	29-14
Viewing Client Service Statistics	29-15
Viewing Entries in the Ingress Cache Table	29-19
Viewing Entries in the Egress Cache Table	29-20
Viewing MPOA Servers	29-21
30 Managing WAN Switching Modules	30-1
Introduction	30-1
Supported Physical Interfaces	30-2
Universal Serial Port	30-2
ISDN Basic Rate Interface Port	30-2
Fractional T1 Port	30-2
Fractional E1 Port	30-2
Supported Protocols	30-3
Application Examples	30-4
Frame Relay OSWSM Using Serial Ports	30-4
Back-to-Back OSWSM Using T1 Ports	30-5
Combined Frame Relay with ISDN Backup	30-5
WAN Modules	30-6

OSWSM-FT1/FE1-SC: WAN T1 or E1 Submodule	30-7
Configuring the T1/E1 Ports	30-7
OSWSM-FT1/E1 Technical Specifications	30-7
Front Panel	30-8
Cabling/Jumper Settings	30-9
OSWSM-BRI: ISDN Submodule	30-10
OSWSM-BRI Technical Specifications	30-10
Front Panel	30-11
OSWSM-S: Two or Four Serial Port WAN Submodule	30-13
OSWSM Technical Specifications	30-13
Front Panel	30-14
Cable Interfaces for Universal Serial Ports	30-15
DTE/DCE Type and Transmit/Receive Pins	30-15
Data Compression	30-16
Loopback Detection	30-16
The WAN Port Software Menu	30-17
Setting Configuration Parameters	30-17
Modifying a Port	30-18
Serial Port Example	30-18
ISDN-BRI Port Example	30-21
Fractional T1 Port Example	30-21
Viewing Configuration Parameters for the OSWSM	30-23
Viewing Parameters for all OSWSMs in the Chassis	30-23
Viewing Parameters for all Ports in a Single OSWSM	30-24
Viewing Port Parameters	30-26
Deleting Ports	30-29
Obtaining Status and Statistical Information	30-30
Obtaining Information on All Boards in a Switch	30-30
Obtaining Information on the Ports for a Single OSWSM Board	30-32
Viewing Information on a Single Port	30-34
Configuring 31 Timeslots on a WAN E1 Port	30-37

31 Managing Frame Relay	31-1
Back-to-Back Frame Relay Configurations	31-2
Universal Serial Port Cable Interfaces	31-3
“Physical” and “Logical” Devices	31-3
Compression	31-4
Virtual Circuits and DLCIs	31-5
OSWSM Self-Configuration and Virtual Circuits	31-6
Congestion Control	31-7
Regulation Parameters	31-7
Discard Eligibility (DE) Flag	31-8
Interaction Among Congestion Parameters	31-8
Notification By BECN	31-9
Notification By FECN	31-10
Frame Formats Supported	31-11
Bridging Services	31-12
Frame Relay IP Routing	31-13
The Frame Relay Subnet and “Split Horizon”	31-14
Frame Relay IPX Routing	31-16
Trunking	31-17
The Frame Relay Software Menu	31-18
Setting Configuration Parameters	31-19
Modifying a Port	31-19
Modifying a Virtual Circuit	31-25
Adding a Virtual Circuit	31-28
Viewing Configuration Parameters for the OSWSM	31-29
Viewing Parameters for all OSWSMs in the Chassis	31-29
Viewing Port Parameters	31-30
Viewing Virtual Circuit Parameters	31-31
Deleting Ports and Virtual Circuits	31-32
Deleting a Virtual Circuit	31-32
Deleting a Port and Its Virtual Circuits	31-33
Obtaining Status and Statistical Information	31-34
Information on All Boards in a Switch	31-34
Information on the Ports for One OSWSM Board	31-36
Information on One Port	31-37
Information on One Virtual Circuit	31-43
Resetting Statistics Counters	31-46
Resetting Statistics for a OSWSM Board	31-46
Resetting Statistics for a OSWSM Port	31-46
Resetting Statistics for a Virtual Circuit (DLCI)	31-46
Managing Frame Relay Services	31-47

Configuring a Bridging Service	31-49
Configuring a WAN Routing Service	31-51
Step 1. Set Up a Frame Relay Routing Group	31-51
Step 2. Set Up a Frame Relay Routing Service	31-52
Configuring a Trunking Service	31-54
Viewing Frame Relay Services	31-56
Modifying a Frame Relay Service	31-57
Deleting a Frame Relay Service	31-58
32 Point-to-Point Protocol	32-1
PPP Connection Phases	32-1
Data Compression	32-2
Multi-Link PPP	32-2
Multilink Modes of Operation	32-3
Overview of PPP Configuration Procedures	32-3
The PPP Submenu	32-5
PPP Configuration Overview	32-5
Setting Global PPP Parameters	32-6
Adding a PPP Entity	32-8
Modifying a PPP Entity	32-13
Viewing PPP Entity Configurations	32-14
Displaying the Configuration of All PPP Entities	32-14
Displaying the Configuration of a Specific PPP Entity	32-15
Displaying PPP Entity Status	32-17
Displaying the Status of All PPP Entities	32-17
Displaying the Status of a Specific PPP Entity	32-18
Deleting a PPP Entity	32-20
33 WAN Links	33-1
Introduction	33-1
Configuring WAN Interfaces	33-1
The Link Submenu	33-2
Adding a WAN Link	33-3
Adding WSM Port Links	33-3
Adding ISDN Call Links	33-4
Modifying a WAN Link	33-9
Modifying ISDN Links	33-9
Modifying WSM Links	33-10
Deleting WAN Links	33-11

Viewing WAN Links	33-12
Displaying All Existing WAN Links	33-12
Displaying Information for a Specific WAN Link	33-13
Displaying Link Status	33-15
Displaying Status for All WAN Links	33-15
Displaying Status for a Specific WAN Link	33-16
34 Managing ISDN Ports	34-1
Overview of ISDN	34-1
Basic Rate Interface (BRI) Versus Primary Rate Interface (PRI)	34-1
“U”, “S/T” , and “R” Interfaces	34-2
The “B,” “D,” and “H” Channels	34-2
The ISDN Submenu	34-3
Switch Configuration	34-3
Modifying an ISDN Configuration Entry	34-4
Deleting an ISDN Configuration Entry	34-5
Viewing an ISDN Configuration Entry	34-6
Displaying ISDN Configuration Entry Status	34-7
Displaying Status of All ISDN Ports	34-7
Displaying Status of a Specific ISDN Slot	34-8
Displaying Status of a Specific ISDN Port	34-9
35 Managing T1 and E1 Ports	35-1
T1 and E1 Overview	35-2
The T1/E1 Menu	35-3
Configuring a T1 Port	35-4
Configuring an E1 Port	35-8
Viewing T1/E1 Configuration and Alarm Information	35-11
Viewing Information for all T1/E1 Ports in the Switch	35-11
Viewing Information for T1/E1 Ports on One Module	35-12
Viewing Information For a T1 Port	35-13
Viewing Information For an E1 Port	35-15
Viewing T1/E1 Local Statistics	35-17
Viewing Total Local Statistics	35-17
Viewing Current Local Statistics	35-18
Viewing Local Historical Statistics	35-19
Viewing T1 Remote Statistics	35-20
Viewing Total Remote Statistics	35-20
Viewing Current Remote Statistics	35-21
Viewing Remote Historical Statistics	35-21
Clearing the Framer Statistics for a T1/E1 Port	35-22

36 Managing DS3/E3 Ports	36-1
DS3/E3 Overview	36-1
DS3 Framing	36-1
E3 Framing	36-1
DS3/E3 Port Management Menu	36-2
Configuring a DS3 Port	36-2
Field Descriptions	36-3
Configuring an E3 Port	36-4
Field Descriptions	36-4
Viewing DS3/E3 Configuration and Alarm Information	36-7
Viewing Information for all DS3/E3 Ports in the Switch	36-7
Field Descriptions	36-7
Viewing Information for DS3/E3 Ports on a Board	36-8
Viewing Information for a DS3 Port	36-9
Field Descriptions	36-9
Viewing Information for an E3 Port	36-10
Field Descriptions	36-12
Viewing DS3/E3 Local Statistics	36-13
Viewing DS3/E3 Local Total Statistics	36-13
Field Descriptions	36-14
Displayed Statistics	36-14
Viewing DS3/E3 Local Current Statistics	36-15
Viewing DS3/E3 Local Interval (Historical) Statistics	36-16
Viewing ATM Physical Layer Statistics for DS3 (CbitParity PLCP Sublayer)	36-17
Status Definitions for DS3 3.	6-18
Statistics Definitions for DS3 3.	6-19
Viewing ATM Physical Layer Statistics for DS3 (CbitParity ADM Sublayer)	36-20
Viewing ATM Physical Layer Statistics for DS3 (M23 Type PLCP Sublayer)	36-21
Viewing ATM Physical Layer Statistics for DS3 (M23 Type ADM Sublayer)	36-22
Viewing ATM Physical Layer Statistics for E3 (G.751 PLCP Sublayer)	36-23
Status Definitions for E3 G.751 PLCP	36-24
Statistics Definitions for E3, PLCP G.751	36-24
Viewing ATM Physical Layer Statistics for E3 (G.751 ADM Sublayer)	36-25
Statistics Definitions for E3, ADM G.751	36-25

Viewing ATM Physical Layer Statistics for E3 (G.832 ADM Sublayer)	36-26
Status Definitions for G.832 ADM	36-26
Statistics definitions for E3, ADM G.832	36-27
Viewing ATM Physical Layer Interval Statistics for DS3 (CbitParity PLCP Sublayer)	36-28
Viewing ATM Physical Layer Interval Statistics for DS3 (CbitParity ADM Sublayer)	36-29
Viewing ATM Physical Layer Interval Statistics for DS3 (M23 Type PLCP Sublayer)	36-30
Viewing ATM Physical Layer Interval Statistics for DS3 (M23 Type ADM Sublayer)	36-31
Viewing ATM Physical Layer Interval Statistics for E3 (G.832 PLCP Sublayer)	36-32
Viewing ATM Physical Layer Interval Statistics for E3 (G.751 ADM Sublayer)	36-33
Clearing Interval Statistics	36-33
37 Backup Services	37-1
Introduction	37-1
Backup Services Commands	37-2
Accessing the Backup Services Menu	37-2
Adding a Backup Service	37-3
Adding a backup for a Physical Port	37-3
Field Descriptions	37-4
Backing Up a Frame Relay PVC	37-5
Modifying a Backup Service	37-7
Modifying a backup for a Physical Port	37-7
Modifying a Frame Relay PVC Backup Service	37-8
Viewing Backup Service(s) Configurations	37-10
Viewing the Configurations of All Backup Services	37-10
Viewing the Configuration of a Single Backup Service (bsview Command)	37-10
Deleting a Backup Service	37-10

38 Managing the OSWSM-M013 Module	38-1
Introduction	38-1
Digital Signal Level X (DSX)	38-2
Supported Physical Interfaces	38-3
BNC	38-3
Balanced T1	38-3
Supported Protocols	38-3
Application Examples	38-4
Internet Services Provider Point-of-Presence	38-4
Local Exchange Carrier's Central Office	38-5
OSWSM-M013 Module	38-6
OSWSM-M013 Technical Specifications	38-6
OSWSM-M013 Configuration Overview	38-8
The OSWSM-M013 Management Menu	38-10
Physical Configuration Commands	38-11
Logical Configuration Commands	38-11
Configuring a DS3 Port	38-13
Configuring a DS3 Port using C-Bit Parity	38-16
Maintenance Data Link (MDL) Field Descriptions	38-17
Viewing Cumulative Statistics and Errors of a Local DS3 Port	38-19
Viewing Current 15-Minute Statistics and Errors of a Local DS3 Port	38-21
Viewing 15-Minute Interval (Historical) Statistics and Errors of a Local DS3 Port	38-22
Clearing Interval Statistics and Errors of a Local DS3 Port	38-24
Viewing Configuration and Statistical Parameters for a DS3 Port	38-25
Viewing Received MDL Messages	38-26
Configuring a DS1 Channel	38-27
Setting DS1 Collection Statistics for a DS3 Port	38-31
Viewing Cumulative Statistics and Errors of a Local DS1 Channel	38-31
Viewing Current 15-Minute Statistics of a Local DS1 Channel	38-33
Viewing 15-Minute Interval Statistics and Errors of a Local DS1 Channel	38-34
Clearing Interval Statistics of a Local DS1 Channel	38-36
Viewing Configuration and Statistical Parameters for a DS1 Channel	38-37
Adding a Logical Port Configuration	38-38
Adding a Logical Port Configuration to a Clear Channel DS3 Port	38-40
Modifying a Logical Port Configuration	38-40
Deleting a Logical Port	38-43
Viewing Logical Port Configuration and Statistics	38-44
Clear Statistics for a Logical Port	38-46
Modify the Protocol Configuration of a Logical Port using PPP	38-47
Modify the Protocol Configuration of a Logical Port using Frame Relay	38-50
Display Protocol Configuration and Statistics of a Logical Port using PPP	38-54

Display Protocol Configuration and Statistics of a Logical Port using Frame Relay	38-58
Clear Protocol Statistics of a Logical Port	38-63
Add Frame Relay DLCI on a Logical Port	38-64
Delete Frame Relay DLCI on a Logical Port	38-65
Adding a Router Interface	38-66
Modifying a Router Interface Configuration	38-67
Deleting a Router Interface	38-67
Viewing Router Interfaces	38-68
Clearing Statistics for a Router Interface	38-68
Creating a Bridging or Trunking Service	38-69
Deleting Services	38-71
Viewing Service Configurations	38-71
Modifying Service Configurations	38-73
Deleting the Module Configuration	38-74
39 Troubleshooting	39-1
Introduction	39-1
Detecting Problems	39-1
Reporting Problems	39-1
Software Problems	39-2
Can't Install Software	39-2
Operational Problems	39-2
Hardware Problems	39-4
Error Messages	39-5
Chassis Error Messages	39-7
40 Running Hardware Diagnostics	40-1
Introduction	40-1
Getting Started	40-2
Accessing the Diagnostics Submenu	40-4
Temperature Masking	40-5
Initiating Hardware Tests	40-6
Port Test Wrap Cable/Plug Requirements	40-9
Sample Test Session: OmniStack 5024	40-12
If You Do Not Run Port Tests	40-14
Displaying Available Diagnostic Tests	40-15
Configuring the Diagnostic Test Environment	40-16
Configuring Tests for Ethernet Slots	40-17
Diagnostic Test Cable Schematics	40-18
Enabling Diagnostics on an OmniStack 1032 or 4016	40-20

A	The Boot Line Prompt	A-1
	Entering the Boot Prompt	A-2
	Boot Prompt Basics	A-3
	Resuming Switch Boot (@)	A-3
	Displaying Current Configuration (p)	A-4
	Loading the Last Configured Boot File (l)	A-4
	Listing Available Files in the Flash Memory (L)	A-4
	Deleting All Files in the Flash Memory (P)	A-5
	Deleting Specific Files in the Flash Memory (R)	A-5
	Saving Configuration Changes (S)	A-5
	Viewing Version Number (V)	A-5
	Configuring an OmniStack	A-6
B	Custom Cables	B-1
	V.35 DTE Cable (For OSWSM-to-DCE Device Connection)	B-2
	V.35 DCE Cable (For OSWSM-to-DTE Device Connection)	B-3
	RS232 DTE Cable (For OSWSM-to-DCE Device Connection)	B-4
	RS232 DCE Cable (For OSWSM-to-DTE Device Connection)	B-5
	RS530 DTE Cable (For OSWSM-to-DCE Device Connection)	B-6
	RS530 DCE Cable (For OSWSM-to-DTE Device Connection)	B-7
	X.21 DTE Cable (For OSWSM-to-DCE Device Connection)	B-8
	X.21 DCE Cable (For OSWSM-to-DTE Device Connection)	B-9
	RS449 DTE Cable (For OSWSM-to-DCE Device Connection)	B-10
	RS-449 DCE Cable Assembly (For OSWSM-to-DTE Device 75W Connection)	B-11
	RJ-45 to DB15F Cable Assembly (For T1/E1 Port 120W Connections)	B-12
	RJ-45 to BNC Cable Assembly (For E1 75W Port Connections)	B-13
	Index	I-1

