

Part No. 030542-10, Rev. A  
May 2000

# **OmniAccess™ 408 User Manual**

## **Release 4.2**



[www.alcatel.com](http://www.alcatel.com)

**SwitchExpert<sup>SM</sup> Service Programs:** An Alcatel service agreement brings your company the assurance of 7x24 no-excuses technical support. You'll also receive regular software updates to maintain and maximize your Alcatel product's features and functionality and on-site hardware replacement through our global network of highly qualified service delivery partners. Additionally, with 24-hour-a-day access to Alcatel's Service and Support web page, you'll be able to view and update any case (open or closed) that you have reported to Alcatel's technical support, open a new case or access helpful release notes, technical bulletins, and manuals. For more information on Alcatel's Service Programs, see our web page at [www.ind.alcatel.com](http://www.ind.alcatel.com), call us at 1-800-995-2696, or email us at [switchexpert@ind.alcatel.com](mailto:switchexpert@ind.alcatel.com).

**This Manual documents Release 4.2 OmniAccess 408 hardware and software.  
The functionality described in this Manual is subject to change without notice.**

Copyright© 2000 by Alcatel Internetworking, Inc. All rights reserved. This document may not be reproduced in whole or in part without the express written permission of Alcatel Internetworking, Inc.

Alcatel<sup>®</sup> and the Alcatel logo are registered trademarks of Alcatel. Xylan<sup>®</sup>, OmniSwitch<sup>®</sup>, PizzaSwitch<sup>®</sup> and Omni-Stack<sup>®</sup> are registered trademarks of Alcatel Internetworking, Inc. X-Cell<sup>™</sup>, Omni Switch/Router<sup>™</sup>, OmniAccess<sup>™</sup>, PizzaPort<sup>™</sup>, X-Vision<sup>™</sup>, AutoTracker<sup>™</sup>, SwitchManager<sup>™</sup>, SwitchStart<sup>™</sup>, SwitchExpert<sup>SM</sup>, WebView<sup>™</sup>, PolicyView<sup>™</sup>, and the Xylan logo are trademarks of Alcatel Internetworking, Inc. All other brand and product names are trademarks of their respective companies.



26801 West Agoura Road  
Calabasas, CA 91301  
(818) 880-3500 FAX (818) 880-3505  
[info@ind.alcatel.com](mailto:info@ind.alcatel.com)

US Customer Support—(800) 995-2696  
International Customer Support—(818) 878-4507  
Internet—<http://www.ind.alcatel.com>

## Warning

This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in this guide, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user will be required to correct the interference at his own expense.

The user is cautioned that changes and modifications made to the equipment without approval of the manufacturer could void the user's authority to operate this equipment. It is suggested that the user use only shielded and grounded cables to ensure compliance with FCC Rules.

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus out in the radio interference regulations of the Canadian department of communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la Class A prescrites dans le règlement sur le brouillage radioélectrique édicté par le ministère des communications du Canada.

**Lithium Batteries Caution:** There is a danger of explosion if the Lithium battery in your chassis is incorrectly replaced. Replace the battery only with the same or equivalent type of battery recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. The manufacturer's instructions are as follows:

**Return the module with the Lithium battery to Alcatel. The Lithium battery will be replaced at Alcatel's factory.**

The OmniAccess 408 has no user serviceable parts.



# Table of Contents

<b>1 OmniAccess 408</b>	1-1
Introduction	1-1
Application Example	1-2
OmniAccess 408 Hardware Options	1-3
OmniAccess 408 Slot Designations	1-5
OmniAccess 408 Management LEDs	1-6
OmniAccess 408 Ethernet Port LEDs	1-7
Configuring the Ethernet Ports	1-8
Configuring the T1/E1 Ports	1-8
Configuring the DS3/E3 Ports	1-8
The Console Management Port	1-8
OA-408-IMA-T1/E1	1-9
OA-408-IMA-T1/E1 Front Panel	1-10
OA-408-IMA-T1/E1 Hardware Specifications	1-11
General Chassis Information	1-11
OA-408-IMA-T1 Software Specifications	1-13
Standards Supported	1-13
Additional Software Information	1-13
OA-408-155FM-T1/E1	1-14
OA-408-155FM-T1/E1 Front Panel	1-15
OA-408-155FM-T1/E1 Hardware Specifications	1-16
General Chassis Information	1-16
OA-408-155FM-T1/E1 Software Specifications	1-18
Standards Supported	1-18
Additional Software Information	1-18
OA-408-155FS-T1/E1	1-19
OA-408-155FS-T1/E1 Front Panel	1-20
OA-408-155FS-T1/E1 Hardware Specifications	1-21
General Chassis Information	1-21
OA-408-155FS-T1/E1 Software Specifications	1-23
Standards Supported	1-23
Additional Software Information	1-23
OA-408-155-RFS-T1/E1	1-24
OA-408-155-RFS-T1/E1 Front Panel	1-25
OA-408-155-RFS-T1/E1 Hardware Specifications	1-26
General Chassis Information	1-26
OA-408-155-RFS-T1/E1 Software Specifications	1-28
Standards Supported	1-28
Additional Software Information	1-28

OA-408-155FSH-T1/E1 . . . . .	1-29
OA-408-155FSH-T1/E1 Front Panel . . . . .	1-30
OA-408-155FSH-T1/E1 Hardware Specifications . . . . .	1-31
General Chassis Information . . . . .	1-31
OA-408-155FSH-T1/E1 Software Specifications . . . . .	1-33
Standards Supported . . . . .	1-33
Additional Software Information . . . . .	1-33
OA-408-155-RFSH-T1/E1 . . . . .	1-34
OA-408-155-RFSH-T1/E1 Front Panel . . . . .	1-35
OA-408-155-RFSH-T1/E1 Hardware Specifications . . . . .	1-36
General Chassis Information . . . . .	1-36
OA-408-155-RFSH-T1/E1 Software Specifications . . . . .	1-38
Standards Supported . . . . .	1-38
Additional Software Information . . . . .	1-38
OA-408-DS3/E3 . . . . .	1-39
OA-408-DS3/E3 Front Panel . . . . .	1-40
OA-408-DS3/E3 Hardware Specifications . . . . .	1-41
General Chassis Information . . . . .	1-41
OA-408-DS3/E3 Software Specifications . . . . .	1-43
Standards Supported . . . . .	1-43
Additional Software Information . . . . .	1-43
Rear Panel . . . . .	1-44
Power Cords . . . . .	1-45
<b>2 The User Interface . . . . .</b>	<b>2-1</b>
Main Menu Summary . . . . .	2-2
General User Interface Guidelines . . . . .	2-3
Monitoring Your Switch . . . . .	2-3
Entering Command Names . . . . .	2-3
Quitting a Command . . . . .	2-3
Scrolling . . . . .	2-3
The UI Configuration Menu . . . . .	2-4
Configuring the System Prompt . . . . .	2-4
Configuring More Mode for the User Interface . . . . .	2-5
Enabling and Disabling Verbose Mode for the User Interface . . . . .	2-8
Configuring the Auto Logout Time . . . . .	2-9
Viewing Commands . . . . .	2-10
Changing Passwords . . . . .	2-10
Command History and Re-Executing Commands . . . . .	2-11
Abbreviating IP Addresses . . . . .	2-13
User Interface Display Options . . . . .	2-15
Setting Echo/NoEcho for User Entry . . . . .	2-16
Login Accounts . . . . .	2-17

Multiple User Sessions . . . . .	2-18
Listing Other Users . . . . .	2-19
Communicating with Other Users . . . . .	2-20
Deleting Other Sessions . . . . .	2-21
Advanced Kill Command Options . . . . .	2-22
UI Table Filtering (Using Search and Filter Commands) . . . . .	2-23
The Search Command . . . . .	2-24
Renewing a Search . . . . .	2-25
The Filter Command . . . . .	2-26
Combining Search and Filter Commands . . . . .	2-28
Using Wildcards with Search and Filter Commands . . . . .	2-30
Wildcard Command Options . . . . .	2-30
<b>3 Installing Switch Software . . . . .</b>	<b>3-1</b>
Using FTP Server . . . . .	3-2
Using FTP Client . . . . .	3-3
Using ZMODEM . . . . .	3-4
Using ZMODEM with the load Command . . . . .	3-4
Using ZMODEM With the Boot Line Prompt . . . . .	3-5
<b>4 Managing Files . . . . .</b>	<b>4-1</b>
File Menu . . . . .	4-1
Displaying the Current Directory . . . . .	4-2
Listing Switch Files . . . . .	4-2
Required Command and Image Files . . . . .	4-2
Configuration and Log File Generation . . . . .	4-2
File Name Directory . . . . .	4-3
Removing Switch Files . . . . .	4-4
Removing Multiple Files . . . . .	4-4
Removing All Image Files . . . . .	4-5
Copying System Files . . . . .	4-6
Viewing Text Files . . . . .	4-6
Editing Text Files . . . . .	4-7
Adding Lines of Text to the Text Buffer . . . . .	4-8
Clearing the Text Buffer . . . . .	4-8
Deleting a Line of Text from the Text Buffer . . . . .	4-8
Editing a Line Name of Text in the Text Buffer . . . . .	4-8
Inserting a Line of Text into the Text Buffer . . . . .	4-9
Listing the Contents of the Text Buffer . . . . .	4-9
Naming the Text Buffer . . . . .	4-9
Reading an ASCII File into the Text Buffer . . . . .	4-10
Writing a Text File from the Text Buffer . . . . .	4-10

Real-World Examples . . . . .	4-11
Real-World Example 1 . . . . .	4-11
Real-World Example 2 . . . . .	4-12
System Menu . . . . .	4-13
Checking the Flash File System . . . . .	4-14
Creating a New File System . . . . .	4-15
<b>5 Switch Security . . . . .</b>	<b>5-1</b>
Changing Passwords . . . . .	5-2
Rebooting the Switch . . . . .	5-3
Secure Switch Access . . . . .	5-4
Configuring Secure Switch Access Users Database . . . . .	5-4
Configuring Secure Access IP Protocols . . . . .	5-6
Viewing Secure Access Violations Log . . . . .	5-9
<b>6 Configuring Switch-Wide Parameters . . . . .</b>	<b>6-1</b>
Summary Menu . . . . .	6-1
Displaying the MIB-II System Group Variables . . . . .	6-2
Displaying the Chassis Summary . . . . .	6-3
Displaying Current Router Interface Status . . . . .	6-4
System Menu . . . . .	6-5
Displaying Basic System Information . . . . .	6-6
Setting the System Date and Time . . . . .	6-8
Configuring the Serial Port Parameters . . . . .	6-14
Viewing Slot Data . . . . .	6-16
Viewing System Statistics . . . . .	6-17
Viewing Task Utilization Statistics . . . . .	6-18
Viewing MPM Memory Statistics . . . . .	6-19
Checking the Flash File System . . . . .	6-20
Creating a New File System . . . . .	6-21
Configuring a System Description . . . . .	6-22
Viewing CAM Information . . . . .	6-23
Duplicate MAC Address Support . . . . .	6-24
Multicast Claiming . . . . .	6-25
Disabling Flood Limits . . . . .	6-25



<b>7</b>	<b>Switch Logging</b>	7-1
	Logging Overview	7-1
	Configuring the Syslog Parameters	7-2
	Configuring Switch Logging	7-6
	Displaying the Command History Entries in the FFS Log	7-10
	Displaying the Connection Entries in the FFS Log	7-11
	Displaying Screen (Console) Capture Entries in the FFS Log	7-12
	Displaying Debug Entries in the FFS Log	7-14
	Displaying Secure Access Entries in the FFS Log	7-14
<b>8</b>	<b>Health Statistics</b>	8-1
	The Health Statistics Management Menu	8-1
	Setting Resource Thresholds	8-2
	Setting Bandwidth Thresholds	8-3
	Setting Miscellaneous Thresholds	8-4
	Setting the Sampling Interval	8-6
	View Switch-Level Statistics	8-6
	View Module-Level Statistics	8-8
	View Port-Level Statistics	8-8
	Reset Health Statistics	8-9
<b>9</b>	<b>Network Time Protocol</b>	9-1
	Introduction	9-1
	Stratum	9-2
	Using NTP in a Network	9-2
	NTP and Authentication	9-4
	Network Time Protocol Management Menu	9-5
	NTP Configuration Menu	9-6
	Configuring an NTP Client	9-6
	Configuring an NTP Client/Server	9-8
	Configuring Client/Server Authentication	9-9
	Configuring a New Peer Association	9-12
	Configuring a New Server	9-13
	Configuring a Broadcast Time Service	9-13
	Unconfigure Existing Peer Associations	9-14
	Set the Server's Advertised Precision	9-14
	NTP Information Menu	9-15
	Display List of Peers the Server Knows About	9-15
	Display Peer Summary Information	9-16
	Display Alternate Peer Summary Information	9-17
	Display Detailed Information for One or More Peers	9-18
	Print Version Number	9-20
	Display Local Server Information	9-21

NTP Statistics Menu . . . . .	9-23
Display Local Server Statistics . . . . .	9-23
Display Server Statistics Associated with Particular Peer(s) . . . . .	9-24
Display Loop Filter Information . . . . .	9-26
Display Peer Memory Usage Statistics . . . . .	9-26
Display I/O Subsystem Statistics . . . . .	9-27
Display Event Timer Subsystem Statistics . . . . .	9-28
Reset Various Subsystem Statistics Counters . . . . .	9-28
Reset Stat Counters Associated With Particular Peer(s) . . . . .	9-28
Display Packet Count Statistics from the Control Module . . . . .	9-29
Display the Current Leap Second State . . . . .	9-30
Turn the Server's Monitoring Facility On or Off . . . . .	9-31
Display Data The Server's Monitor Routines Have Collected . . . . .	9-31
NTP Administration Menu . . . . .	9-33
Set the Primary Receive Timeout . . . . .	9-33
Set the Delay Added to Encryption Time Stamps . . . . .	9-33
Specify the Host Whose NTP Server We Talk To . . . . .	9-34
Specify a Password to Use for Authenticated Requests . . . . .	9-34
Set Key ID to Use for Authenticated Requests . . . . .	9-34
Set Key Type to Use for Authenticated Requests (DES MD5) . . . . .	9-35
Set a System Flag (Auth, Bclient, Monitor, Stats) . . . . .	9-35
Clear a System Flag (Auth, Bclient, Monitor, Stats) . . . . .	9-35
NTP Access Control Menu . . . . .	9-36
Change the Request Message Authentication Key ID . . . . .	9-36
Change the Control Message Authentication Key ID . . . . .	9-37
Add One or More Key ID's to the Trusted List . . . . .	9-37
Display the Trusted Key ID List . . . . .	9-37
Remove One or More Key ID's from the Trusted List . . . . .	9-38
Display the State of the Authentication Code . . . . .	9-38
Create Restrict Entry/Add Flags to Entry . . . . .	9-39
View the Server's Restrict List . . . . .	9-40
Remove Flags from a Restrict Entry . . . . .	9-41
Delete a Restrict Entry . . . . .	9-41
Configure a Trap in the Server . . . . .	9-41
Display the Traps Set in the Server . . . . .	9-42
Remove a Trap (Configured or Otherwise) from the Server . . . . .	9-42
<b>10 SNMP (Simple Network Management Protocol) . . . . .</b>	<b>10-1</b>
Introduction . . . . .	10-1
Configuring SNMP Parameters and Traps . . . . .	10-2
Procedure for Defining a New Network Management Station . . . . .	10-4
Viewing SNMP Statistics . . . . .	10-7
Trap Tables . . . . .	10-10
SNMP Standard Traps . . . . .	10-10
Extended Traps . . . . .	10-21

<b>11</b>	<b>DNS Resolver and RMON</b>	11-1
	Introduction	11-1
	Configuring the DNS Resolver	11-1
	The Names Submenu	11-1
	Remote Network Monitoring (RMON)	11-3
	Probes and Events	11-3
	Ethernet Probes	11-3
	History Probes	11-3
	Alarm Probes	11-3
	Monitoring Probes	11-4
	Monitoring Events	11-5
<b>12</b>	<b>Managing Ethernet Modules</b>	12-1
	The Ethernet Management Menus	12-2
	Configuring 10/100 Auto-Sensing Ethernet Ports	12-3
	Configuring High-Density Ethernet Ports	12-5
	Viewing Configurations for Ethernet Ports	12-6
	OmniChannel	12-7
	Creating an OmniChannel	12-8
	Adding Ports to an OmniChannel	12-9
	Deleting an OmniChannel	12-10
	Deleting Ports from an OmniChannel	12-11
	Viewing OmniChannel Parameters	12-12
<b>13</b>	<b>Managing 802.1Q Groups</b>	13-1
	IEEE 802.1Q Sections Not Implemented	13-1
	Application Example	13-2
	Single vs. Multiple Spanning Tree	13-3
	Assigning an 802.1Q Group to a Port	13-5
	Modifying 802.1Q Groups	13-7
	Viewing 802.1Q Groups in a Port	13-8
	Deleting 802.1Q Groups from a Port	13-9

<b>14</b>	<b>Configuring Bridging Parameters</b>	14-1
	Configuration Overview	14-3
	Bridge Management Menu	14-4
	Selecting a Default Group	14-6
	Using the + or - to Change Groups	14-6
	Bridging Commands	14-7
	Displaying Bridge Forwarding Table	14-7
	Configuring a Static Bridge Address	14-9
	Modifying a Static Bridge Address	14-10
	Deleting a Static Bridge Address	14-11
	Displaying Static Bridge Addresses	14-12
	Displaying Bridge Port Statistics	14-13
	Displaying Media Access Control (MAC) Information	
	for a Specific MAC address	14-15
	Displaying Media Access Control (MAC) Information for all MAC addresses	14-16
	Display Statistics of Bridge MAC Addresses	14-16
	Clear Statistics of Bridge MAC Addresses	14-17
	Display Remote Trunking Stations	14-17
	View the Domain Bridge Mapping Table	14-18
	Setting Flood Limits	14-20
	Setting Flood Limits for a Group	14-20
	Displaying Group Flood Limits	14-21
	Configuring Spanning Tree	14-22
	Configuring Spanning Tree Parameters	14-23
	Display Spanning Tree Bridge Parameters	14-26
	Configuring Spanning Tree Port Parameters	14-28
	Displaying Spanning Tree Port Parameters	14-30
<b>15</b>	<b>Configuring Frame Translations</b>	15-1
	Protocols other than IP and IPX	15-1
	The SNAP Conversion	15-2
	Other Conversions	15-2
	Summary of Non-IPX Encapsulation Transformation Rules	15-2
	IPX Encapsulation Transformation Rules	15-3
	The Network Header	15-4
	Address Mapping	15-4
	Address Mapping in IP: ARP	15-4
	Address Mapping in IPX	15-5

Frame Size Requirements	15-6
Insertion of Frame Padding	15-6
Stripping of Padding for all IEEE 802.3 Frames.	15-6
No stripping of non-IPX Ethertype Frames	15-6
IPX Specific Stripping	15-6
MTU Handling	15-6
IP Fragmentation	15-7
ICMP Based MTU Discovery	15-7
IPX Packet Size Negotiation	15-7
Other Protocols	15-7
Banyan Vines	15-8
Configuring Encapsulation Options	15-9
Forwarding versus Flooding	15-9
Port Based Translation Options	15-9
MAC Address Based Translation Options	15-9
“Native” versus “Non-Native” on Ethernet	15-10
No Translation on Trunk or PTOP ports	15-10
The User Interface	15-11
The addvp, modvp and crgp Commands	15-11
The Default Translation Option	15-11
Ethernet Factory Default Translations	15-12
ATM LANE Factory Default Translations	15-12
The Ethertype Option	15-13
The SNAP Option	15-14
The LLC Option	15-15
Interaction with the new interface	15-15
The “vi” Command	15-16
The Switch Menu	15-17
Factory Defaults	15-17
Default Ethernet Translations	15-18
Port Translations	15-19
Configuring Additional Ports	15-20
Displaying Ethernet Switch Statistics	15-20
Any to Any MAC Translations	15-24
Default Autoencapsulation	15-25
Translational Bridging	15-26
Learning	15-26
Translations across Trunks	15-26
Dissimilar LAN Switching Capabilities	15-27
Switching Between Similar LANs	15-27
Switching Between Ethernet LANs Across a Trunked Backbone	15-28
Switching Between Similar LANs across a Native Backbone	15-29

<b>16 Managing Groups and Ports</b>	16-1
How Ports Are Assigned to Groups	16-2
Static Port Assignment	16-2
Dynamic Port Assignment (Group Mobility)	16-2
How Dynamic Port Assignment Works	16-3
Mobile Groups	16-5
Configuring Mobile Groups	16-5
Turning Group Mobility On or Off	16-6
Understanding Port Membership in Mobile Groups	16-7
How a Device Is Dropped from the Default Mobile Group (def_group)	16-8
How a Port's Primary Mobile Group Changes (move_from_def)	16-9
How a Port Ages Out of a Mobile Group (move_to_def)	16-10
Configuring Switch-Wide Group Mobility Variables	16-11
Viewing Ports in a Mobile Group	16-13
Viewing a Port's Mobile Group Affiliations	16-13
Dynamic LANE Services	16-14
Dynamic LANE Services and Non-Dynamic LANE Services	16-14
Creating Auto-Activated LANE Services	16-15
Deleting an Auto-Activated Service	16-15
Viewing Auto-Activated Services	16-16
Non-Mobile Groups and AutoTracker VLANs	16-17
Routing in a Non-Mobile Group	16-17
Spanning Tree and Non-Mobile Groups	16-18
Group and Port Software Commands	16-19
Creating a New Group	16-20
Step 1. Entering Basic Group Information	16-21
Step 2. Configuring the Virtual Router Port (Optional)	16-22
Step 3. Set Up Group Mobility and User Authentication	16-27
Step 4. Configuring Virtual Ports	16-28
Step 5. Configure Auto-Activated LANE Ports (Mobile Groups Only)	16-33
Step 6. Configuring AutoTracker Policies (Mobile Groups Only)	16-34
Creating an ATM CIP Group	16-35
Viewing Current Groups	16-37
Modifying a Group or VLAN	16-39
Viewing Your Changes	16-40
Saving Your Changes	16-40
Canceling Your Changes	16-40
Changing the IP Address	16-40
Changing the IP Subnet Mask	16-40
Enabling IP or IPX Routing	16-41
Deleting a Group	16-42
Adding Virtual Ports	16-43

Modifying a Virtual Port . . . . .	16-44
Deleting a Virtual Port . . . . .	16-45
Viewing Information on Ports in a Group . . . . .	16-46
Viewing Detailed Information on Ports . . . . .	16-48
Viewing Port Statistics . . . . .	16-51
Viewing Port Errors . . . . .	16-53
Port Mirroring . . . . .	16-55
How Port Mirroring Works . . . . .	16-55
What Happens to the Mirroring Port . . . . .	16-55
Using Port Mirroring With External RMON Probes . . . . .	16-56
Setting Up Port Mirroring . . . . .	16-58
Disabling Port Mirroring . . . . .	16-58
Port Monitoring . . . . .	16-59
Port Monitoring Menu . . . . .	16-59
RAM Disk System for Data Capture Files . . . . .	16-60
Configuring RAM Drive Resources (pmcfg) . . . . .	16-60
Changing the Default System Directory (cd) . . . . .	16-60
Starting a Port Monitoring Session (pmon) . . . . .	16-61
If You Chose Dump to Screen . . . . .	16-62
If You Did Not Choose Dump to Screen . . . . .	16-62
Ending a Port Monitoring Session . . . . .	16-63
Viewing Port Monitoring Statistics (pmstat) . . . . .	16-63
Port Mapping . . . . .	16-64
Groups/VLANs and Port Mapping . . . . .	16-64
The Details of Port Mapping . . . . .	16-65
Who Can Talk to Whom? . . . . .	16-66
Port Mapping Limitations . . . . .	16-66
Creating a Port Mapping Set . . . . .	16-67
Adding Ports to a Port Mapping Set . . . . .	16-68
Removing Ports from a Port Mapping Set . . . . .	16-69
Viewing a Port Mapping Set . . . . .	16-70
Deleting a Port Mapping Set . . . . .	16-70
Priority VLANs . . . . .	16-71
Configuring VLAN Priority . . . . .	16-72
Viewing VLAN Priority . . . . .	16-72

<b>17</b>	<b>Configuring Group and VLAN Policies</b>	17-1
	AutoTracker Policy Types	17-2
	Defining and Configuring AutoTracker Policies	17-4
	Where These Procedures Start	17-4
	Defining a Port Policy	17-5
	Defining a MAC Address Policy	17-6
	Defining a Protocol Policy	17-7
	Defining a Network Address Policy	17-9
	Defining Your Own Rules	17-11
	Defining a Port Binding Policy	17-13
	Defining a DHCP Port Policy	17-17
	Defining a DHCP MAC Address Policy	17-18
	Viewing Mobile Groups and AutoTracker VLANs	17-19
	Viewing Policy Configurations	17-20
	Viewing Virtual Ports' Group/VLAN Membership	17-21
	View VLAN Membership of MAC Devices	17-22
	Application Example: DHCP Policies	17-23
	The VLANs	17-23
	DHCP Servers and Clients	17-24
	DHCP Port and MAC Rules	17-25
<b>18</b>	<b>Interswitch Protocols</b>	18-1
	Interswitch Protocol Commands	18-1
	XMAP	18-2
	XMAP Transmission States	18-3
	Discovery Transmission State	18-3
	Common Transmission State	18-4
	Passive Reception State	18-4
	Common Transmission and Remote Switches	18-4
	Configuring XMAP	18-5
	Enabling or Disabling XMAP	18-5
	Viewing a List of Adjacent Switches	18-5
	Configuring the Discovery Transmission Time	18-6
	Configuring the Common Transmission Time	18-7
	VLAN Advertisement Protocol (VAP)	18-8
	VAP and Port Policies	18-9
	Configuring VAP	18-9



GMAP	18-10
GMAP Updating Rules	18-10
Configuring GMAP	18-11
Enabling and Disabling GMAP	18-11
Configuring the Gap Time	18-11
Configuring the Interpacket Update Time	18-12
Configuring the Hold Time	18-12
Displaying GMAP Statistics by MAC Address	18-13
<b>19 Managing AutoTracker VLANs</b>	19-1
The AutoTracker Menu	19-2
AutoTracker VLANs	19-3
AutoTracker VLAN Policies	19-3
The Default VLAN	19-4
How Devices are Assigned to AutoTracker VLANs	19-5
The defvl Command	19-5
Devices that Generate a Secondary Traffic Type	19-6
Router Traffic in IP and IPX Network Address VLANs	19-7
Port Policy Functionality	19-9
Frame Flooding in AutoTracker VLANs	19-15
Routing Between AutoTracker VLANs	19-15
Creating AutoTracker VLANs	19-16
Step A. Entering Basic VLAN Information	19-16
Step B. Defining and Configuring VLAN Policies	19-18
Step C. Configuring the Virtual Router Port (Optional)	19-19
Modifying an AutoTracker VLAN	19-23
Deleting an AutoTracker VLAN	19-25
Viewing AutoTracker VLANs	19-26
Viewing Policy Configurations	19-27
Viewing Virtual Ports' VLAN Membership	19-28
View VLAN Membership of MAC Devices	19-29
Creating a VLAN for Banyan Vines Traffic	19-30

<b>20 Multicast VLANs</b>	20-1
How Devices are Assigned to Multicast VLANs	20-2
Multicast VLANs and Multicast Claiming	20-2
Frame Flooding in Multicast VLANs	20-3
Creating Multicast VLANs	20-4
Step A. Entering Basic Information	20-5
Step B. Defining the Multicast Address	20-6
Step C. Defining the Recipients of Multicast Traffic	20-7
Defining Recipients By Port	20-7
Defining Recipients By MAC Address	20-8
Modifying Multicast VLANs	20-9
Deleting a Multicast VLAN	20-11
Modifying a Multicast Address Policy	20-12
Viewing Multicast VLANs	20-13
Viewing Multicast VLAN Policies	20-14
Viewing the Virtual Interface of Multicast VLANs	20-15
<b>21 AutoTracker VLAN Application Examples</b>	21-1
Application Example 1	21-2
VLANs Based on Logical Policies	21-2
Application Example 2	21-4
VLANs in IPX Networks	21-4
IPX VLAN Assignment at Bootup	21-5
Application Example 3	21-7
Routing in IPX Networks	21-7
Application Example 4	21-9
Traversing a Backbone	21-9
<b>22 IP Routing</b>	22-1
Introduction	22-1
IP Routing Overview	22-2
Routing Protocols	22-2
Transport Protocols	22-3
Application-Layer Protocols	22-3
Additional IP Protocols	22-3
Setting Up IP Routing on the Switch	22-4
The Networking Menu	22-6
The IP Submenu	22-7

Viewing the Address Translation (ARP) Table . . . . .	22-8
Displaying All Entries in the ARP Table . . . . .	22-8
Adding Entries to the ARP Table . . . . .	22-9
Deleting Entries from the ARP Table . . . . .	22-10
Flushing Temporary Entries from the ARP Table . . . . .	22-10
Finding a Specific IP Address in the ARP Table . . . . .	22-10
Finding a Specific MAC Address in the ARP Table . . . . .	22-11
Viewing IP Statistics and Errors . . . . .	22-12
Viewing the IP Forwarding Table . . . . .	22-14
Adding an IP Static Route . . . . .	22-16
Removing an IP Static Route . . . . .	22-18
Viewing ICMP Statistics and Errors . . . . .	22-19
Using the PING Command . . . . .	22-21
Viewing UDP Statistics and Errors . . . . .	22-22
Viewing the UDP Listener Table . . . . .	22-23
Viewing RIP Statistics and Errors . . . . .	22-24
Viewing TCP Statistics . . . . .	22-25
Viewing the TCP Connection Table . . . . .	22-27
Using the TELNET Command . . . . .	22-28
Tracing an IP Route . . . . .	22-29
Flushing the RIP Routing Tables . . . . .	22-29
Configuring IP RIP Filters . . . . .	22-30
Adding a “Global” IP RIP Filter . . . . .	22-30
Adding an IP RIP Filter For a Specific Group or VLAN . . . . .	22-31
IP RIP Filter Precedence . . . . .	22-32
Deleting IP RIP Filters . . . . .	22-32
Displaying IP RIP Filters . . . . .	22-33
Displaying a List of All IP RIP Filters . . . . .	22-33
Displaying a List of “Global” IP RIP Filters . . . . .	22-34
Displaying a List of Specific IP RIP Filters . . . . .	22-34
Viewing the IP-to-MAC Address Table . . . . .	22-35
Displaying All Entries in the IP-to-MAC Table . . . . .	22-35
Displaying Information for a Specific IP Address . . . . .	22-36
Flushing Entries from the Table . . . . .	22-36
Path MTU Discovery . . . . .	22-37

<b>23</b>	<b>UDP Forwarding</b>	23-1
	UDP Relay Hardware/Software Support	23-1
	UDP Relay Configuration Screen	23-2
	BOOTP/DHCP Relay	23-3
	Overview of DHCP	23-3
	DHCP and the OmniAccess 408	23-3
	BOOTP/DHCP Relay and Authentication	23-4
	External BOOTP relay	23-5
	Internal BOOTP/DHCP Relay	23-6
	Example 1	23-6
	Example 2	23-7
	Enabling BOOTP/DHCP Relay	23-8
	Configuring BOOTP/DHCP Relay Parameters	23-9
	NetBIOS Relays	23-10
	Overview of NetBIOS	23-10
	NetBIOS Relay Application	23-11
	Configuring NBNS Relay	23-12
	Next-Hop Addresses for NBNS	23-13
	Forwarding VLANs for NBNS Relay	23-14
	Configuring NBDD Relay	23-15
	Next-Hop Addresses for NBDD	23-16
	Forwarding VLANs for NBDD Relay	23-17
	Generic Service UDP Relay	23-18
	Generic Services Menu	23-18
	Adding a Generic Service	23-18
	Modifying a Generic Service	23-20
	Deleting a Generic Service	23-21
	Viewing UDP Relay Statistics	23-22
<b>24</b>	<b>IPX Routing</b>	24-1
	Introduction	24-1
	IPX Routing Overview	24-2
	IPX Protocols	24-2
	Setting Up IPX Routing on the Switch	24-2
	The IPX Submenu	24-4
	Viewing the IPX Routing Table	24-5
	Displaying All Entries in the IPX Routing Table	24-5
	Displaying a List of Specific IPX Routes	24-6
	Viewing IPX Statistics	24-7
	Viewing the IPX SAP Bindery	24-9
	Displaying a List of Specific SAP Servers	24-9
	Adding an IPX Static Route	24-11

Removing an IPX Static Route . . . . .	24-12
Turning the IPX Router Complex On and Off . . . . .	24-13
Flushing the IPX RIP/SAP Tables . . . . .	24-13
Using the IXPING Command . . . . .	24-14
Configuring IPX RIP/SAP Filtering . . . . .	24-16
Adding a “Global” IPX RIP/SAP Filter . . . . .	24-17
Adding an IPX RIP/SAP Filter for a Specific Group or VLAN . . . . .	24-18
Deleting an IPX RIP/SAP Filter . . . . .	24-20
Displaying IPX RIP/SAP Filters . . . . .	24-21
Displaying a List of All IPX Filters . . . . .	24-21
Displaying a List of “Global” IPX Filters . . . . .	24-22
Displaying a List of Specific IPX Filters . . . . .	24-22
IPX RIP/SAP Filter Precedence . . . . .	24-23
Controlling IPX Type 20 Packet Forwarding . . . . .	24-24
Configuring NetWare to Minimize WAN Connections . . . . .	24-25
Configuring RIP and SAP Timers . . . . .	24-27
Adding a RIP and SAP Timer . . . . .	24-27
Viewing RIP and SAP Timers . . . . .	24-27
Configuring Extended RIP and SAP Packets . . . . .	24-29
Enabling or Disabling Extended RIP and SAP Packets . . . . .	24-29
Viewing the Current Status of Extended Packets . . . . .	24-29
Configuring an IPX Default Route . . . . .	24-30
Adding an IPX Default Route . . . . .	24-30
Viewing the Status of an IPX Default Route . . . . .	24-30
Disabling an IPX Default Route . . . . .	24-30
<b>25 Managing ATM Ports . . . . .</b>	<b>25-1</b>
LAN Switch With ATM Uplinks . . . . .	25-2
The ATM Menu . . . . .	25-3
Modifying an ATM Access Port Configuration . . . . .	25-4
Creating a Virtual Channel Connection . . . . .	25-7
Modifying a Virtual Channel Connection . . . . .	25-10
Deleting a Virtual Channel Connection . . . . .	25-10
Creating a Virtual ATM Address . . . . .	25-11
Modifying Virtual ATM Addresses . . . . .	25-12
Deleting a Virtual ATM Address . . . . .	25-12
Viewing ATM Port Configuration Information . . . . .	25-13
Viewing SSCOP, ILMI, and PHY . . . . .	25-16
Viewing Virtual Channel Connections . . . . .	25-18
Viewing Virtual ATM Addresses . . . . .	25-20

Viewing the ATM Layer Statistics Table . . . . .	25-22
Viewing the ATM Layer Rx Error Statistics Table . . . . .	25-23
Viewing the ATM Layer Tx Error Statistics Table . . . . .	25-25
Viewing the ATM Connection Statistics Table . . . . .	25-26
Viewing the ATM Connection Rx Error Statistics Table . . . . .	25-27
Viewing the ATM Connection Tx Error Statistics Table . . . . .	25-29
Traffic Shaping . . . . .	25-31
Configuring Traffic Shaping . . . . .	25-31
Viewing Traffic Shaping Parameters . . . . .	25-33
<b>26 Managing Circuit Emulation Ports . . . . .</b>	<b>26-1</b>
The Circuit Emulation Ports . . . . .	26-2
The Circuit Emulation Ports: An Overview . . . . .	26-2
Circuit Emulation T1/E1 Ports . . . . .	26-3
Configuring a Circuit Emulation Port . . . . .	26-4
Circuit Emulation Services . . . . .	26-5
Circuit Emulation Clocking Modes . . . . .	26-6
Synchronous Clocking . . . . .	26-6
Synchronous Residual Time Stamp (SRTS) Clocking . . . . .	26-6
Adaptive Clocking . . . . .	26-7
Application Example . . . . .	26-8
The Circuit Emulation Menu . . . . .	26-9
Creating a Virtual Channel Connection on a T1/E1 Port . . . . .	26-10
Circuit Emulation Port Number . . . . .	26-10
Valid VCI Range . . . . .	26-10
Creating a Virtual Channel Connection on a Serial Port . . . . .	26-14
Circuit Emulation Port Number . . . . .	26-14
Valid VCI Range . . . . .	26-14
Configuring a Circuit Emulation T1/E1 Port . . . . .	26-15
Configuring a Circuit Emulation Serial Port . . . . .	26-17
Modifying a Virtual Channel Connection . . . . .	26-19
Deleting a Virtual Circuit . . . . .	26-20
Viewing Information for a T1/E1 Virtual Circuit . . . . .	26-21
Viewing Information for a Serial Port Virtual Circuit . . . . .	26-23

Viewing Circuit Emulation Information . . . . .	26-24
Viewing General Circuit Emulation Information . . . . .	26-24
Viewing Information on the CES slot . . . . .	26-25
Viewing Information for a T1 or E1 Port . . . . .	26-27
Viewing Information for a Serial Port . . . . .	26-28
Viewing Information for a T1/E1 Virtual Circuit . . . . .	26-29
Viewing Information for a Serial Port Virtual Circuit . . . . .	26-30
Clearing ATM Circuit Emulation Statistics . . . . .	26-31
<b>27 Configuring ATM Services . . . . .</b>	<b>27-1</b>
Introduction . . . . .	27-1
ATM Services . . . . .	27-1
PVC/SVC Support . . . . .	27-2
Service . . . . .	27-2
SVC . . . . .	27-2
PVC . . . . .	27-2
LANE Client (LEC) Services . . . . .	27-3
Token Ring vs. Ethernet Networks . . . . .	27-4
LANE Version 2.0 . . . . .	27-4
ATM Trunking . . . . .	27-5
Groups over ATM . . . . .	27-5
VLANs over ATM . . . . .	27-6
Spanning Tree and Trunking . . . . .	27-6
Translations Across Trunks . . . . .	27-6
Classical IP Routing . . . . .	27-7
LLC Header Encapsulation . . . . .	27-7
IP to ATM Address Resolution . . . . .	27-7
IP Over ATM Signaling . . . . .	27-7
Typical CIP over ATM Configuration . . . . .	27-8
Point-to-Point Bridging . . . . .	27-9
VLAN Clusters . . . . .	27-10
Method 1 . . . . .	27-11
Method 2 . . . . .	27-11
Configuring ATM Services . . . . .	27-12
Services Menu . . . . .	27-12
Creating a Service . . . . .	27-13
Creating a LANE Client Service . . . . .	27-15
Setting LANE Client Parameters . . . . .	27-17
Creating a Trunking Service . . . . .	27-19
Creating a Classical IP Service . . . . .	27-20
Creating a PTOp Bridging Service . . . . .	27-22
Creating a VLAN Cluster Service . . . . .	27-24

Modifying a Service . . . . .	27-26
Modifying a LANE Client Service . . . . .	27-26
Modifying a Trunking Service . . . . .	27-27
Modifying a Classical IP Service . . . . .	27-28
Adding Static ARP Entries for CIP . . . . .	27-30
Modifying a PTOp Bridging Service . . . . .	27-31
Modifying a VLAN Cluster Service . . . . .	27-32
Modifying VLAN Cluster Parameters . . . . .	27-33
Deleting a Service . . . . .	27-34
Deleting Static ATM ARP Entries for CIP . . . . .	27-35
Viewing ATM Access Port Services . . . . .	27-36
Viewing General Service Statistics on a Port . . . . .	27-37
Viewing Service Statistics for a LANE Client . . . . .	27-38
Viewing the LANE LE_ARP Table . . . . .	27-41
Viewing ATM Service Statistics for Classical IP . . . . .	27-42
Viewing the CIP ARP Table . . . . .	27-44
Viewing Service Statistics for VLAN Clusters . . . . .	27-45
 <b>28 Inverse Multiplexing Over ATM (IMA) . . . . .</b>	 28-1
IMA Hardware . . . . .	28-2
IMA Software . . . . .	28-2
OA-408-IMA Software Slot Numbering . . . . .	28-2
OmniAccess Default IMA Group . . . . .	28-2
IMA Configuration Overview . . . . .	28-3
IMA Process Overview . . . . .	28-4
Adding and Deleting Links in an IMA Group . . . . .	28-5
ATM Services on an IMA Group . . . . .	28-6
Sample IMA Network . . . . .	28-6
IMA Application Example . . . . .	28-8
How to Set Up this Network . . . . .	28-9
IMA Theory of Operation . . . . .	28-11
IMA Link State Machine (LSM) . . . . .	28-11
IMA Synchronization Process . . . . .	28-12
The IMA Submenu . . . . .	28-13
Creating a New IMA Group . . . . .	28-14
Adding and Modifying IMA Group Membership . . . . .	28-17
Modifying an IMA Group . . . . .	28-19
Modifying an IMA Group with T1 Ports (Short-Haul Line) . . . . .	28-19
Modifying an IMA Group with T1 Ports (Long-Haul Line) . . . . .	28-22
Modifying an IMA Group with E1 Ports . . . . .	28-23
Configuring IMA Link Parameters . . . . .	28-26



Conducting an IMA Test . . . . .	28-27
Starting an IMA Test . . . . .	28-27
Ending an IMA Test . . . . .	28-29
Restarting an IMA Group . . . . .	28-30
Deleting an IMA Group . . . . .	28-31
Upgrading IMA Flash Memory on OA-408-IMA Switches . . . . .	28-32
Displaying the Summary Status of an IMA Group . . . . .	28-33
Displaying the Summary Status of an IMA Group . . . . .	28-33
Displaying the Summary Status of a Single IMA Group . . . . .	28-35
Displaying the Detailed Status of a Single IMA Group with Link Status . . . . .	28-38
Displaying the Summary Status of IMA Links . . . . .	28-41
Displaying the Summary Status of All IMA Links . . . . .	28-41
Displaying the Detailed Status of a Single IMA Link . . . . .	28-43
Displaying the Statistics for an IMA Group . . . . .	28-45
Displaying Summary Statistics for an IMA Group . . . . .	28-45
Displaying Detailed Statistics for an IMA Group . . . . .	28-47
Displaying 24-Hour Performance Statistics on a Local Group . . . . .	28-51
Displaying Current Performance Statistics on a Local Group . . . . .	28-52
Displaying Performance Statistics Intervals on a Local Group . . . . .	28-53
Displaying Detailed Statistics for IMA Links . . . . .	28-54
Displaying 24-Hour Performance Statistics on a Local Link . . . . .	28-57
Displaying Current Performance Statistics on a Local Link . . . . .	28-60
Displaying Performance Statistics Intervals on a Local Link . . . . .	28-61
Clearing IMA Group Statistics . . . . .	28-64
Clearing IMA Link Statistics . . . . .	28-64
Troubleshooting IMA Networks . . . . .	28-65
<b>29 Managing T1 and E1 Ports . . . . .</b>	<b>29-1</b>
T1 and E1 Overview . . . . .	29-2
The T1/E1 Menu . . . . .	29-3
Configuring a T1 Port . . . . .	29-4
Configuring an E1 Port . . . . .	29-7
Viewing T1/E1 Configuration and Alarm Information . . . . .	29-10
Viewing Information for all T1/E1 Ports in the Switch . . . . .	29-10
Viewing Information for T1/E1 Ports . . . . .	29-11
Viewing Information For a T1 Port . . . . .	29-12
Viewing Information For an E1 Port . . . . .	29-14

Viewing T1/E1 Local Statistics . . . . .	29-16
Viewing Total Local Statistics . . . . .	29-16
Viewing Current Local Statistics . . . . .	29-17
Viewing Local Historical Statistics . . . . .	29-18
Viewing T1 Remote Statistics . . . . .	29-19
Viewing Total Remote Statistics . . . . .	29-19
Viewing Current Remote Statistics . . . . .	29-20
Viewing Remote Historical Statistics . . . . .	29-20
Clearing the Framer Statistics for a T1/E1 Port . . . . .	29-21
Running Bit Error Ratio Tests (BERT) . . . . .	29-22
Displaying BERT Statistics . . . . .	29-24
Clearing BERT Statistics . . . . .	29-25
Configuring Port Type (T1/E1) . . . . .	29-26
<b>30 Managing DS3/E3 Ports . . . . .</b>	<b>30-1</b>
DS3/E3 Overview . . . . .	30-1
DS3 Framing . . . . .	30-1
E3 Framing . . . . .	30-1
DS3/E3 Port Management Menu . . . . .	30-2
Configuring a DS3 Port . . . . .	30-2
Configuring an E3 Port . . . . .	30-5
Viewing DS3/E3 Configuration and Alarm Information . . . . .	30-8
Viewing Information for all DS3/E3 Ports in the Switch . . . . .	30-8
Viewing Information for DS3/E3 Ports on a Board . . . . .	30-9
Viewing Information for a DS3 Port . . . . .	30-10
Viewing Information for an E3 Port . . . . .	30-11
Viewing DS3/E3 Local Statistics . . . . .	30-14
Viewing DS3/E3 Local Total Statistics . . . . .	30-14
Displayed Statistics . . . . .	30-15
Viewing DS3/E3 Local Current Statistics . . . . .	30-16
Viewing DS3/E3 Local Interval (Historical) Statistics . . . . .	30-17
Viewing ATM Physical Layer Statistics for DS3 (CbitParity PLCP Sublayer) . . . . .	30-18
Status Definitions for DS3 3. . . . .	0-19
Statistics Definitions for DS3 . . . . .	30-20
Viewing ATM Physical Layer Statistics for DS3 (CbitParity ADM Sublayer) . . . . .	30-21
Viewing ATM Physical Layer Statistics for DS3 (M23 Type PLCP Sublayer) . . . . .	30-22
Viewing ATM Physical Layer Statistics for DS3 (M23 Type ADM Sublayer) . . . . .	30-23
Viewing ATM Physical Layer Statistics for E3 (G.751 PLCP Sublayer) . . . . .	30-24
Status Definitions for E3 G.751 PLCP . . . . .	30-25
Statistics Definitions for E3, PLCP G.751 . . . . .	30-25
Viewing ATM Physical Layer Statistics for E3 (G.751 ADM Sublayer) . . . . .	30-26
Statistics Definitions for E3, ADM G.751 . . . . .	30-26

Viewing ATM Physical Layer Statistics for E3 (G.832 ADM Sublayer) . . . . .	30-27
Status Definitions for G.832 ADM 3 . . . . .	0-27
Statistics definitions for E3, ADM G.832 . . . . .	30-28
Viewing ATM Physical Layer Interval Statistics for DS3 (CbitParity PLCP Sublayer) . . . . .	30-29
Viewing ATM Physical Layer Interval Statistics for DS3 (CbitParity ADM Sublayer) . . . . .	30-30
Viewing ATM Physical Layer Interval Statistics for DS3 (M23 Type PLCP Sublayer) . . . . .	30-31
Viewing ATM Physical Layer Interval Statistics for DS3 (M23 Type ADM Sublayer) . . . . .	30-32
Viewing ATM Physical Layer Interval Statistics for E3 (G.832 PLCP Sublayer) . . . . .	30-33
Viewing ATM Physical Layer Interval Statistics for E3 (G.751 ADM Sublayer) . . . . .	30-34
Clearing Interval Statistics . . . . .	30-34
Configuring Port Type . . . . .	30-35
<b>31 Troubleshooting . . . . .</b>	<b>31-1</b>
Introduction . . . . .	31-1
Detecting Problems . . . . .	31-1
Reporting Problems . . . . .	31-1
Software Problems . . . . .	31-2
Can't Install Software . . . . .	31-2
Operational Problems . . . . .	31-2
Hardware Problems . . . . .	31-4
Error Messages . . . . .	31-5
Chassis Error Messages . . . . .	31-7
<b>32 Running Hardware Diagnostics . . . . .</b>	<b>32-1</b>
Introduction . . . . .	32-1
Getting Started . . . . .	32-2
Accessing the Diagnostics Submenu . . . . .	32-4
Temperature Masking . . . . .	32-5
Initiating Hardware Tests . . . . .	32-6
Port Test Wrap Cable/Plug Requirements . . . . .	32-8
Sample Test Session: OmniAccess 408 . . . . .	32-9
If You Do Not Run Port Tests . . . . .	32-11
Displaying Available Diagnostic Tests . . . . .	32-12
Configuring the Diagnostic Test Environment . . . . .	32-13
Configuring Tests for Ethernet Slots . . . . .	32-14
Diagnostic Test Cable Schematics . . . . .	32-15

<b>A</b>	<b>The Boot Line Prompt</b>	A-1
	Entering the Boot Prompt	A-2
	Boot Prompt Basics	A-3
	Resuming Switch Boot (@)	A-3
	Displaying Current Configuration (p)	A-4
	Loading the Last Configured Boot File (l)	A-4
	Listing Available Files in the Flash Memory (L)	A-4
	Deleting All Files in the Flash Memory (P)	A-5
	Deleting Specific Files in the Flash Memory (R)	A-5
	Saving Configuration Changes (S)	A-5
	Viewing Version Number (V)	A-5
	Configuring an OmniAccess 408	A-6
<b>B</b>	<b>Pinouts and Custom Cables</b>	B-1
	OmniAccess 408 Pinouts	B-2
	Console Management Port (DB-9 Connector)	B-2
	Ethernet Port (RJ-45 Connector)	B-2
	T1/E1 Port (RJ-48C Connector)	B-2
	Circuit Emulation Services (CES) Universal Serial Port	B-3
	CES Universal Serial Port Specifications	B-4
	Custom Cables	B-6
	RJ-45 to DB15F Cable Assembly (For T1/E1 Port 120W Connections)	B-6
	RJ-45 to BNC Cable Assembly (For E1 75W Port Connections)	B-7
	<b>Index</b>	I-1